



## **Command Line Interface Reference Guide for Cisco Unified Communications Solutions, Release 12.5(1)SU4**

**First Published:** 2021-02-23

**Last Modified:** 2023-10-03

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2021 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### PREFACE

<b>Preface</b>	<b>xxiii</b>
Purpose	xxiii
Audience	xxiii
Organization	xxiii
Related Documents	xxiv

---

### CHAPTER 1

<b>About CLI</b>	<b>1</b>
CLI Privilege Levels	1
Start CLI session	1
Tab completes command	3
Command help	3
Ctrl-C exits command	4
Quit CLI session	4

---

### CHAPTER 2

<b>Delete Commands</b>	<b>5</b>
delete account	5
delete cuc futuredelivery	5
delete cuc locale	6
delete dns	7
delete dscp	7
delete ipsec policy_group	8
delete ipsec policy_name	8
delete process	9
delete smtp	9

---

### CHAPTER 3

<b>File Commands</b>	<b>11</b>
----------------------	-----------

file build log	11
file check	15
file delete	16
file delete tftp	16
file delete dir tftp	17
file dump	18
file dump sftpdetails	18
file dump tftp	19
file fragmentation sdi	19
file fragmentation sdi file	20
file fragmentation sdi all	20
file fragmentation sdl	21
file fragmentation sdl file	21
file fragmentation sdl all	22
file get	22
file get salog	23
file get tftp	24
file list	25
file list salog	26
file list tftp	27
file search	28
file search tftp	28
file tail activelog	29
file tail tftp	30
file view	30
file view activelog	31
file view inactivelog	32
file view system-management-log	33
file view tftp	33

---

**CHAPTER 4****License Commands 35**

license smart deregister	35
license smart register idtoken <token> [force]	36
license smart renew auth	36

license smart renew ID	36
license smart transport direct	37
license smart transport gateway <URL>	37
license smart transport proxy <proxy-server> <proxy-port>	38
license smart factory reset	38
license smart reservation enable	39
license smart reservation disable	39
license smart reservation request	39
license smart reservation cancel	40
license smart reservation install "<authorization-code>"	40
license smart reservation install-file <url>	40
license smart reservation return	41
license smart reservation return authorization "<authorization-code>"	41
license smart export request local <exportfeaturename>	42
license smart export return local <exportfeaturename>	42
license smart export cancel	43

---

**CHAPTER 5**
**Run Commands 45**

run cuc dbquery	45
run cuc preupgrade test	46
run cuc smtpstest	48
run cuc sysagent task	48
run cuc vui rebuild	49
run loadcsv	50
run loadxml	50
run sql	51
run pe sql	51

---

**CHAPTER 6**
**Set Commands 53**

set account enable	55
set account name	56
set accountlocking	57
set accountlocking count	58
set accountlocking unlocktime	59

set account ssorecoveryurlaccess	59
set account ssoidvalue	60
set cert bulk consolidate	61
set cert bulk export	61
set cert bulk import	62
set cert bulk sftp	62
set cert default-ca-list disable	63
set cert default-ca-list enable	64
set cert delete	66
set cert import	66
set cert regen	67
set cert regen ITLRecovery	68
set cli pagination	68
set cli session timeout	69
set commandcount	70
set csr gen	70
set cuc jetty stderrlog	71
set cuc jetty stdoutlog	72
set cuc jetty requestlog	73
set cuc speechview registration certificate size	73
set cuc srsv timeout	74
set cuc trace	74
set date	75
set dscp defaults	76
set dscp	76
set dscp marking	77
set ipsec policy_group	78
set ipsec policy_name	78
set key regen authz encryption	79
set key regen authz signing	79
set logging	79
set Login Grace Timeout	80
set network cluster publisher	80
set network cluster subscriber details	81

set network cluster subscriber dynamic-cluster-configuration	82
set network dhcp eth0	82
set network dns	83
set network dns options	83
set network domain	84
set network failover	85
set network gateway	86
set network hostname	86
set network ip eth0	88
set network ipv6 dhcp	89
set network ipv6 gateway	90
set network ipv6 service	91
set network ipv6 static_address	91
set network max_ip_contrack	92
set network mtu	92
set network name-service hosts cache-enable	93
set network name-service hosts max-db-size	94
set network name-service hosts negative-time-to-live	94
set network name-service hosts persistent	95
set network name-service hosts positive-time-to-live	95
set network name-service hosts suggested-size	95
set network name-service services cache-enable	96
set network name-service services max-db-size	96
set network name-service services negative-time-to-live	97
set network name-service services persistent	97
set network name-service services positive-time-to-live	98
set network name-service services suggested-size	98
set network nic eth0	99
set network ntp option	99
set network pmtud state	100
set network restore	100
set network status eth0	102
set network name-service	102
set password complexity minimum-length	103

set password age	103
set password change-at-login	104
set password complexity character	104
set password complexity character difference	106
set password complexity character max-repeat	106
set password expiry maximum-age	107
set password expiry user maximum-age configure	108
set password expiry minimum-age	108
set password expiry user maximum-age	109
set password expiry user minimum-age	110
set password history	111
set password inactivity	111
set password system bootloader encryptHash	112
set password user admin	112
set password user security	113
Set replication-sync monitor	114
set samltrace level	114
set session maxlimit	115
set smtp	115
set strace enable	116
set strace disable	116
set timezone	117
set tls min-version	117
set trace disable	118
set trace enable	119
set tlsresumptiontimeout	120
set tlstrace*	120
set tlstrace disable	120
set tlstrace enable	121
set web-security	121
set webapp session timeout	123
set webapp session maxlimit	123
set workingdir	126



---

**CHAPTER 7****Show Commands 127**

show account	131
show accountlocking	131
show cert default-ca-list	132
show cert list	133
show cert list type	134
show cert own	134
show cert trust	135
show cli pagination	135
show cli session timeout	136
show csr list	136
show csr list type	137
show csr own	137
show csr own name	138
show ctl	139
show cuc cluster status	139
show cuc config groups	139
show cuc config settings	140
show cuc dbconsistency	141
show cuc dbcontents	142
show cuc dbschema	143
show cuc dbserver disk	144
show cuc dbserver session	144
show cuc dbserver sessions all	145
show cuc dbserver sessions list	145
show cuc dbserver user list	146
show cuc dbserver user waiting	146
show cuc dbtable contents	146
show cuc dbtable list	147
show cuc dbtable schema	148
show cuc dbview contents	150
show cuc dbview list	151
show cuc dbview schema	152

show cuc jetty ssl status	153
show cuc locales	153
show cuc speechview registration certificate size	154
show cuc sysagent task list	154
show cuc sysagent task results	155
show cuc sysinfo	156
show cuc tech dbschemaversion	157
show cuc tech dbserver all	158
show cuc tech dbserver integrity	158
show cuc tech dbserver log diagnostic	159
show cuc tech dbserver log message	159
show cuc tech dbserver status	160
show cuc trace levels	160
show cuc version	161
show date	162
show diskusage	162
show dscp all	163
show dscp defaults	163
show dscp marking	163
show dscp status	164
show environment fans	165
show environment power-supply	165
show environment temperatures	165
show fileserver transferspeed	166
show haproxy client-auth	166
show haproxy num-threads	167
show hardware	168
show ipsec information	168
show ipsec policy_group	169
show ipsec policy_name	170
show ipsec status	170
show itl	170
show logins	171
show logins successful	171

show logins unsuccessful	172
show key authz encryption	172
show key authz signing	172
show license all	173
show license status	173
show license summary	173
show license tech support	174
show license trace	174
show license UDI	174
show license usage	175
show Login Grace Timeout	175
show media streams	175
show memory	177
show myself	177
show network all	178
show network cluster	178
show network dhcp eth0	178
show network eth0	179
show network failover	179
show network ip_contrack	180
show network ipprefs	180
show network ipv6	181
show network max_ip_contrack	181
show network ntp option	182
show network route	182
show network status	183
show network name-service attributes	183
show network name-service cache-stats	184
show network name-service {hosts services} attributes	185
show open files all	185
show open files process	186
show open files regexp	186
show open ports all	186
show open ports regexp	187

show packages	187
show password	188
show password change-at-login	188
show password complexity character	189
show password complexity length	189
show password expiry	189
show password expiry user	190
show password expiry user list	190
show perf counterhelp	191
show perf list categories	191
show perf list classes	191
show perf list counters	192
show perf list instances	192
show perf query class	193
show perf query counter	193
show perf query instance	194
show perf query path	195
show process list	195
show process load	196
show process name	197
show process name process-name	197
show process open	198
show process open-fd	198
show process pid	199
show process search	199
show process user	200
show process using-most cpu	200
show process using-most memory	201
show registry	201
show risdb list	202
show risdb query	203
show samltrace level	203
show session maxlimit	204
show smtp	204

show stats io	204
show status	205
show tech activesql	206
show tech all	206
show tech ccm_service	206
show tech database	207
show tech dberrcode	207
show tech dbhighcputasks	208
show tech dbintegrity	208
show tech dbschema	208
show tech dbinuse	209
show tech dbstateinfo	209
show tech devdefaults	210
show tech dumpCSVandXML	210
show tech gateway	211
show tech locales	211
show tech network all	211
show tech network hosts	212
show tech network interfaces	212
show tech network resolv	213
show tech network routes	214
show tech network sockets	214
show tech notify	215
show tech params	215
show tech prefs	215
show tech procedures	216
show tech repltimeout	216
show tech routepatterns	217
show tech routeplan	217
show tech runtime	217
show tech sqlhistory	218
show tech systables	218
show tech system	219
show tech table	220

show tech triggers	220
show tech version	220
show timezone config	221
show timezone list	221
show tls trace	222
show tls min-version	222
show tlsresumptiontimeout	223
show trace	223
show ups status	223
show version active	224
show version inactive	224
show vos version	225
show web-security	225
show webapp session timeout	226
show workingdir	226
show logins unsuccessful	226

---

**CHAPTER 8****Unset Commands 229**

unset ipsec policy_group	229
unset ipsec policy_name	229
unset network cluster subscriber details	230
unset network cluster subscriber dynamic-cluster-configuration	230
unset network dns options	231
unset network domain	231
unset network ntp options	232
unset network ipv6 gateway	232
unset network ipv6 static_address	233

---

**CHAPTER 9****Utils Commands 235**

utils auditd	240
utils BE6000Mode enable	240
utils BE6000Mode disable	241
utils BE6000Mode status	241
utils branding enable	241

utils branding disable	242
utils branding status	242
utils contactsearchauthentication disable	242
utils contactsearchauthentication enable	242
utils contactsearchauthentication status	243
utils core analyze	243
utils core list	244
utils capf cert import	244
utils capf set keep_alive	244
utils capf stale-lsc	245
utils create report	245
utils create report database	246
utils ctl	246
utils ctl reset localkey	247
utils cuc activate CUSRSV	248
utils cuc auto ITL download	248
utils cuc cluster activate	249
utils cuc cluster deactivate	250
utils cuc cluster makeprimary	250
utils cuc cluster overwrittenb	250
utils cuc cluster renegotiate	251
utils cuc create report	251
utils cuc dbreplication 01_tear_down	252
utils cuc dbreplication 02_define_servers	253
utils cuc dbreplication 03_define_db_template	253
utils cuc dbreplication 04_sync_database	254
utils cuc dbreplication reset_all	255
utils cuc encryption	255
utils cuc jetty ssl disable	256
utils cuc jetty ssl enable	257
utils cuc networking clear_replication	258
utils cuc networking dscp	258
utils cuc reset password	259
utils cuc set PinExpiry_PromptTime “Authentication Rule Name”	259

utils dbreplication dropadmindb	260
utils dbreplication forcedatasyncsub	260
utils dbreplication quickaudit	261
utils dbreplication rebuild	262
utils dbreplication repair	262
utils dbreplication repairreplicate	263
utils dbreplication repairtable	264
utils dbreplication reset	264
utils dbreplication runtimestate	265
utils dbreplication setprocess	265
utils dbreplication setrepltimeout	266
utils dbreplication status	267
utils dbreplication stop	268
utils imdb_replication replication status	268
utils diagnose	269
utils disaster_recovery backup network	269
utils disaster_recovery cancel_backup	270
utils disaster_recovery device add network	270
utils disaster_recovery device delete	271
utils disaster_recovery device list	271
utils disaster_recovery estimate_tar_size	272
utils disaster_recovery history	272
utils disaster_recovery jschLogs operation	273
utils disaster_recovery prepare restore pub_from_sub	273
utils disaster_recovery restore network	274
utils disaster_recovery schedule add	274
utils disaster_recovery schedule	275
utils disaster_recovery schedule delete	275
utils disaster_recovery schedule disable	276
utils disaster_recovery schedule list	276
utils disaster_recovery show_backupfiles	277
utils disaster_recovery show_registration	277
utils disaster_recovery status	278
utils EnhancedSecurityMode disable	278



utils EnhancedSecurityMode enable	278
utils EnhancedSecurityMode status	279
utils filebeat config	279
utils filebeat disable	280
utils filebeat enable	280
utils filebeat status	280
utils filebeat tls	281
utils fior	281
utils fior disable	282
utils fior enable	282
utils fior list	282
utils fior start	283
utils fior status	283
utils fior stop	284
utils fior top	284
utils fips	284
utils fips_common_criteria	286
utils firewall ipv4 debug	286
utils firewall ipv4	287
utils firewall ipv4 list	288
utils firewall ipv4 status	288
utils firewall ipv6 debug	288
utils firewall ipv6	289
utils firewall ipv6 list	290
utils firewall ipv6 status	290
utils ha failover	291
utils ha fallback	291
utils haproxy set {required optional disable} client-auth	292
utils haproxy set num-threads	294
utils ha recover	295
utils ha status	296
utils ils showpeerinfo	297
utils import config	297
Execute utils import config in VMware Deployment	298

utils iostat	298
utils iothrottle	299
utils itl reset	299
utils ipsec restart	300
utils ldap config	301
utils ldap config status	301
utils managementAgent alarms minpushLevel	302
utils managementAgent alarms pushfrequency	302
utils managementAgent alarms pushnow	303
utils network arp delete	303
utils network arp set	303
utils network arp list	304
utils network capture	305
utils network capture-rotate	306
utils network connectivity	307
utils network host	308
utils network ipv6 host	308
utils network ipv6 traceroute	309
utils network ipv6 ping	309
utils network ping	310
utils network traceroute	310
utils network name-service {hosts services} cache invalidate	311
utils ntp auth symmetric-key	311
utils ntp auth auto-key	313
utils ntp server add	316
utils ntp server delete	317
utils ntp config	319
utils ntp restart	319
utils ntp server list	320
utils ntp start	320
utils ntp status	320
utils os kerneldump	321
utils os kerneldump ssh	321
utils os kerneldump status	322

utils os secure	322
utils os secure dynamic-policies compile	323
utils os secure dynamic-policies list	323
utils os secure dynamic-policies load	324
utils os secure dynamic-policies remove	324
utils os secure dynamic-policies show	325
utils os secure dynamic-policies start-recording	325
utils os secure dynamic-policies stop-recording	326
utils PlatformWebAccess disable	326
utils PlatformWebAccess enable	327
utils PlatformWebAccess status	327
utils processCoreDumps disable	328
utils processCoreDumps enable	328
utils processCoreDumps status	328
utils remote_account create	329
utils remote_account disable	329
utils remote_account enable	329
utils remote_account status	330
utils remotesyslog set protocol tcp	330
utils remotesyslog set protocol udp	330
utils remotesyslog set protocol tls	331
utils remotesyslog show protocol	331
utils reset_application_ui_administrator_name	332
utils reset_application_ui_administrator_password	332
utils restore_application_ui_administrator_account	333
utils rosters list limited	333
utils rosters list full	333
utils rosters list watchers	334
utils rosters list contacts	334
utils rosters delete	334
utils scheduled-task disable	335
utils scheduled-task enable	335
utils scheduled-task list	335
utils set urlpattern disable	336

utils set urlpattern enable	336
utils service	337
utils service list	337
utils service auto-restart	338
utils service start	339
utils service stop	339
utils snmp config 1/2c community-string	339
utils snmp config 1/2c inform	340
utils snmp config 1/2c trap	341
utils snmp config 3 inform	341
utils snmp config mib2	342
utils snmp config 3 trap	342
utils snmp config 3 user	343
utils snmp get	344
utils snmp get 1	344
utils snmp get 2c	345
utils snmp get 3	346
utils snmp hardware-agents	346
utils snmp test	347
utils snmp walk	348
utils snmp walk 1	349
utils snmp walk 2c	350
utils snmp walk 3	350
utils soap realservice test	351
utils sso	351
utils sso recovery-url	352
utils system restart	352
utils system shutdown	353
utils system switch-version	353
utils system boot	354
utils system upgrade	354
utils system upgrade cluster	357
utils system enableAdministration	360
utils update dst	361

utils users validate	362
utils vmtools refresh	362
utils vmtools status	363
utils vmtools switch open	363
utils vmtools switch native	364
utils system boot status	364
utils system upgrade dataexport initiate	364
utils system upgrade dataexport status	365
utils system upgrade dataexport cancel	365
utils ucmgmt agent disable	366
utils ucmgmt agent enable	366
utils ucmgmt agent remove	367
utils ucmgmt agent restart	367
utils ucmgmt agent status	367
utils ucmgmt agent verification	368
utils ucmgmt config export	368
utils ucmgmt config import	369
utils ucmgmt organization	369
utils ucmgmt proxy add	370
utils ucmgmt proxy clear	371
utils ucmgmt proxy force add	371
utils ucmgmt proxy list	372





## Preface

---

- [Purpose](#), on page xxiii
- [Audience](#), on page xxiii
- [Organization](#), on page xxiii
- [Related Documents](#), on page xxiv

## Purpose

The *Command Line Interface Reference Guide for Cisco Unified Communications Solutions* provides information about all the commands supported on the IM and Presence Service, Cisco Unified Communications Manager, and Cisco Unity Connection. Every command includes an "Applies to" section identifying applicable products.

## Audience

The *Command Line Interface Reference Guide for Cisco Unified Communications Solutions* provides information to execute specific commands for network administrators responsible for managing and supporting IM and Presence, Cisco Unified Communications Manager, and Cisco Unity Connection.

## Organization

The following table shows the organization for this guide:

**Table 1: Organization of Command Line Interface Reference Guide for Cisco Unified Communications Solutions**

Chapter	Description
About CLI	Provides information about the CLI and tips to help make the management of the products easier to navigate.
Delete commands	Lists all commands relating to the removal of specific information.
File commands	Lists all commands relating to the management of files and logs.

License commands	Lists all commands relating to licensing.
Run commands	Lists all commands relating to the execution of sql queries, various tests, and tasks.
Set commands	Lists all commands relating to the tasks such as enabling, disabling, importing, and exporting.
Show commands	Lists all commands relating to the display of specified information.
Unset commands	Lists all commands relating to the disabling of specified network and ipsec options.
Utils commands	Lists all commands relating to utilities.

## Related Documents

See the *Cisco Unified Communications Manager Documentation Guide* to learn about the documentation for Unified Communications Manager and IM and Presence Service.

For the latest IM and Presence Service and Unified Communications Manager requirements, see the *Release Notes for Cisco Unified Communications Manager*.





# CHAPTER 1

## About CLI

---

- [CLI Privilege Levels, on page 1](#)
- [Start CLI session, on page 1](#)
- [Tab completes command, on page 3](#)
- [Command help, on page 3](#)
- [Ctrl-C exits command, on page 4](#)
- [Quit CLI session, on page 4](#)

## CLI Privilege Levels

During installation of Unified Communications Manager, an administrator with level 4 privilege is created at the platform level. This administrator has all privileges to execute all the command line interface (CLI) commands. Through the CLI commands, the administrator with level 4 privilege creates the following administrators:

- Administrator with level 0 privilege—This administrator has read-only access privilege on the interface.
- Administrator with level 1 privilege—This administrator has both read and write access privilege on the interface.



---

**Note** Administrators can execute CLI commands based on the privileges defined for each of them.

---

After the administrators with the various privileges are created, you can start the CLI session.

## Start CLI session



---

**Note** This procedure applies to both Unified Communications Manager and the IM and Presence Service. The Operating System for Unified Communications Manager is called the Cisco Unified Operating System. The Operating System for the IM and Presence Service is called the Unified IM and Presence Operating System. To start a CLI session for the IM and Presence Service, you must use the Unified IM and Presence Operating System.

---

You can access the Cisco Unified Operating System (or, for the IM and Presence Service, the Unified IM and Presence Operating System) remotely or locally:

- From a web client workstation, such as the workstation that you use for Cisco Unified Operating System Administration, you can use SSH to connect securely to the Cisco Unified Operating System.
- You can access the Cisco Unified Operating System CLI directly by using the monitor and keyboard that you used during installation or by using a terminal server that is connected to the serial port. Use this method if a problem exists with the IP address.

### Before you begin

Ensure you have the following information that is defined during installation:

- A primary IP address and hostname
- An administrator ID
- A password

You will need this information to log in to the Cisco Unified Operating System.

### Procedure

---

#### Step 1

Perform one of the following actions depending on your method of access:

- a) From a remote system, use SSH to connect securely to the Cisco Unified Operating System. In your SSH client, enter

```
ssh adminname@hostname
```

where *adminname* specifies the Administrator ID and *hostname* specifies the hostname that was defined during installation.

For example, `ssh admin@ipt-1`.

- b) From a direct connection, you receive this prompt automatically:

```
ipt-1 login:
```

where *ipt-1* represents the host name of the system.

Enter the administrator ID that was defined during installation.

#### Step 2

Enter the password that was defined at installation.

The CLI prompt displays. The prompt represents the Administrator ID; for example:

```
admin:
```

You can now use any CLI command.

---

## Tab completes command

To complete commands, use Tab:

- Enter the start of a command and press **Tab** to complete the command. For example, if you enter `se` and press **Tab**, `set` is completed.
- Enter a full command name and press **Tab** to display all the commands or subcommands that are available. For example, if you enter `set` and press **Tab**, you see all the `set` subcommands. An `*` identifies the commands that have subcommands.
- If you reach a command, keep pressing **Tab**, and the current command line repeats; this indicates that no additional expansion is available.

## Command help

You can get two kinds of help about any command:

- Detailed help that includes a definition of the command and an example of its use
- Short query help that includes only command syntax

If you want to:	At the CLI prompt:
Get detailed help	Enter <b>help</b> <i>command</i> Where <i>command</i> specifies the command name or the command and parameter. See “Detailed Help Example.”
Query only command syntax	Enter <i>command</i> ? Where <i>command</i> represents the command name or the command and parameter. See “Query Example.”

### Troubleshooting Tips

If you enter a `?` after a menu command, such as `set`, it acts like the **Tab** key and lists the commands that are available.

### Detailed Help Example:

```
admin:help file list activelog
activelog help:
This will list active logging files

options are:
page      - pause output
detail    - show detailed listing
```

```
reverse - reverse sort order
date    - sort by date
size    - sort by size

file-spec can contain '*' as wildcards

Example:
admin:file list activelog platform detail
02 Dec,2004 12:00:59 <dir> drf
02 Dec,2004 12:00:59 <dir> log
16 Nov,2004 21:45:43      8,557 enGui.log
27 Oct,2004 11:54:33     47,916 startup.log
dir count = 2, file count = 2
```

**Query Example:**

```
admin:file list activelog?Syntax:
file list activelog file-spec [options]
file-spec mandatory file to view
options optional page|detail|reverse|[date|size]
```

## Ctrl-C exits command

You can stop most interactive commands by entering the **Ctrl-C** key sequence, as shown in the following example:

**Exiting a Command with Ctrl-C**

```
admin:utils system upgrade initiateWarning: Do not close this window without first
  exiting the upgrade command.
Source:
1) Remote Filesystem
2) DVD/CD
q) quit
Please select an option (1 - 2 or "q" ):
Exiting upgrade command. Please wait...
Control-C pressed
admin:
```




---

**Note** If you execute the command **utils system switch-version** and enter **Yes** to start the process, entering **Ctrl-C** exits the command but does not stop the switch-version process.

---

## Quit CLI session

At the CLI prompt, enter **quit**. If you are logged in remotely, you get logged off, and the ssh session is dropped. If you are logged in locally, you get logged off, and the login prompt returns.



## CHAPTER 2

# Delete Commands

- [delete account](#), on page 5
- [delete cuc futuredelivery](#), on page 5
- [delete cuc locale](#), on page 6
- [delete dns](#), on page 7
- [delete dscp](#), on page 7
- [delete ipsec policy\\_group](#), on page 8
- [delete ipsec policy\\_name](#), on page 8
- [delete process](#), on page 9
- [delete smtp](#), on page 9

## delete account

This command allows you to delete an administrator account.

**delete account** *account-name*

Syntax Description	Parameters	Description
	<i>account-name</i>	Specifies the name of an administrator account.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## delete cuc futuredelivery

This command deletes all messages that have been marked for future delivery.

**delete cuc futuredelivery****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

The following example deletes two messages that have been marked for future delivery.

```
admin: delete cuc futuredelivery
```

```
Deleting File : UmssMtaFutureDelivery/UnityMbxDb1/5C56C086-E64B-11DC-9BAF-41FC55D89593.eml
```

```
Deleting File : UmssMtaFutureDelivery/UnityMbxDb1/6D7DD796-E64B-11DC-A0E6-D1FD55D89593.eml
```

```
Files : Found = 2, Deleted = 2
```

Note: Files that are in use cannot be deleted

## delete cuc locale

This command deletes the specified locale and all of the associated files and settings from Connection.

**delete cuc locale** *locale-id*

**Syntax Description****Parameters Description**

*locale-id* Specifies the ID of the locale that you want to delete.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

Before you run this command, you must stop the Connection Conversation Manager and Connection Mixer services. After you run this command, you must restart the Connection Conversation Manager and Connection Mixer services. While running "delete cuc" locale command, you can choose to retain or not retain the locale mappings at your Unity Connection System.

If you choose to retain locale mapping, then after re-install of same locale, all objects like Subscribers and Call handlers are automatically mapped to retained locale. If you choose not to retain the locale mapping, then after uninstall all locale mappings are lost.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example

The following example deletes the en-GB locale and all of the associated files and settings.

```
admin:delete cuc locale en-GB
```

```
en-GB uninstalled
```

## delete dns

This command allows you to delete the IP address for a DNS server.

**delete dns** *addr*

### Syntax Description

Parameters	Description
<i>addr</i>	Represents the IP address of the DNS server that you want to delete.

### Command Modes

Administrator (admin:)

### Usage Guidelines

After you execute this command, the system asks whether you want to continue.



**Caution** If you continue, this command causes a temporary loss of network connectivity.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## delete dscp

This command deletes a DSCP port tag.

**delete dscp** *port-tag*

**Syntax Description****Parameters Description**

Parameters	Description
<i>port-tag</i>	Represents a DSCP port tag, which is a string that is mapped to a TCP or UDP port to identify the application that uses the port. This value is for the portTag field displayed when you use the command <b>show dscp defaults</b> . The set of port tags is predefined.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

After you delete an enabled port tag, DSCP marking on that port tag stops. You can recreate a deleted port tag when you use the set dscp marking command; enter the name of the port tag that you previously deleted.



**Tip** Use the command **show dscp defaults** to list the configured port tags.

**Requirements**

Command privilege level: 1

Applies to: Unified Communications Manager, Cisco Unity Connection

## delete ipsec policy\_group

This command deletes all policies within the specified group or all groups.

```
delete ipsec policy_group {group | all}
```

**Syntax Description****Parameters Description**

Parameters	Description
<i>group</i>	Represents a specific group name.
<b>all</b>	Deletes all groups.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, Cisco Unity Connection

## delete ipsec policy\_name

This command deletes an IPSec policy with given policy name.

```
delete ipsec policy_name {policy_group policy_name }
```



Syntax Description	Parameters	Description
	<i>policy_group</i>	Represents the policy group.
	<i>policy_name</i>	Represents the policy name.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, Cisco Unity Connection

## delete process

This command allows you to delete a particular process.

**delete process** *process-id* [{**force** | **terminate** | **crash**}]

Syntax Description	Parameters	Description
	<i>process-id</i>	Represents the process ID number.
	<b>force</b>	Causes the process to stop.
	<b>terminate</b>	Causes the operating system to terminate the process.
	<b>crash</b>	Crashes the process and produces a crash dump.

**Command Modes** Administrator (admin:)

**Usage Guidelines** Use the **force** option only if the command alone does not delete the process; use the **terminate** option only if **force** does not delete the process.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## delete smtp

This command allows you to delete the SMTP host.

**delete smtp****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection



## CHAPTER 3

# File Commands

- [file build log](#), on page 11
- [file check](#), on page 15
- [file delete](#), on page 16
- [file delete tftp](#), on page 16
- [file dump](#), on page 18
- [file dump sftpdetails](#), on page 18
- [file dump tftp](#), on page 19
- [file fragmentation sdi](#), on page 19
- [file fragmentation sdl](#), on page 21
- [file get](#), on page 22
- [file get tftp](#), on page 24
- [file list](#), on page 25
- [file list tftp](#), on page 27
- [file search](#), on page 28
- [file search tftp](#), on page 28
- [file tail activelog](#), on page 29
- [file tail tftp](#), on page 30
- [file view](#) , on page 30
- [file view tftp](#), on page 33

## file build log

This command collects log information by service or feature and duration.

**file build log** *service/feature duration*

### Syntax Description

Parameters	Description
<i>service/feature</i>	specifies the component or functional area from which to retrieve log information
<i>duration</i>	specifies the time period, measured in days, from which the log information is retrieved.

### Command Modes

Administrator (admin:)

**Usage Guidelines****Requirements**

Command privilege level:

Allowed during upgrade:

Applies to: IM and Presence Service on Unified Communications Manager

**Examples**

This command collects logs for the Client Profile Agent.

```
admin: file build log cpa 10
Collecting logs
```

```
Collecting: logname1.txt
Collecting: logname2.txt
```

To retrieve run the following command:  
file get epas/trace/acdc\_2012-06-28-111258.tar.gz

This command collects all logs defined in the xml config.

```
admin:file build log all
Collecting logs
```

```
Collecting: logname1.txt
Collecting: logname2.txt
```

To retrieve run the following command:  
file get epas/trace/acdc\_2012-06-28-111258.tar.gz

This command collects logs for multiple services.

```
admin:file build log dbmon cpa
Collecting logs
```

```
Collecting: logname1.txt
Collecting: logname2.txt
```

To retrieve run the following command:  
file get epas/trace/acdc\_2012-06-28-111258.tar.gz

This command shows help.

```
admin:file build log ?
Syntax:
file build log [serviceName [serviceName] ..]
```

```
Service Names:
FullName                               ShortName
-----
cisco_client_profile_agent             cpa
cisco_database_layer_monitor           dbmon
cisco_audit_logs                       audit
cisco_ris_dat_collector                 risdc
```

This command shows information for the deployment.

```
admin: file build log deployment info 0
```

```
DB Queries may take up to 5 minutes to complete. Please be patient...
About to start queries for deployment data... please wait...
-----
Gathering CUCM Version...
```

```
ccmversion
11.0.1.100000(9)
-----
Gathering CUCM Publisher Node
ccmpublisherhostname
gwydlg050498vm1
-----
Gathering Rosters table...
rosters
3032681
-----
Gathering Groups table...
groups
1518966
-----
Gathering Non-Presence contacts...
nonpresencecontacts
502573
-----
Gathering Number of inter-cluster users...
enduser
0
-----
Gathering CUCM Nodes in cluster...
processnode
2
-----
Gathering CUCM Node names in cluster...
name
EnterpriseWideData
processnode
gwydlg050408vm1
-----
Gathering IM&P nodes in cluster...
processnode
2
-----
Gathering XCP Routing Node...
paramvalue
t
-----
Gathering Exchange Calendaring...
pebackendgateway
-----
Gathering SIP Inter-domain Federation...
domainname

paramvaluegwydlg050408vm2-public.cisco.com
-----
Gathering XMPP Inter-domain Federation...
xmpps2ssnodes
0
-----
Gathering Intra-domain Partitioned Federation...
enablepartitionedfedwithacs
f
-----
Gathering Inter-cluster Peering...
cupsinterclusterpeers

-----
Gathering Message Archiver...
pkid
8fede7a9-b6a6-4ad4-8da6-b8ea4c8d5411
```

```

databasetype
Postgres
databasename
tcmadb
name
gwydlg050408vm2
tknodeusage
0
tkprocessnoderole
2
nodeid
3
-----
Gathering Third-party compliance...
ftextdbprocessnodemap
0
-----
Gathering Persistent Chat...
enablepersistentgear
t
databasetype
Postgres
datanasename
tcmadb
name
gwydlg050408vm2
tknodeusage
0
tkprocessnoderole
2
nodeid
2
-----
Gathering Advanced File Transfer...
tkfiletransfer
2
databasetype
Postgres
datbasename
tcmadb
name
gwydlg050408vm2
tknodeusage
0
tkprocessnoderole
2
nodeid
3
-----
Gathering AD Groups...
paramvalue
t
-----
Gathering XEP-198...
paramvalue
t
-----
Gathering DB Replication Status...
replicationdynamic
2
Services on this node that currently have debug logging enabled are:

Cisco Presence Engine
Cisco DRF Local
```

```
Cisco XCP File Transfer Manager
```

```
Collecting Logs for deployment_info
```

```
Collected: platformConfig.xml
```

```
Collected: deployment_info.xml
```

```
Collected: system_info.txt
```

To retrieve the logs, run the following CLI Command:

```
file get activelog epas/trace/log_2015-08-17-154010.tar.gz
```

To maintain a stable system it is recommended that you remove the file after retrieval.

To do this run the CLI Command:

```
file delete activelog epas/trace/log_2015-08-17-154010.tar.gz
```

Please Note: Debug logging is not enabled for any of the files you have retrieved

## file check

This command checks the /usr directory tree to see whether files or directories have been added, removed, or changed in size since the last fresh installation or upgrade and shows the results.

**file check** [*detection-size-kb*]

### Syntax Description

Parameters	Description
<i>detection-size-kb</i>	Specifies the minimum file size change that is required for the command to display the file as changed.  Default value: 100 KB.

### Command Modes

Administrator (admin:)

### Usage Guidelines

The command notifies you about a possible impact to system performance and asks you whether you want to continue. The display includes both deleted and new files.



**Caution** Because this command can affect system performance, we recommend that you run the command during off-peak hours.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file delete

This command deletes a log on the active or inactive side.

**file delete** { **activelog** | **inactivelog** | **install** } *file-spec* [**detail**] [**noconfirm**]

Syntax Description	Parameters	Description
	<b>activelog</b>	Specifies a log on the active side.
	<b>inactivelog</b>	Specifies a log on the inactive side.
	<b>install</b>	Specifies an installation log.
	<i>file-spec</i>	Specifies the path and filename of the log or logs to delete (includes install log files).
	<b>detail</b>	Shows a listing of deleted files with the date and time.
	<b>noconfirm</b>	Deletes files without asking you to confirm each deletion.

**Command Modes** Administrator (admin:)

**Usage Guidelines** You get prompted for confirmation after you enter the command. You cannot delete directories or files that are in use.



**Caution** You cannot recover a deleted file, but you may be able to with The Disaster Recovery System.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file delete tftp

This command deletes a TFTP file.

**file delete tftp** *file-spec* [**detail**] [**noconfirm**]



Syntax Description	Parameters	Description
	<i>file-spec</i>	Represents the TFTP file name.
	<b>detail</b>	Shows a listing of deleted files with the date and time.
	<b>noconfirm</b>	Deletes files without asking you to confirm each deletion.

**Command Modes** Administrator (admin:)

**Usage Guidelines** You get prompted for confirmation after you enter the command. You cannot delete directories or files that are in use.



**Caution** You cannot recover a deleted file, but you may be able to with the Disaster Recovery System.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file delete dir tftp

This command deletes the TFTP directory.

**file delete dir tftp** *dir-name* [**detail**]

Syntax Description	Parameters	Description
	<i>dir-name</i>	Specifies the TFTP directory to delete.
	<b>detail</b>	Shows a listing of deleted files with the date and time.

**Command Modes** Administrator (admin:)

**Usage Guidelines** You get prompted for confirmation after you enter the command. You cannot delete directories or files that are in use.



**Caution** You cannot recover a deleted file, but you may be able to with the Disaster Recovery System.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file dump

This command dumps the contents of a log, a page at a time.

**file dump** {**activelog** | **inactivelog** | **install**} *file-spec* [**hex**] [**recent**] [**regexp** *expression*]

Syntax Description	Parameters	Description
	<b>activelog</b>	Specifies a log on the active side.
	<b>inactivelog</b>	Specifies a log on the inactive side.
	<b>install</b>	Specifies an installation log.
	<i>file-spec</i>	Represents the log file to dump.
	<b>hex</b>	Shows output in hexadecimal.
	<b>recent</b>	Dumps the most recently changed file in the directory.
	<b>regexp</b> <i>expression</i>	Displays only the lines in the file that match the regular expression <i>expression</i> .

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

#### Example

This command dumps contents of file `_cdrIndex.idx`.

```
admin: file dump activelog cm/cdr/_cdrIndex.idx
```

## file dump sftpdetails

This command specifies the list of files that can be dumped in the SFTP context and allows you to choose which file to dump.

**file dump sftpdetails**


---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** Enter **a** to dump all SFTP-related files. Enter **q** to exit this command.
**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file dump tftp

This command dumps the contents of a TFTP file to the screen, a page at a time.

**file dump tftp** *file-spec* [**page**] [**detail**] [**hex**]**Syntax Description**

Parameters	Description
<i>file-spec</i>	Represents the name of a TFTP file.
<b>page</b>	Displays the output one screen at a time.
<b>detail</b>	Displays the listing with the date and time.
<b>hex</b>	Displays the output in hexadecimal.

---

**Command Modes** Administrator (admin:)
**Usage Guidelines**


---

**Note** *file-spec* must resolve to a single file.
 

---

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file fragmentation sdi

This command shows file fragmentation information about SDI log files.

**file fragmentation sdi** **most** {**fragmented** | **recent**} [*number*]

Syntax Description	Parameters	Description
	<b>most fragmented</b>	Represents the most fragmented log files.
	<b>most recent</b>	Represents the most recent logs files.
	<i>number</i>	Represents the number of files to list.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file fragmentation sdi file

This command shows file fragmentation information about an SDI log file.

**file fragmentation sdi file** *filename* [**verbose**]**Syntax Description**

Parameters	Description
<i>filename</i>	Represents the SDI log file name.
<b>verbose</b>	Shows more detailed information on the screen.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level:1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file fragmentation sdi all

This command shows file fragmentation information about all SDI log files in the directory.

**file fragmentation sdi all** *filename***Syntax Description**

Parameters	Description
<i>filename</i>	Specifies the SDI log file name for which you want to show all fragmentation details.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## file fragmentation sdl

This command shows file fragmentation information about the most fragmented SDL log files.

**file fragmentation sdl most** {**fragmented** | **recent**} [*number*]

Syntax Description	Parameters	Description
	<b>most fragmented</b>	Represents the most fragmented log files.
	<b>most recent</b>	Represents the most recent log files.
	<i>number</i>	Represents the number of files to list.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection.

## file fragmentation sdl file

This command displays file fragmentation information about an SDL log file.

**file fragmentation sdl file** *filename* [**verbose**]

Syntax Description	Parameters	Description
	<i>filename</i>	Represents the file name of the SDL log file.
	<b>verbose</b>	Shows more detailed information on the screen.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection.

## file fragmentation sdl all

This command shows file fragmentation information about all SDL log files in the directory.

**file fragmentation sdl all** *filename*

**Syntax Description****Parameters Description**

*filename* Represents the file name for which you want to show all fragmentation details.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection.

## file get

This command sends a log to another system by using SFTP.

**file get** {**activelog**|**inactivelog**|**install**} *file-spec* [{*reltime**abstime*}] [**match** *regex*] [**recurs**] [**compress**]

**Syntax Description****Parameters****Description**

**activelog**

Specifies a log on the active side.

**inactivelog**

Specifies a log on the inactive side.

**install**

Specifies an installation log.

*file-spec*

Specifies the name of the file to transfer.

*reltime*

The relative time period, specified in **minutes** | **hours** | **days** | **weeks** | **months** | **time value**

Parameters	Description
<i>abstime</i>	The absolute time period, specified as <b>hh:mm:MM/DD/YY</b> <b>hh:mm:MM/DD/YY</b>
<b>match</b> <i>regex</i>	Match a particular string in the filename, specified as <i>regex</i> .
<b>recurs</b>	Get all files, including subdirectories.
<b>compress</b>	Transfer files as compressed file.
<b>tftp</b>	

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

After the command identifies the specified files, you get prompted to enter an SFTP host, username, and password.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

**Example**

This example gets all files in the activelog operating system directory that match the string "plat."

```
admin: file get activelog platform match plat
```

This example gets all operating system log files for a particular time period.

```
admin: file get activelog platform/log abstime 18:00:10/20/13 18:00:10/21/13
```

**file get salog**

This command sends the partBsalog or salog directory to another system by using SFTP.

```
file get {partBsalog | salog} file-spec [{reltimeabstime}] [match regex] [recurs] [compress]
```

**Syntax Description**

Parameters	Description
<b>partBsalog</b>	Specifies the partBsalog directory.
<b>salog</b>	Specifies the salog directory.

Parameters	Description
<i>file-spec</i>	Specifies the name of the file to transfer.
<i>reltime</i>	The relative time period, specified in <b>minutes</b>   <b>hours</b>   <b>days</b>   <b>weeks</b>   <b>months</b>   <b>time value</b>
<i>abstime</i>	The absolute time period, specified as <b>hh:mm:MM/DD/YY</b> <b>hh:mm:MM/DD/YY</b>
<b>match</b> <i>regex</i>	Match a particular string in the filename, specified as <i>regex</i> .
<b>recurs</b>	Get all files, including subdirectories.
<b>compress</b>	Transfer files as compressed file.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

After the command identifies the specified files, you get prompted to enter an SFTP host, username, and password.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file get tftp

This command sends a TFTP file to another system by using SFTP.

```
file get tftp file-spec [{reltimeabstime}] [match regex] [recurs] [compress]
```

**Syntax Description**

Parameters	Description
<i>file-spec</i>	Specifies the name of the TFTP file to transfer.
<i>reltime</i>	The relative time period, specified in <b>minutes</b>   <b>hours</b>   <b>days</b>   <b>weeks</b>   <b>months</b>   <b>time value</b>



Parameters	Description
<i>abstime</i>	The absolute time period, specified as <b>hh:mm:MM/DD/YY</b> <b>hh:mm:MM/DD/YY</b>
<b>match</b> <i>regex</i>	Match a particular string in the filename, specified as <i>regex</i> .
<b>recurs</b>	Get all files, including subdirectories.
<b>compress</b>	Transfer files as compressed file.

**Command Modes** Administrator (admin:)

**Usage Guidelines** After the command identifies the specified files, you get prompted to enter an SFTP host, username, and password.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file list

This command lists the log files in an available log directory.

**file list** {**activelog** | **inactivelog** | **install**} *file-spec* [{**page** | **detail** | **reverse**}] [{**date** | **size**}

Syntax Description	Parameters	Description
	<b>activelog</b>	Specifies a log on the active side.
	<b>inactivelog</b>	Specifies a log on the inactive side.
	<b>install</b>	Specifies an installation log.
	<i>file-spec</i>	Specifies the name of the log file .
	<b>page</b>	Shows the output one screen at a time.
	<b>detail</b>	Shows a detailed listing with date and time.
	<b>reverse</b>	Reverses the sort direction.
	<b>date</b>	Sorts files by date.

Parameters	Description
<b>size</b>	Sorts files by size.

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

**Example: Log Files with Details**

This example lists operating system log files with details.

```
admin: file list activelog platform/log page detail
```

**Example: Directories in the CDR Repository**

This example lists directories in CDR repository.

```
admin: file list activelog cm/cdr_repository
```

**Example: CDR Files by Size**

This example lists CDR files in a specified directory by size.

```
admin: file list activelog cm/cdr_repository/processed/20050812 size
```

## file list salog

This command lists the partBsalog or salog directory.

```
file list {partBsalog | salog} file-spec [{page | detail | reverse}] [{date | size}]
```

**Syntax Description**

Parameters	Description
<b>partBsalog</b>	Specifies the partBsalog log directory.
<b>salog</b>	Specifies the salog log directory.
<i>file-spec</i>	Specifies the path to the file or files to list.
<b>page</b>	Shows the output one screen at a time.
<b>detail</b>	Shows a detailed listing with date and time.
<b>reverse</b>	Reverses the sort direction.

Parameters	Description
<b>date</b>	Sorts files by date.
<b>size</b>	Sorts files by size.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file list tftp

This command lists TFTP files.

**file list tftp** *file-spec* [{**page** | **detail** | **reverse**}] [{**date** | **size**}]

**Syntax Description**

Parameters	Description
<i>file-spec</i>	Specifies the name of the TFTP file.
<b>page</b>	Shows the output one screen at a time.
<b>detail</b>	Shows a detailed listing with date and time.
<b>reverse</b>	Reverses the sort direction.
<b>date</b>	Sorts files by date.
<b>size</b>	Sorts files by size.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file search

This command searches the content of a log and shows the matching lines a page at a time.

**file search** {**activelog** | **inactivelog** | **install**} *file-spec* [{*reltime**abstime*}] [**ignorecase**]

Syntax Description	Parameters	Description
	<b>activelog</b>	Specifies a log on the active side.
	<b>inactivelog</b>	Specifies a log on the inactive side.
	<b>install</b>	Specifies an installation log.
	<i>file-spec</i>	Specifies the name of the file to search.
	<i>reltime</i>	The relative time period, specified in <b>minutes</b>   <b>hours</b>   <b>days</b>   <b>weeks</b>   <b>months</b>   <b>time value</b>
	<i>abstime</i>	The absolute time period, specified as <b>hh:mm:MM/DD/YY</b> <b>hh:mm:MM/DD/YY</b>
	<b>ignorecase</b>	Ignores case in a search.

### Command Modes

Administrator (admin:)

### Usage Guidelines

Write the search term in the form of a regular expression, which is a special text string to describe a search pattern.

If the search term is found in only one file, the filename appears at the top of the output. If the search term is found in multiple files, each line of the output begins with the filename in which the matching line was found.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## file search tftp

This command searches the content of a TFTP file and shows the matching lines a page at a time.

**file search tftp** *file-spec* [{*reltime**abstime*}] [**ignorecase**]

Syntax Description	Parameters	Description
	<i>file-spec</i>	Specifies the name of the TFTP file to search.
	<i>reltime</i>	The relative time period, specified in <b>minutes</b>   <b>hours</b>   <b>days</b>   <b>weeks</b>   <b>months</b>   <b>time value</b>
	<i>abstime</i>	The absolute time period, specified as <b>hh:mm:MM/DD/YY</b> <b>hh:mm:MM/DD/YY</b>
	<b>ignorecase</b>	Ignores case in a search.

**Command Modes** Administrator (admin:)

**Usage Guidelines** Write the search term in the form of a regular expression, which is a special text string to describe a search pattern.

If the search term is found in only one file, the filename appears at the top of the output. If the search term is found in multiple files, each line of the output begins with the filename in which the matching line was found.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## file tail activelog

This command tails (prints the last few lines) of a log file.

**file tail** {**activelog** | **inactivelog** | **install**} *filespec* [**hex**] [*lines*] [**regexp** *expression*]

Syntax Description	Parameters	Description
	<b>activelog</b>	Specifies a log on the active side.
	<b>inactivelog</b>	Specifies a log on the inactive side.
	<b>install</b>	Specifies an installation log.
	<i>filespec</i>	Specifies the path to the file. You can use the wildcard character, *, for filename as long as it resolves to one file.
	<b>hex</b>	Show the listing in hexadecimal.
	<i>lines</i>	Specifies the number of lines to display.
	<b>regexp</b> <i>expression</i>	Tails log files that match <i>expression</i>

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

This example tails the operating system CLI log file.

```
admin: file tail activelog platform/log/cli00001.log
```

## file tail tftp

This command tails (prints the last few lines) of a TFTP file.

**file tail tftp** *filespec* [**detail**] [**hex**] [*lines*]

### Syntax Description

Parameters	Description
<i>filespec</i>	Specifies the path to the file. You can use the wildcard character, *, for filename as long as it resolves to one file.
<b>detail</b>	Long listing with date and time
<b>hex</b>	Show the listing in hexadecimal.
<i>lines</i>	Specifies the number of lines to display.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file view

This command shows the contents of log files.

**file view** {**activelog/inactivelog/install**} **file-spec**

Syntax Description	Parameters	Description
	<b>activelog</b>	Shows the contents of an active side logging files
	<b>inactivelog</b>	Shows the contents of an inactive side logging files
	<b>install</b>	Shows the contents of an install logging file
	<i>file-spec</i>	Specifies the path to the file to view. You can use the wildcard character, *, as long as it resolves to one file.

**Command Modes** Administrator (admin:)

### Usage Guidelines



**Caution** Do not use this command to view binary files because this can corrupt the terminal session.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

This example shows a particular CDR log on the active side.

```
admin: file view activelog /cm/cdr_repository/processed/20058012/{filename}
```

## file view activelog

This command shows the contents of log files.

**file view activelog file-spec**

Syntax Description	Parameters	Description
	<b>activelog</b>	Shows the contents of an active side logging files
	<i>file-spec</i>	Specifies the path to the file to view. You can use the wildcard character, *, as long as it resolves to one file.

**Command Modes** Administrator (admin:)

---

## Usage Guidelines



**Caution** Do not use this command to view binary files because this can corrupt the terminal session.

---



**Note** This command may use a considerable amount of I/O and running it may impact system performance. It is highly recommended that this command be run off-hours.

---

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

This example shows a particular log on the active side.

```
admin:file view activelog cm/trace/ccm/sdl/{filename}
```

## file view inactivelog

This command displays the contents of a log on the inactive side.

**file view inactivelog** {file-spec}

---

### Syntax Description

Parameters	Description
<b>file-spec</b>	Specifies the path to the file to view. You can use the wildcard character, *, for <b>file-spec</b> as long as it resolves to one file.

---

### Command Modes

Administrator (admin:)

---

### Usage Guidelines



**Caution** Do not use this command to view binary files because this can corrupt the terminal session.

---



**Note** This command may use a considerable amount of I/O and running it may impact system performance. It is highly recommended that this command be run off-hours.

---



**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified CM, Unified CM with IM and Presence, Cisco Unity Connection

**Example**

This example shows a particular log on the inactive side.

```
admin:file view inactive log cm/trace/ccm/sdl/{filename}
```

## file view system-management-log

This command shows the contents of the Integrated Management Logs (IML).

**file view system-management-log**

---

**Command Modes** Administrator (admin:)

**Usage Guidelines**


---

**Caution** Do not use this command to view binary files because this can corrupt the terminal session.

---

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## file view tftp

This command displays the contents of the installation log.

**file view tftp** *file-spec*

**Syntax Description**

Parameters	Description
<i>file-spec</i>	Specifies the path to the file to view. You can use the wildcard character, *, as long as it resolves to one file.

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines**

---

**Caution** Do not use this command to view binary files because this can corrupt the terminal session.

---

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection



## CHAPTER 4

# License Commands

---

- [license smart deregister](#), on page 35
- [license smart register idtoken <token> \[force\]](#), on page 36
- [license smart renew auth](#), on page 36
- [license smart renew ID](#), on page 36
- [license smart transport direct](#), on page 37
- [license smart transport gateway <URL>](#), on page 37
- [license smart transport proxy <proxy-server> <proxy-port>](#), on page 38
- [license smart factory reset](#), on page 38
- [license smart reservation enable](#), on page 39
- [license smart reservation disable](#), on page 39
- [license smart reservation request](#), on page 39
- [license smart reservation cancel](#), on page 40
- [license smart reservation install "<authorization-code>"](#), on page 40
- [license smart reservation install-file <url>](#), on page 40
- [license smart reservation return](#), on page 41
- [license smart reservation return authorization "<authorization-code>"](#), on page 41
- [license smart export request local <exportfeaturename>](#), on page 42
- [license smart export return local <exportfeaturename>](#), on page 42
- [license smart export cancel](#), on page 43

## license smart deregister

Use this command to unregister smart licensing on Unified Communications Manager and remove the product from Cisco Smart Software Manager.

### license smart deregister

---

**Command Modes**

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

```
license smart register idtoken <token> [force]
```

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart register idtoken <token> [force]

Use this command to register Unified Communications Manager with Cisco Smart Software Manager using an ID token.

```
license smart register idtoken <token> [force]
```

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart renew auth

Use this command to manually renew the license usage information .

```
license smart renew auth
```

---

### Command Modes

Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart renew ID

Use this command to manually renew the license registration.

```
license smart renew ID
```

---

### Command Modes

Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart transport direct

Use the following command to configure the Smart Licensing feature to send license usage information directly to Cisco Smart Software Manager. This is a default setting.

**license smart transport direct**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager



---

**Note** The following command is executed when Unified Communications Manager is unregistered with Cisco Smart Software Manager or satellite.

---

## license smart transport gateway <URL>

Use the following command to configure the Smart Licensing feature to send license usage information to Cisco Smart Software Manager through an on-premise Transport Gateway or Smart Software Manager satellite. The setting is used when the product does not have internet access.

**license smart transport gateway <URL>**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager



---

**Note** The following command is executed when Unified Communications Manager is unregistered with Cisco Smart Software Manager or satellite.

---

**license smart transport proxy <proxy-server> <proxy-port>**

## license smart transport proxy <proxy-server> <proxy-port>

Use the following command to configure the Smart Licensing feature to communicate with Cisco Smart Software Manager through an HTTP or HTTPS Proxy:

<proxy-server> - Proxy Server IP Address/HostName

<proxy-port> - Proxy Server Port

**license smart transport proxy <proxy-server> <proxy-port>**

### Command Modes

Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager



**Note** The following command is executed when Unified Communications Manager is unregistered with Cisco Smart Software Manager.



**Note** When user gets the prompt **Do you want to enable Authentication based proxy? Yes/No**  
Enter "Yes" if you want to register Unified Communication Manager with Cisco Smart Software Manager using authentication based proxy server.

### Example

```
admin:license smart transport proxy <proxy-server> <proxy-port>
```

```
Do you want to enable Authentication based proxy ? y/n y
User Name : xyz
Password: *****
```

Result: Transport settings updated successfully.

## license smart factory reset

Use this command to clear all licensing information from the trusted store and memory, except the evaluation period count down and the Specific License Reservation (SLR) sequence number.

**license smart factory reset**

### Command Modes

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Cisco Unified Communications Manager

## license smart reservation enable

Use this command to enable the license reservation feature.

**license smart reservation enable**

---

**Command Modes**

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart reservation disable

Use this command to disable the license reservation feature.

**license smart reservation disable**

---

**Command Modes**

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart reservation request

Use this command to generate reservation request code from Unified Communications Manager product.

**license smart reservation request**

---

**Command Modes**

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart reservation cancel

Use this command to cancel the reservation process before the authorization code obtained from Cisco Smart Software Manager against the Product request code is installed.

### license smart reservation cancel

---

**Command Modes** Administrator (admin)

#### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart reservation install "<authorization-code>"

Use this command to install the license reservation authorization-code generated on the Cisco Smart Software Manager.

### license smart reservation install "<authorization-code>"

---

**Command Modes** Administrator (admin)

#### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart reservation install-file <url>

Use this command to install the license reservation authorization-code file generated on the Cisco Smart Software Manager.

### license smart reservation install-file <url>

---

**Command Modes** Administrator (admin)

#### Requirements

Command privilege level: 4



Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection



---

**Note** url is mandatory Path to the authorization-code file on SFTP server in below format:  
sftp://<HostName/IP>:<port>/<Path to Authorization-Code file>

---

## license smart reservation return

Use this command to generate a return code that must be entered into the Cisco Smart Software Manager to return the licenses to the virtual account pool.

### license smart reservation return

---

**Command Modes** Administrator (admin)

#### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart reservation return authorization "<authorization-code>"

Use this command to generate a return code using the authorization code specified on the command line. The return code must be entered into the Cisco Smart Software Manager to return the licenses to the virtual account pool.

### license smart reservation return authorization "<authorization-code>"

---

**Command Modes** Administrator (admin)

#### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## license smart export request local <exportfeaturename>

Use this command to allow user with Smart Account for whom Export Restrictions apply, to request a regulatory export license from Cisco Smart Software Manager or satellite.

The command returns an export authorization key if regulatory Export License is available from Cisco Smart Software Manager or satellite and enable export-controlled functionality on the product.

**license smart export request local <exportfeaturename>**



- 
- Note**
- Export restricted feature name for Unified Communications Manager is <CUCM\_Export\_Restricted\_Authorization\_Key>
  - Export restricted feature name for Cisco Unity Connection is <CUC\_Export\_Restricted\_Authorization\_Key>
- 

### Command Modes

Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Cisco Unified Communications Manager, Cisco Unity Connection.

## license smart export return local <exportfeaturename>

Use this command to allow a return, previously requested export restricted license to Cisco Smart Software Manager or satellite. The export authorization key for the export restricted feature is removed from the system.

**license smart export return local <exportfeaturename>**



- 
- Note**
- Export restricted feature name for Unified Communications Manager is <CUCM\_Export\_Restricted\_Authorization\_Key>
  - Export restricted feature name for Cisco Unity Connection is <CUC\_Export\_Restricted\_Authorization\_Key>
- 

### Command Modes

Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Cisco Unified Communications Manager, Cisco Unity Connection.

## license smart export cancel

Use this command to allow user with Smart Account for whom Export Restrictions apply, to cancel the automatic retry of previously failed export request or return from Cisco Smart Software Manager or satellite.

### license smart export cancel

---

**Command Modes**

Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Cisco Unified Communications Manager, Cisco Unity Connection.

license smart export cancel



## CHAPTER 5

# Run Commands

- [run cuc dbquery](#), on page 45
- [run cuc preupgrade test](#), on page 46
- [run cuc smtpstest](#), on page 48
- [run cuc sysagent task](#), on page 48
- [run cuc vui rebuild](#), on page 49
- [run loadcsv](#), on page 50
- [run loadxml](#), on page 50
- [run sql](#), on page 51
- [run pe sql](#), on page 51

## run cuc dbquery

This command runs an SQL query and displays the results.

**run cuc dbquery** *database\_name sql\_query* [**page**]

### Syntax Description

Parameters	Description
<i>database_name</i>	Specifies the database that <i>sql_statement</i> operates on.  <b>Note</b> Be aware that database names are case sensitive.  Connection databases include: <b>unitydirdb</b> : Contains the directory and configuration data. <b>unitydyndb</b> : Contains dynamic data that Connection uses internally. <b>unitymbxdb1</b> to <b>unitymbxdb5</b> : Contains the data about the current voice messages in the corresponding mailbox store. This data includes pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b> . <b>unityrptdb</b> : Contains audit log data.
<i>sql_query</i>	Specifies the SQL query that you want to run.

Parameters	Description
<b>page</b>	Shows the output one page at a time.
<b>Note</b>	Be aware that <b>page</b> is case sensitive.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

You can also use the **run cuc dbquery** command with the `csp_ConfigurationModify` procedure, which configures the Wait for Blind Transfer Ringing timer. The command usage for this timer is as follows:

```
run cuc dbquery unitydirdb execute procedure
csp_ConfigurationModify(pFullName='System.Telephony.WaitForBlindTransferLongTimeoutMs',pvalueLong="new
value"
```

where, *new value* specifies the value of the Wait for Blind Transfer Ringing Timer parameter. The default and minimum value of this parameter is 500ms. The maximum value of this parameter can be 5000ms.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

The following example runs the SQL query **select alias from vw\_usertemplate** on the unitydirdb database.

```
admin: run cuc dbquery unitydirdb select alias from vw_usertemplate
```

```
alias
```

```
-----
```

```
AdministratorTemplate
```

```
VoiceMailUserTemplate
```

## run cuc preupgrade test

This command verifies the state of the connection server on which the upgrade process is to be performed and specifies the actions that can be taken before upgrading the system.

**run cuc preupgrade test****Command Modes**

Administrator (admin:)

**Usage Guidelines** None**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only.

**Example**

```

admin:run cuc preupgrade test
=====
DISCLAIMER ::
This cli command should be executed from publisher before upgrade to
check system health. This cli command is not intended to correct the
system state , rather it aims at informing the administrator what all
actions are advised to be taken before running upgrade.
=====
Checking connection db. Please wait...Done
Checking critical services. Please wait...Done
Checking cluster state. Please wait...Done
Checking cop file installation. Please wait...Done
Checking locales installation. Please wait...Done
Checking drs backup history. Please wait...Done
=====
R E P O R T   C A R D
=====
Locales Installation Test: PASS
Connection DB Test: PASS
DRS Backup History Test: FAIL
Cluster State Test: SKIPPED
Critical Services Test: PASS
Cop File Installation Test: SKIPPED
=====
A C T I O N   S U M M A R Y
=====
ACTION : Connection DB is online.
        NO constraints were found disabled in :unitydirdb,NO ACTION required before upgrade.

        NO indexes were found disabled in :unitydirdb,NO ACTION required before upgrade.
        NO constraints were found disabled in :unitydyndb,NO ACTION required before upgrade.

        NO indexes were found disabled in :unitydyndb,NO ACTION required before upgrade.
        NO constraints were found disabled in :unitymbxdb1,NO ACTION required before
upgrade.

        NO indexes were found disabled in :unitymbxdb1,NO ACTION required before upgrade.
        NO constraints were found disabled in :unityrptdb,NO ACTION required before upgrade.

        NO indexes were found disabled in :unityrptdb,NO ACTION required before upgrade.
        Connection DB state is GOOD,NO ACTION required before upgrade.
ACTION : All Critical services are running ,NO ACTION required before upgrade.
ACTION : Standalone/Cores detected , excluding cluster state checking
ACTION : Skipping COP installation check, product version detected :'8.6.2.21018-1',NO
ACTION required before upgrade.
ACTION : No locales were found installed ,NO ACTION required before upgrade.
ACTION : Make Sure DRS backup is taken atleast a day before upgrade.
Check report /var/log/active/cuc/cli/preupgrade_120325-224523.txt for details.

```

## run cuc smtpstest

This command initiates a test that helps to verify the outgoing or incoming SMTP configuration for SpeechView transcriptions.

**run cuc smtpstest** *email-address*

### Syntax Description

Parameters	Description
<i>email-address</i>	Specifies the email address.

### Command Modes

Administrator (admin:)

### Usage Guidelines

The test sends a test message to a specified email address. You then access the email account and reply to the test message without changing the subject line. The test passes after the Cisco Unity Connection server receives the response. The success or failure of parts of the test help to pinpoint problems in the outgoing or incoming SMTP configuration for transcriptions.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection.

### Example

The following example runs the Sysagent task **CleanDeletedMessagesTask**.

```
admin: run cuc sysagent task CleanDeletedMessagesTask
```

## run cuc sysagent task

This command runs a Sysagent task.

**run cuc sysagent task** *task\_name*

### Syntax Description

Parameters	Description
<i>task_name</i>	Specifies the name of the Sysagent task that you want to run.

In an HTTP(S) network, you need to provide the HTTP(S) link display name as a parameter in the command to run directory synchronization (Data.LocalNetworkSync) and voice name synchronization (Data.LocalNetworkSync.Voicename) tasks. The syntax is shown below:

**run cuc sysagent task** *task\_name HTTP(S)LinkDisplayName*

The following example runs the `Data.LocalNetworkSync` task:



```
admin: run cuc sysagent task Data.LocalNetworkSync HTTP(S)LinkDisplayName1
```

```
Data.LocalNetworkSync started
```

Where HTTP(S)LinkDisplayName is the display name of the HTTP(S) link with which you want to synchronize the directory information.



---

**Note** Before running the command, make sure that the scheduled task for directory or voice name synchronization is disabled for the specified HTTP(S) link "HTTP(S)LinkDisplayName" to avoid any issues in synchronization.

---

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** For a list of Sysagent tasks, run the command **show cuc sysagent task list** (Cisco Unity Connection only). Be aware that sysagent task names are case sensitive.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example

The following example runs the Sysagent task **Umss.CleanDeletedMessagesTask**.

```
admin: run cuc sysagent task Umss.CleanDeletedMessagesTask
```

```
Umss.CleanDeletedMessagesTask started
```

## run cuc vui rebuild

This command instructs the voice recognition transport utility to immediately rebuild the voice recognition name grammars with pending changes.

### run cuc vui rebuild

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** This command rebuilds only grammars that have changes flagged in the database. This command ignores name grammar update blackout schedules and executes immediately. Due to the overhead of retrieving potentially large amounts of name-related data from the database, you should use this command sparingly and only when absolutely necessary.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## run loadcsv

This command is used on the publisher node to install the csv files that are available on a server.

**run loadcsv****Command Modes**

Administrator (admin:)

**Usage Guidelines****Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## run loadxml

This command is a workaround for when service parameters or product-specific information does not appear in the administration window as expected.

**run loadxml****Command Modes**

Administrator (admin:)

**Usage Guidelines**

**Note** This command is processor intensive, and you may need to restart some services after you run this command.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

# run sql

This command allows you to run an SQL command.

**run sql** *sql\_statement*

Syntax Description	Parameters	Description
	<i>sql_statement</i>	Specifies the SQL command to run.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: 0

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection



**Note** Users with ordinary privileges can run read-only SQL commands.

### Example

This example runs an SQL command.

```
admin: run sql select name from device
```

# run pe sql

This command allows you to run an input SQL statement against the specified presence datastore.

**run pe sql** *datastore\_name sql\_statement*

Syntax Description	Parameters	Description
	<i>datastore_name</i>	Represents the name of the datastore.
	<i>sql_statement</i>	Represents the SQL command to run.

**Command Modes** Administrator (admin:)

### Usage Guidelines

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: IM and Presence Service on Unified Communications Manager



---

**Note** Users with ordinary privileges can run read-only SQL commands.

---

### Example

This example runs an SQL command against the datastore.

```
admin: run pe sql ttsoft select * from presenceeventtable
```



## CHAPTER 6

# Set Commands

---

- [set account enable](#), on page 55
- [set account name](#), on page 56
- [set accountlocking](#), on page 57
- [set accountlocking count](#), on page 58
- [set accountlocking unlocktime](#), on page 59
- [set account ssorecoveryurlaccess](#), on page 59
- [set account ssoidvalue](#), on page 60
- [set cert bulk consolidate](#), on page 61
- [set cert bulk export](#), on page 61
- [set cert bulk import](#), on page 62
- [set cert bulk sftp](#), on page 62
- [set cert default-ca-list disable](#), on page 63
- [set cert default-ca-list enable](#), on page 64
- [set cert delete](#), on page 66
- [set cert import](#), on page 66
- [set cert regen](#), on page 67
- [set cert regen ITLRecovery](#), on page 68
- [set cli pagination](#), on page 68
- [set cli session timeout](#), on page 69
- [set commandcount](#), on page 70
- [set csr gen](#), on page 70
- [set cuc jetty stderrlog](#), on page 71
- [set cuc jetty stdoutlog](#), on page 72
- [set cuc jetty requestlog](#), on page 73
- [set cuc speechview registration certificate size](#), on page 73
- [set cuc srsv timeout](#), on page 74
- [set cuc trace](#), on page 74
- [set date](#), on page 75
- [set dscp defaults](#), on page 76
- [set dscp](#), on page 76
- [set dscp marking](#), on page 77
- [set ipsec policy\\_group](#), on page 78
- [set ipsec policy\\_name](#), on page 78

- [set key regen authz encryption](#), on page 79
- [set key regen authz signing](#) , on page 79
- [set logging](#), on page 79
- [set Login Grace Timeout](#), on page 80
- [set network cluster publisher](#), on page 80
- [set network cluster subscriber details](#), on page 81
- [set network cluster subscriber dynamic-cluster-configuration](#), on page 82
- [set network dhcp eth0](#), on page 82
- [set network dns](#), on page 83
- [set network dns options](#), on page 83
- [set network domain](#), on page 84
- [set network failover](#), on page 85
- [set network gateway](#), on page 86
- [set network hostname](#), on page 86
- [set network ip eth0](#), on page 88
- [set network ipv6 dhcp](#), on page 89
- [set network ipv6 gateway](#), on page 90
- [set network ipv6 service](#), on page 91
- [set network ipv6 static\\_address](#), on page 91
- [set network max\\_ip\\_contrack](#), on page 92
- [set network mtu](#), on page 92
- [set network name-service hosts cache-enable](#), on page 93
- [set network name-service hosts max-db-size](#), on page 94
- [set network name-service hosts negative-time-to-live](#), on page 94
- [set network name-service hosts persistent](#), on page 95
- [set network name-service hosts positive-time-to-live](#), on page 95
- [set network name-service hosts suggested-size](#), on page 95
- [set network name-service services cache-enable](#), on page 96
- [set network name-service services max-db-size](#), on page 96
- [set network name-service services negative-time-to-live](#), on page 97
- [set network name-service services persistent](#), on page 97
- [set network name-service services positive-time-to-live](#), on page 98
- [set network name-service services suggested-size](#), on page 98
- [set network nic eth0](#), on page 99
- [set network ntp option](#), on page 99
- [set network pmtud state](#), on page 100
- [set network restore](#) , on page 100
- [set network status eth0](#), on page 102
- [set network name-service](#), on page 102
- [set password complexity minimum-length](#), on page 103
- [set password age](#), on page 103
- [set password change-at-login](#), on page 104
- [set password complexity character](#), on page 104
- [set password complexity character difference](#), on page 106
- [set password complexity character max-repeat](#), on page 106
- [set password expiry maximum-age](#), on page 107

- [set password expiry user maximum-age configure](#), on page 108
- [set password expiry minimum-age](#), on page 108
- [set password expiry user maximum-age](#), on page 109
- [set password expiry user minimum-age](#), on page 110
- [set password history](#), on page 111
- [set password inactivity](#), on page 111
- [set password system bootloader encryptHash](#), on page 112
- [set password user admin](#), on page 112
- [set password user security](#), on page 113
- [Set replication-sync monitor](#), on page 114
- [set samltrace level](#), on page 114
- [set session maxlimit](#), on page 115
- [set smtp](#), on page 115
- [set strace enable](#), on page 116
- [set strace disable](#), on page 116
- [set timezone](#), on page 117
- [set tls min-version](#), on page 117
- [set trace disable](#), on page 118
- [set trace enable](#), on page 119
- [set tlsresumptiontimeout](#), on page 120
- [set tlstrace\\*](#), on page 120
- [set web-security](#), on page 121
- [set webapp session timeout](#), on page 123
- [set webapp session maxlimit](#), on page 123
- [set workingdir](#), on page 126

## set account enable

This command enables the OS user account that was disabled because of password inactivity.

**set account enable** *user-id*

Syntax	Description
<b>Parameters</b>	<b>Description</b>
<i>user-id</i>	Specifies the user ID of the account that was disabled.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

# set account name

This command sets up a new account on the operating system.

**set account name** *name*

## Syntax Description

Parameters	Description
<i>name</i>	Represents the username for the new account.  Enter a name comprised of only alphabets or characters comprised of alphanumeric characters (a-z, A-D, 0-9).  <b>Note</b> Umlaut characters are not supported.

## Command Modes

Administrator (admin:)

## Usage Guidelines

After you enter the username, the system prompts you to enter the privilege level (0 or 1) and password for the new account. The privilege levels definitions are as follows:

### Privilege level 0

Specifies an ordinary privilege level. Users with ordinary privileges can run CLI commands with privilege level 0 only.

### Privilege level 1

Specifies an advanced privilege level. Users with advanced privileges can run CLI commands with privilege level 1 and below.



**Note** The administrator account that the system creates during Unified Communications Manager installation has a privilege level of 4. The administrator can run all commands in the CLI.

The **set account name** command includes the following new prompts:

- **'Allow this User to login to SAML SSO-enabled system through the Recovery URL ? (Yes / No)'** — Level 4 administrators can enable or disable the access to the recovery URL sign-in option for new platform administrators by typing **'Yes'** or **'No'** on the CLI. The value can be configured to **'Yes'** if a user chooses to sign-in using the Recovery URL.
- **'To authenticate a platform login for SSO, a Unique Identifier (UID) must be provided that identifies this user to LDAP (such as sAMAccountName or UPN). Please enter the appropriate LDAP Unique Identifier (UID) for this user:[UID]'** — Level 4 administrator can type the unique identifier value for each platform administrator for this prompt.





**Note** Only the Level 4 administrator has privileges to run all the CLI commands.

The administrator must ensure to perform the following tasks:

- Type either 'Yes' or 'No' for the '**Allow this User to login to SAML SSO-enabled system through Recovery URL ? (Yes / No)**' prompt. If this prompt value is blank, an error message appears.
- Type a value for the '**To authenticate a platform login for SSO, a Unique Identifier (UID) must be provided that identifies this user to LDAP (such as sAMAccountName or UPN). Please enter the appropriate LDAP Unique Identifier (UID) for this user:[UID]**' prompt. If the prompt value is duplicate, an error message appears. You can hit the Enter key and then, the user account name is saved by default. After the account is created successfully, the administrator will see the message *Account created successfully. Log in to the CLI and update the password before you log in to OS Administration.*
- In the case of SAML SSO login for Operating System Admin pages, if LDAP user consists of '&' character, make sure you create platform user without '&' and then map to LDAP user consisting of '&' character.
- In the case of SAML SSO login for Operating System Admin pages, if LDAP attribute value for User ID is telephonenumber, make sure you create platform user using consisting of alphanumeric characters or English alphabets only. Do not include platform user name with only numeric values. Then, map to the appropriate LDAP user having the UID value as telephone number.

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## set accountlocking

This command enables or disables account locking for the current administration accounts.

**set accountlocking** {enable | disable}

Syntax Description	Parameters	Description
	<b>enable</b>	Enable account locking.
	<b>disable</b>	Disable account locking.

**Command Modes** Administrator (admin:)

## Usage Guidelines



**Note** After you run this command with **enable**, the system automatically enables account lockout notification after the system enables the audit logging function.

When the Administration account locking feature is enabled, and the user enters the wrong password more than the accountlocking count, the account gets locked for a set period. The message that the account is locked is only seen on the VM console and secure logs.

### Requirements

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

# set accountlocking count

This command sets the global consecutive failed sign-in attempt count that triggers locking a user account.

**set accountlocking count** *attempts*

Syntax Description	Parameters	Description
	<i>attempts</i>	Represents the number of consecutive sign-in attempts before the system locks the account. Value Range: 2-5 Default value: 3

### Command Modes

Administrator (admin:)

### Usage Guidelines

To change the global value for consecutive failed sign-in attempts before the system locks a user account, execute this command.



**Note** This command is only valid when account locking is enabled. If account locking is disabled, the system does not remember the account locking value and uses the default value, 3, after you enable account locking.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## set accountlocking unlocktime

This command configures the unlock time for the current Unified Communications Manager admin accounts.

**set accountlocking unlocktime** *seconds*

Syntax Description	Parameters	Description
	<i>seconds</i>	Specifies the unlock time in seconds. Value Range: 30-3600 Default value: 300



- Note**
- The account gets automatically unlocked only after the configured unlock time.
  - This command is only valid when account locking is enabled. If account locking is disabled, the system does not remember the account locking unlock time and uses the default value, 300, after you enable account locking.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## set account ssorecoveryurlaccess

This command enables or disables the SSO recovery URL access for platform administrators.



- Note** By default, the platform administrator Level 4 has access to the recovery URL. If the platform administrator Level 4 attempts to update the recovery URL access for own self, an error appears.

**set account ssorecoveryurlaccess** {**enable** | **disable**}*userid*

Syntax Description	Parameters	Description
	<b>enable</b>	Enable the recovery sign-in option for platform administrators.
	<b>disable</b>	Disable the recovery sign-in option for platform administrators.

Parameters	Description
<i>userid</i>	Specifies a particular Cisco Unified Operating System Administrator account.

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Note**

- If you enable or disable the recovery sign-in option, which is already enabled or disabled, an error appears.
- The administrator account that the system creates when Unified Communications Manager installs has a privilege level of 4. The administrator can run all commands in the CLI.

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager

## set account ssoidvalue

This command updates the unique identifier value for the existing platform administrators.

**set account ssoidvalue** *userid*

**Syntax Description**

Parameters	Description
<i>userid</i>	Specifies a particular Cisco Unified Operating System Administrator account whose unique identifier value needs to be updated.

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Note**

- When you run the **set account ssoidvalue userid** command, a prompt appears to provide the UID value. If the UID value is blank, then samaccountname is saved as ssoidvalue by default.
- If a duplicate UID value exists, an error appears.

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager

## set cert bulk consolidate

This command consolidates all the certificates that are available on the unit.

**set cert bulk consolidate** *unit*

### Syntax Description

Parameters	Description
<i>unit</i>	Represents the unit name.

### Command Modes

Administrator (admin:)

### Usage Guidelines

You must specify the SFTP server information to use for cert bulk operations.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

#### Related Topics

[set cert bulk sftp](#), on page 62

## set cert bulk export

This command exports all the certificates that are available on the unit.

**set cert bulk export** *unit*

### Syntax Description

Parameters	Description
<b>export</b>	Exports all the available certificates for this unit in this cluster to the preconfigured SFTP location.
<i>unit</i>	Represents the unit name.

### Command Modes

Administrator (admin:)

### Usage Guidelines

You must specify the SFTP server information to use for cert bulk operations.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set cert bulk export all
Successfully exported tomcat certificate(s) to sftp server.
Successfully exported tftp certificate(s) to sftp server.
```

### Related Topics

[set cert bulk sftp](#), on page 62

## set cert bulk import

This command imports the certificates that are in the SFTP location into the specified unit trust-store.

**set cert bulk import** *unit*

### Syntax Description

Parameters	Description
<i>unit</i>	Represents the unit name.

### Command Modes

Administrator (admin:)

### Usage Guidelines

You must specify the SFTP server information to use for cert bulk operations.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set cert bulk import all
Successfully imported tomcat certificates.
Successfully imported tftp certificates.
```

### Related Topics

[set cert bulk sftp](#), on page 62

## set cert bulk sftp

This command prompts for the SFTP server information to use for bulk operations.

**set cert bulk sftp****Command Modes**

Administrator (admin:)

**Usage Guidelines**

You must specify the SFTP server information to use for cert bulk operations.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set cert default-ca-list disable

This command disables all or particular default CA certificates from all servers in the cluster.

When you try to execute this command, a warning message appears displaying that this operation disables all or particular default Cisco CA certificates.

```
set cert default-ca-list disable {all | common-name}
```

**Note**

- Please ensure that you are executing this command from the Unified Communications Manager publisher node.
- The default CA certificate names can be obtained by executing the **show cert default-ca-list** command.

**Syntax Description**

Parameters	Description
<b>all</b>	Deletes all the default CA certificates from all servers in the cluster.
<b>common-name</b>	Deletes the particular default CA certificate from all servers in the cluster.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

Consider the following information after you disable all the default CA certificates.

- Restart the “Cisco Tomcat”, “Cisco CallManager”, “Cisco Tftp”, and “Cisco Certificate Authority Proxy Function” services.

Consider the following information after you disable the specific default CA certificate.

- Restart the “Cisco CallManager”, “Cisco Tftp”, and “Cisco Certificate Authority Proxy Function” services.
- If you are disabling “VeriSign Class 3 Secure Server CA - G3” certificate, then restarting of only “Cisco Tomcat” service is sufficient.

## Requirements

Command privilege level: 1

Applies to: Unified Communications Manager

## Example

```
admin:set cert default-ca-list disable all
```

WARNING: This operation will disable all Cisco CA certificates that have been installed by default. You can use the "show cert default-ca-list" to view the list of default Cisco CA certificates.

You must restart the "Cisco Tomcat", "Cisco CallManager", "Cisco Tftp" and "Cisco Certificate Authority Proxy Function" services after running this command. This command should be run from the Publisher.

Do you wish to proceed (yes|no)? **yes**

Successfully disabled the default Cisco CA certificates.

Please wait for a few min to UI to reflect the correct status.

```
admin:set cert default-ca-list disable common-name
```

Enter the Common Name of Default CA Certificate : **CAP-RTP-001**

WARNING: This operation will disable the "CAP-RTP-001" Cisco CA certificate.

You must restart the "Cisco CallManager", "Cisco Certificate Authority Proxy Function" and "Cisco Tftp" services after running this command. This command should be run from the Publisher.

Do you wish to proceed (yes|no)? **yes**

Successfully disabled default "CAP-RTP-001" certificate.

```
admin:set cert default-ca-list disable common-name
```

Enter the Common Name of Default CA Certificate : **VeriSign Class 3 Secure Server CA - G3**

WARNING: This operation will disable the "VeriSign Class 3 Secure Server CA - G3" Cisco CA certificate. You must restart the "Cisco Tomcat" services after running this command.

This command should be run from the Publisher.

Do you wish to proceed (yes|no)? **yes**

Successfully disabled default "VeriSign Class 3 Secure Server CA - G3" certificate.

```
admin:set cert default-ca-list enable common-name
```

Enter the Common Name of Default CA Certificate : **capf**

The capf certificate is not in the list of default Cisco CA certificates.

admin:

# set cert default-ca-list enable

This command enables all or particular default CA certificates except CAPF-trust on all servers in the cluster. CAPF-trust certificate enable only on the Unified Communications Manager publisher node not across the cluster.

When you try to execute this command, a warning message appears displaying that this operation enables all or particular default Cisco CA certificates as a trusted certificate.

```
set cert default-ca-list enable {all |common-name}
```





- Note**
- Please ensure that you are executing this command from the Unified Communications Manager publisher node.
  - The default CA certificate names can be obtained by executing the **show cert default-ca-list** command.

Syntax Description	Parameters	Description
	<b>all</b>	Enables all the default CA certificates on all servers in the cluster.
	<b>common-name</b>	Enables the particular default CA certificate on all servers in the cluster.

**Command Modes** Administrator (admin:)

**Usage Guidelines** Consider the following information after you enable all the default CA certificates.

- Restart the “Cisco Tomcat”, “Cisco CallManager”, “Cisco Tftp”, and “Cisco Certificate Authority Proxy Function” services.

Consider the following information after you enable the specific default CA certificate.

- Restart the “Cisco CallManager”, “Cisco Tftp”, and “Cisco Certificate Authority Proxy Function” services.
- If you are enabling “VeriSign Class 3 Secure Server CA - G3” certificate, then restarting of only “Cisco Tomcat” service is sufficient.

### Requirements

Command privilege level: 1

Applies to: Unified Communications Manager

### Example

```
admin:set cert default-ca-list enable all
```

```
WARNING: This operation will enable all default Cisco CA certificates
as trusted certificates for all nodes in this cluster.
You can use the "show cert default-ca-list" to view the list of default
Cisco CA certificates. You must restart the "Cisco Tomcat", "Cisco CallManager",
"Cisco Tftp" and "Cisco Certificate Authority Proxy Function" services after
running this command. This command should be run from the Publisher.
```

```
Do you wish to proceed (yes|no)? yes
```

```
Successfully enabled the default Cisco CA certificates.
```

```
Please wait for a few minutes for the UI to reflect the correct status.
```

```
admin:set cert default-ca-list enable common-name
```

```
Enter the Common Name of Default CA Certificate : CAP-RTP-002
```

```
WARNING: This operation will install the "CAP-RTP-002" certificate as a trusted certificate
for all nodes in this cluster. You must restart the "Cisco CallManager",
"Cisco Certificate Authority Proxy Function" and "Cisco Tftp" services after running this
```

```
command. This command should be run from the Publisher.
Do you wish to proceed (yes|no)? yes
Successfully enabled default "CAP-RTP-002" certificate.
```

```
admin:set cert default-ca-list enable common-name
Enter the Common Name of Default CA Certificate : VeriSign Class 3 Secure Server CA - G3
WARNING: This operation will install the "VeriSign Class 3 Secure Server CA - G3" certificate
as a trusted certificate for all nodes in this cluster. You must restart the "Cisco Tomcat"
services after running this command. This command should be run from the Publisher.
Do you wish to proceed (yes|no)? yes
Successfully enabled default "VeriSign Class 3 Secure Server CA - G3" certificate.
```

```
admin:set cert default-ca-list enable common-name
Enter the Common Name of Default CA Certificate : CAP-RTP-003
The CAP-RTP-003 certificate is not in the list of default Cisco CA certificates.
admin:
```

## set cert delete

This command deletes a specific certificate file from the trust unit.

```
set cert delete unit name
```

Syntax Description	Parameters	Description
	<i>unit</i>	Specifies the name of the trust category, as “own” or “trust”.
	<i>name</i>	Certificate file name.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set cert delete cucm siptest.pem
```

## set cert import

This command imports the specified certificate for the specified certificate type.

```
set cert import type name [caCert]
```

Syntax Description	Parameters	Description
	<i>type</i>	Specifies the certificate type as “own” or “trust”.
	<i>name</i>	Represents the unit name.
	[ <i>caCert</i> ]	Represents the name of the CA certificate file name.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set cert import trust tomcat
Successfully imported certificate for tomcat.
Please restart services related to tomcat for the new certificate to
become active.
```

## set cert regen

This command regenerates the certificate for the specified unit.

**set cert regen** *name*

Syntax Description	Parameters	Description
	<i>name</i>	Represents the unit name.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set cert regen tomcat
Successfully regenerated certificate for tomcat.
```

## set cert regen ITLRecovery

This command regenerates the ITLRecovery certificate for the specified unit.

After you type this command, a warning message appears displaying that if you are using a tokenless CTL and if the you are regenerating the CallManager certificate, ensure that the CTL file has the updated CallManager certificate and that certificate is updated to endpoints. To regenerate the certificate, type **yes** or else type **no**.

**set cert regen** *ITLRecovery*

### Syntax Description

#### Parameters Description

*ITLRecovery* Represents the ITLRecovery certificate.

### Command Modes

Administrator (admin:)

### Requirements



**Caution** You must restart the services related to ITLRecovery for the regenerated certificates to become active.

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set cert regen ITLRecovery
```

```
WARNING: If you are using a tokenless CTL and if the CallManager certificate is recently
generated, please ensure that the CTL File already has the new CallManager certificate and
is
updated to the endpoints, before generating the ITL Recovery certificate. Are you sure want
to proceed?
```

```
Proceed with regeneration (yes|no)? yes
```

```
Successfully Regenerated Certificate for ITLRecovery.
```

```
You must restart the services related to ITLRecovery for the regenerated certificates to
become active.
```

## set cli pagination

For the current CLI session, this command turns automatic pagination On or Off.

**set cli pagination** {on | off}

Syntax Description	Parameters	Description
	<b>on</b>	Turns pagination on.
	<b>off</b>	Turns pagination off.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

```
admin:set cli pagination off
Automatic pagination is turned off
```

## set cli session timeout

This command sets the time, in minutes, after which an active CLI session times out and disconnects.

**set cli session timeout** *minutes*

Syntax Description	Parameters	Description
	<i>minutes</i>	Specifies the time, in minutes, that can elapse before an active CLI session times out and disconnects. <ul style="list-style-type: none"> <li>• Value range: 5-99999 minutes</li> <li>• Default value: 30 minutes</li> </ul>

**Command Modes** Administrator (admin:)

**Usage Guidelines** Be aware that the new session timeout value becomes effective immediately for a new CLI session; however, active sessions retain their original timeout value. Also the show cli session timeout command reflects the new value, even if the current session does not use that value.



**Note** This setting gets preserved through a software upgrade and does not get reset to the default value.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set commandcount

This command changes the CLI command prompt, so it displays how many CLI commands have executed.

```
set commandcount {enable | disable}
```

Syntax Description	Parameters	Description
	<b>enable</b>	Turns on command count.
	<b>disable</b>	Turns off command count.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set csr gen

This command generates the csr for the unit name.

```
set csr gen name
```

Syntax Description	Parameters	Description
	<i>name</i>	Specifies the unit on which the certificate is generated.

**Command Modes** Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set csr gen tomcat
Successfully Generated CSR for tomcat.
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set cuc jetty stderrlog

This command enables or disables the error log getting generated while any standard error occurs during communicating with the Jetty server. This error log gets generated and is available at the path `/var/log/active/jetty/`.

**set cuc jetty stderrlog** {enable | disable}

Syntax Description	Parameters	Description
	<b>enable</b>	Enables the error log on the Jetty server. Be aware that enable is case sensitive.
	<b>disable</b>	Disables the error log on the Jetty server. Be aware that disable is case sensitive.

**Command Modes** Administrator (admin:)

**Usage Guidelines**

**Caution** You must restart the Jetty services after enabling or disabling the error log on the Jetty server.

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Cisco Unity Connection only.

**Enable Error Log on Jetty Server Example**

```
admin:set cuc jetty stderrlog enable
```

```
Command is executed successfully
To effect changes restart jetty server
Restart Jetty Server through Unity Connection Serviciabilty .
```

Go to Tools -> Service Management -> Restart Connection Jetty Service.  
 Check the logs that should not be generated after running above command.  
 Check the requestlog by sending one voice message through webinbox.  
 Notifications should not come in logs

## set cuc jetty stdoutlog

This command enables or disables the standard input and output log getting generated while communicating with Jetty server. This standard input and output log gets generated and is available at the path `/var/log/active/jetty/`.

**set cuc jetty stdoutlog** {enable | disable}

Syntax Description	Parameters	Description
	<b>enable</b>	Enables the standard input and output log on the Jetty server. Be aware that enable is case sensitive.
	<b>disable</b>	Disables the standard input and output log on the Jetty server. Be aware that disable is case sensitive.

### Command Modes

Administrator (admin:)

### Usage Guidelines



**Caution** You must restart the Jetty services after enabling or disabling the standard input and output log on the Jetty server.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Cisco Unity Connection only.

### Enable Standard Input and Output Log on Jetty Server Example

```
admin:set cuc jetty stdoutlog enable
```

Command is executed successfully  
 To effect changes restart jetty server  
 Restart Jetty Server through Unity Connection Servicibility .  
 Go to Tools -> Service Management -> Restart Connection Jetty Service.  
 Check the logs that should not be generated after running above command.  
 Check the requestlog by sending one voice message through webinbox.  
 Notifications should not come in logs



## set cuc jetty requestlog

This command enables or disables the request log getting generated from the Jetty server while any request is raised for notifications. This request log gets generated and is available at the path `/usr/local/jetty/logs/`.

**set cuc jetty requestlog** {enable | disable}

Syntax Description	Parameters	Description
	<b>enable</b>	Enables the request log on the Jetty server. Be aware that “enable” is case sensitive.
	<b>disable</b>	Disables the request log on the Jetty server. Be aware that “disable” is case sensitive.

**Command Modes** Administrator (admin:)

### Usage Guidelines



**Caution** You must restart the Jetty services after enabling or disabling the request log on the Jetty server.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Cisco Unity Connection only.

### Enable Request Log on Jetty Server Example

```
admin:set cuc jetty requestlog enable
```

Command is executed successfully

To effect changes restart jetty server

Restart Jetty Server through Unity Connection Servicability .

Go to Tools -> Service Management -> Restart Connection Jetty Service.

Check the logs that should not be generated after running above command.

Check the requestlog by sending one voice message through webinbox.

Notifications should not come in logs

## set cuc speechview registration certificate size

This command sets up new certificate bit size for Speech to Text service registration and Voicemail transcription with Nuance server.

**set cuc speechview registration certificate size bit\_size**

Syntax Description	Parameters	Description
	<b>bit_size</b>	Specifies the bit_size of certificate. Its allowed values are 1k, 2k or 4k.

**Command Modes** Administrator (admin:)

**Usage Guidelines** To set the desired certificate bit size, use the **set cuc speechview registration certificate size** (Cisco Unity Connection Only) command. The CLI must be executed on the publisher. It will restart the Connection SpeechView Processor service.

**Requirements**

Command privilege level: 4

## set cuc srsv timeout

This command sets the value for SRSV session timeout.

**set cuc srsv timeout** *timeout\_value*

Syntax Description	Parameters	Description
	<i>timeout_value</i>	Sets the time for session logout.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

## set cuc trace

This command enables or disables the specified traces and trace levels.

**set cuc trace** {**enable** | **disable**} *trace\_name level*

Syntax Description	Parameters	Description
	<b>enable</b>	Enables Connection traces.
	<b>disable</b>	Disables Connection traces.
	<i>trace_name</i>	Specifies the name of the trace to enable or disable. Be aware that trace names are case sensitive.

Parameters	Description
<i>level</i>	Specifies the level or levels of trace_name that you want to enable or disable. Each trace comprises up to 31 levels, numbered 0 to 30; each level provides a different type of information for the specified trace. When you enable or disable multiple levels, use a comma to separate levels and a hyphen to indicate a range of levels. Do not include spaces.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

To display a list of the traces and trace levels that are currently enabled, use the **show cuc trace levels** (Cisco Unity Connection Only) command.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection only.

**Enable VUI Traces 1, 13, and 17 Through 20 Example**

```
admin:set cuc trace enable VUI 1,13,17-20
VUI trace levels are now set to: 1,13,17-20
```

**Disable VUI Traces 17 Through 20 While VUI Trace Levels 1 and 13 Remain Set Example**

```
admin:set cuc trace disable VUI 17-20
VUI trace levels are now set to: 1,13
```

**Related Topics**

[show cuc trace levels](#), on page 160

# set date

This command changes the time and date on the server.

**set date** *HH:mm:ss:MM/DD/YY*

**Syntax Description**

Parameters	Description
<i>HH:mm:ss</i>	Represents the time format (24 hours format).
<i>MM/DD/YY</i>	Represents the date format.
<b>Note</b>	Date format MM/DD/YYYY is also accepted.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

If the server is configured to synchronize with external NTP servers, this command requires the user to remove all of those NTP servers.

**Requirements**

Applies to: Unified Communications Manager and Cisco Unity Connection.

**Set Date and Time to 2:10:33 Pm April 13th 2012 Example**

```
admin:set date 14:10:33:04/13/12
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set dscp defaults

This command sets the factory default DSCP settings for all of the port tags.

**set dscp defaults****Command Modes**

Administrator (admin:)

**Usage Guidelines**

All non-default DSCP settings get removed after you run this command.

You can use the command `show dscp defaults` to see the factory default DSCP settings.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set dscp

This command enables or disables DSCP marking on outgoing TCP or UDP packets. You can enable or disable DSCP on a single port tag, or on all port tags at once.

```
set dscp {enable | disable} {allport_tag}
```

**Syntax Description****Parameters Description**

Parameters	Description
<b>all</b>	Disables all DSCP port tags.

Parameters	Description
<i>port_tag</i>	Represents a DSCP port tag, which is a string that is mapped to a TCP or UDP port to identify the application that uses the port. This value is for the portTag field displayed when you use the command <b>show dscp defaults</b> . The set of port tags is predefined.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set dscp marking

This command sets DSCP markings on port tags by using well-known DSCP classes and numeric values.

**set dscp marking** *port\_tag value***Syntax Description**

Parameters	Description
<i>port_tag</i>	Represents a DSCP port tag, which is a string that is mapped to a TCP or UDP port to identify the application that uses the port. This value is for the portTag field displayed when you use the command <b>show dscp defaults</b> . The set of port tags is predefined.
<i>value</i>	A DSCP value. You can enter the name of a well-known DSCP class or a numeric value in decimal or hexadecimal format. Precede hexadecimal values with 0x or 0X.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

The valid class names as defined by DSCP are:

- Class Selector: values CS0, CS1, CS2, CS3, CS5, CS6, CS7

The class selector (CS) values correspond to IP Precedence values and are fully compatible with IP Precedence.

- Expedited Forwarding: value EF

EF PHB is ideally suited for applications such as VoIP that require low bandwidth, guaranteed bandwidth, low delay, and low jitter.

- Best Effort: value BE

Also called default PHB, this value essentially specifies that a packet be marked with 0x00, which gets the traditional best-effort service from the network router.

- Assured Forwarding: values AF11, AF12, AF13, AF21, AF22, AF23, AF41, AF42, AF43

There are four types of Assured Forwarding classes, each of which has three drop precedence values.

These precedence values define the order in which a packet is dropped (if needed) due to network congestion. For example, packets in AF13 class are dropped before packets in the AF12 class.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set ipsec policy\_group

This command enables ipsec policies with the specified policy group name.

**set ipsec policy\_group** {**ALL***group*}

Syntax Description	Parameters	Description
	<b>ALL</b>	Enables all ipsec policy groups.
	<i>group</i>	Specifies the name of a particular ipsec policy group to enable.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager and Cisco Unity Connection.

## set ipsec policy\_name

This command enables the specified IPsec policy.

**set ipsec policy\_name** { *policy\_group* *policy\_name* }

Syntax Description	Parameters	Description
	<i>policy_group</i>	Specifies the name of a particular ipsec policy group to enable.
	<i>policy_name</i>	Specifies the name of a particular ipsec policy to enable.

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager and Cisco Unity Connection.

## set key regen authz encryption

Run this command on the Unified Communications Manager publisher node to regenerate the symmetric encryption key that encrypts OAuth access tokens and refresh tokens that are used in Cisco Jabber authentication.

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager and the IM and Presence Service.

## set key regen authz signing

Run this command on the Unified Communications Manager publisher node to regenerate the asymmetric RSA key pair for signing the OAuth access tokens and refresh tokens that are used in Cisco Jabber authentication.

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** **Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager and the IM and Presence Service.

## set logging

This command allows you to enable or disable CLI Admin logs.

**set logging** {enable | disable}

---

**Syntax Description**

Parameters	Description
enable	Turns on logging.

Parameters	Description
<b>disable</b>	Turns off logging.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set Login Grace Timeout

This command allows you to configure the LoginGraceTimeout value to the mentioned value.

**set Login Grace Timeout** *LoginGraceTimeout value*

**Syntax Description**

Parameters	Description
<i>LoginGraceTimeout value</i>	Sets the LoginGraceTimeout value for login grace timeout.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network cluster publisher

This command sets the network cluster publisher hostname and IP address.

**set network cluster publisher** {hostname | ip} *name*

**Syntax Description**

Parameters	Description
<b>hostname</b>	Specifies the hostname of the network cluster.
<b>ip</b>	Specifies the ip address of the network cluster.



Parameters	Description
<i>name</i>	Hostname or IP address to assign to the network cluster publisher.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network cluster subscriber details

Use this command to add subscriber to the processnode or appserver table when Tomcat Webserver is server down and GUI is inaccessible.

**set network cluster subscriber details** *servertype hostname ip domainname*

**Syntax Description**

Parameter	Description
<i>servertype</i>	Choose one of these products for this parameter— Unified Communications Manager, IM and Presence Service, and Cisco Unity Connection. This field is mandatory.
<i>hostname</i>	The hostname of the node that you add to the cluster. The hostname is supported on the same domain. This field is mandatory.
<i>ip</i>	The IPv4 address of the node that you add to the cluster. This field is mandatory for IM and Presence publisher and Cisco Unity Connection.
<i>domainname</i>	The domain name of the IM and Presence Service publisher. This field is mandatory for IM and Presence publisher.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to Unified Communications Manager, IM and Presence Service, and Cisco Unity Connection

## set network cluster subscriber dynamic-cluster-configuration

Use this command to enable the Dynamic Cluster Configuration on the publisher. Use this command to specify the duration in which you can add subscriber nodes to the publisher server table. The addition of subscriber nodes is authenticated immediately and those nodes need not wait for the publisher details during the installation of the subscriber nodes.

**set network cluster subscriber dynamic-cluster-configuration** {**default** | **no. of hours**}

Syntax Description	Parameter	Description
	<b>default</b>	Enables the Dynamic Cluster Configuration for 24 hours.
	<b>no. of hours</b>	Specifies a value from 1 to 24 hours.

**Command Modes** Administrator (admin)

### Requirements

Applies to Unified Communications Manager, IM and Presence Service, and Cisco Unity Connection

## set network dhcp eth0

This command enables or disables DHCP for Ethernet interface 0. You cannot configure Ethernet interface 1.

**set network dhcp eth0** {**enable** | **disable**} {*node\_ip* *net\_mask* *gateway\_ip*}

Syntax Description	Parameters	Description
	<b>eth0</b>	Specifies Ethernet interface 0.
	<b>enable</b>	This enables DHCP.
	<b>disable</b>	This disables DHCP.
	<i>node_ip</i>	Represents the static IP address for the server.
	<i>net_mask</i>	Represents the subnet mask for the server.
	<i>gateway_ip</i>	Represents the IP address of the default gateway.

**Command Modes** Administrator (admin:)

## Usage Guidelines



**Caution** If you continue, this command causes the system to restart. We also recommend that you restart all nodes whenever any IP address gets changed.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network dns

This command sets the IP address for the primary or secondary DNS server.

```
set network dns {primary | secondary} addr
```

Syntax Description	Parameters	Description
	<b>primary</b>	
	<b>secondary</b>	
	<i>addr</i>	Represents the IP address of the primary or secondary DNS server.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.



**Note** If you change the IP address for the DNS servers, you must reboot the server through the **utils system restart** CLI command.

## set network dns options

This command sets DNS options.

```
set network dns options [{timeoutseconds}] [{attemptsnumber}] [{rotate}]
```

---

**Syntax Description**

Parameters	Description
<b>timeout</b>	Sets the DNS timeout.
<b>attempts</b>	Sets the number of times to attempt a DNS request.
<b>rotate</b>	Causes the system to rotate among the configured DNS servers and distribute the load.
<i>seconds</i>	Specifies the DNS timeout period in seconds.
<i>number</i>	Specifies the number of attempts.

---

**Usage Guidelines**

Running this command causes an automatic system restart.

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network domain

This command sets the domain name for the system.




---

**Note** Changing the domain name triggers an automatic regeneration of all Unified Communications Manager certificates, including any third party signed certificates that have been uploaded. After the server reboots automatically, phones running in secure (mixed) mode cannot connect to the server until after the CTL client updates the new CTL file to the phones.




---

**Note** Reboot the servers one at a time in order for the phones to register correctly. For more information about changing the domain name, see *Changing the IP Address and Hostname for Cisco Unified Communications Manager*.

```
set network domain [domain-name]
```

---

**Syntax Description**

Parameters	Description
<i>domain_name</i>	Represents the system domain that you want to assign.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes a temporary loss of network connectivity.

If you use the **set network domain** *domain-name* command to change the domain name, you must manually regenerate all of your security certificates in Cisco Unified Operating System Administration. The list of certificates depends on your software release but may include cup.pem, cup-xmpp.pem, cup-xmpp-s2s.pem, tomcat, ipsec and so on. Note that you must restart the tomcat service after the tomcat cert is regenerated and you can only restart this service using the CLI. For more information about regenerating security certificates, see the *Cisco Unified Communications Operating System Administration Guide* (on Cisco.com).

After you regenerate your security certificates, you must reboot all the servers in the cluster. This will ensure that database replication keeps working correctly. After the servers have rebooted, confirm that there are no issues reported on the Cisco Unified Reporting report for Database Replication. After you reboot the server, we recommend that you manually delete old certificates that have become disassociated by the domain name change. For every ICSA peer that exists on the local node, you must either update the ICSA entry for the peer node with the new FQDN hostname, or delete that entry and add a new ICSA peer entry with the new FQDN hostname.

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network failover

This command enables and disables Network Fault Tolerance on the Media Convergence Server network interface card.

**set network failover** {**ena** | **dis**}

Syntax Description	Parameters	Description
	<b>ena</b>	Enables Network Fault Tolerance.
	<b>dis</b>	Disables Network Fault Tolerance.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network gateway

This command enables you to configure the IP address of the network gateway.

**set network gateway** *addr*

Syntax Description	Parameters	Description
	<i>addr</i>	Represents the IP address of the network gateway that you want to assign.
<b>Command Modes</b>	Administrator (admin:)	
<b>Usage Guidelines</b>	The system asks whether you want to continue to execute this command.	



**Caution** If you continue, this command causes the system to restart.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network hostname

This command allows an administrator to set the network host name, change the IP address of the node, and restart the system.

Before attempting this command, the administrator should have a valid DRF backup. Additionally, before attempting a Hostname (or Hostname and IP address) change, the administrator should perform the following:

- verify the cluster configuration does not have any configuration problems by executing **show hcs cluster verify detailed**
- update the cluster configuration by executing **set hcs cluster config**
- validate the cluster configuration by executing **show hcs cluster verify detailed**

**set network hostname** *hostname*

Syntax Description	Parameters	Description
	<i>hostname</i>	Represents the new network hostname of the system.
	<b>Note</b>	The host name must follow the rules for ARPANET host names. It must start with an alphabetic character, end with an alphanumeric character, and consist of alphanumeric characters and hyphens. The host name can have a maximum length of 63 characters.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes the system to restart.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set network hostname
```

```
WARNING: Changing this setting will invalidate software license
on this server. The license will have to be re-hosted.
```

```
Continue(y/n):
```

```
Continue (y/n)?y
```

```
ctrl-c: To quit the input.
```

```
*** W A R N I N G ***
```

```
Do not close this window without first canceling the command.
```

```
This command will automatically restart system services.
The command should not be issued during normal operating
hours.
```

```
=====  
Note: Please verify that the new hostname is a unique  
name across the cluster and, if DNS services are  
utilized, any DNS configuration is completed  
before proceeding.  
=====
```

```
Security Warning : This operation will regenerate  
all CUCM Certificates including any third party  
signed Certificates that have been uploaded.
```

```
Enter the hostname:: app-lfwelty5
```

```
Would you like to change the network ip address at this time [yes]::
```

```
Warning: Do not close this window until command finishes.
```

```
ctrl-c: To quit the input.
```

```
***  W A R N I N G  ***
```

```
=====
Note: Please verify that the new ip address is unique
      across the cluster.
```

```
Note: Changing the IP address will automatically restart
      system services cluster wide.
```

```
Note: The command should not be issued during normal operating hours.
```




---

**Note** The administrator can change both the hostname and IP address by responding **yes**. To change just the hostname, respond **no**.

---

## set network ip eth0

This command sets the IP address for Ethernet interface 0. You cannot configure Ethernet interface 1.

Before attempting this command, the administrator should have a valid DRF backup. Also, before attempting an IP address change, the administrator should perform the following:

- verify that the cluster configuration does not have any configuration problems by executing **show hcs cluster verify detailed**
- update the cluster configuration by executing **set hcs cluster config**
- validate the cluster configuration by executing **show hcs cluster verify detailed**

```
set network ip eth0 addr mask gw
```

Syntax Description	Parameters	Description
	<b>eth0</b>	Specifies Ethernet interface 0.
	<i>addr</i>	Represents the IP address that you want to assign.
	<i>mask</i>	Represents the IP mask that you want to assign.
	<i>gw</i>	Represents the IP default GW that you want to assign.

**Command Modes** Administrator (admin:)



**Usage Guidelines**

The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command restarts the following services:

- NIC driver
- NTP
- CLM
- Service Manager

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set network ip eth0
.....

***  W A R N I N G  ***
=====
Note: Please verify that the new ip address is unique across the cluster
and, if DNS services are utilized, any DNS configuration is
completed before proceeding.
Note: Changing the IP address will automatically restart
system services cluster wide.
Note: The command should not be issued during normal operating hours.
=====
```

## set network ipv6 dhcp

This command sets the DHCPv6 client on the server and enables IPv6 support. For changes to take effect, you must restart the server.

```
set network ipv6 dhcp {enable | disable} [reboot]
```

**Syntax Description**

Parameters	Description
<b>dhcp</b>	Sets the DHCPv6 client on the server. By default, the server does not restart after you enable the DHCPv6 client. For your changes to take effect, you must restart the server by either entering the reboot parameter or manually restarting the server.
<b>enable</b>	Enables IPv6 support.

Parameters	Description
<b>disable</b>	Disables IPv6 support.
<b>reboot</b>	(Optional) Causes the server to automatically restart after you enter the command.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network ipv6 gateway

This command sets the IPv6 gateway for the server. For changes to take effect, you must restart the server.

**set network ipv6 gateway** *addr* [**reboot**]

**Syntax Description**

Parameters	Description
<b>gateway</b>	Sets the IPv6 gateway for the server. By default, the server does not restart after you set the IPv6 gateway for the server. For your changes to take effect, you must restart the server by either entering the reboot parameter or manually restarting the server.
<i>addr</i>	The IPv6 gateway address.
<b>reboot</b>	(Optional) Causes the server to automatically restart after you enter the command.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager , IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.



**Note** IPv6 is not supported in Cisco Business Edition 5000.

## set network ipv6 service

This command enables or disables the IPv6 service on the server. For changes to take effect, you must restart the server.

```
set network ipv6 service {enable | disable} [reboot]
```

Syntax Description	Parameters	Description
	<b>service</b>	Sets the IPv6 service on the server. By default, the server does not restart after you enable or disable the IPv6 service on the server. For your changes to take effect, you must restart the server by either entering the reboot parameter or manually restarting the server.
	<i>enable</i>	Enables IPv6 service on the server.
	<i>disable</i>	Disables IPv6 service on the server.
	<b>reboot</b>	(Optional) Causes the server to automatically restart after you enter the command.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.



**Note** IPv6 is not supported in Cisco Business Edition 5000.

## set network ipv6 static\_address

This command assigns the static IPv6 address to the server. For changes to take effect, you must restart the server.

```
set network ipv6 static_address addr mask [reboot]
```

Syntax Description	Parameters	Description
	<b>static_address</b>	Assigns a static IPv6 address to the server. By default, the server does not restart after you assign the static IPv6 address. For your changes to take effect, you must restart the server by either entering the reboot parameter or manually restarting the server.
	<i>addr</i>	Specifies the static IPv6 address you assign to the server.
	<i>mask</i>	Specifies the IPv6 network mask (0-128).

Parameters	Description
<b>reboot</b>	(Optional) Causes the server to automatically restart after you enter the command.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network max\_ip\_contrack

This command sets the ip\_contrack\_max value.

**set network max\_ip\_contrack** *ip\_contrack\_max value*

**Syntax Description**

Parameters	Description
<i>ip_contrack_max value</i>	Specifies the value for ip_contrack_max.
<b>Note</b>	The value of ip_contrack_max cannot be less than 65536.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set network max_ip_contrack 65536
```

## set network mtu

This command sets the maximum MTU value.

**set network mtu** *mtu\_max*

Syntax Description	Parameters	Description
	<i>mtu_max</i>	Specifies the maximum MTU value. The system default MTU value equals 1500.
	<b>Caution</b>	When packets on UDP port 8500 that have the DF bit set are exchanged between nodes, if there is any policy on the WAN router to clear the DF bit and fragment large packets, this may cause dbreplication issues.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system loses network connectivity temporarily.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set network mtu 576      W A R N I N G
This will cause the system to temporarily lose network connectivity
Do you want to continue ?
Enter "yes" to continue or any other key to abort
yes
executing...
```

## set network name-service hosts cache-enable

This command enables the nsd related cache.

**set network name-service hosts cache-enable** *value*

Syntax Description	Parameters	Description
	<i>value</i>	The boolean value must be either <i>yes</i> or <i>no</i> .

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service hosts max-db-size

This command sets the maximum allowed size for a service.

**set network name-service hosts max-db-size** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter the number of bytes for the database size.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service hosts negative-time-to-live

This command sets the time-to-live (TTL) for negative entries or unsuccessful queries in the specified cache for service. So, using this command improves the performance if there are various files owned by user IDs (UIDs) and are unavailable in system databases. For example, files that are available in the Linux kernel sources as root. To reduce the cache coherency problems, the number of such files should be kept to the minimum.

**set network name-service hosts negative-time-to-live** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter the number of seconds.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service hosts persistent

This command retains the content of the cache for service over server restarts. This command is useful when *paranoia* mode is configured.

**set network name-service hosts persistent** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter a value for a service.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service hosts positive-time-to-live

This command sets the time-to-live (TTL) for positive entries or successful queries in the specified cache for service. Configure the value in seconds. Larger values increase cache hit rates and reduce mean response times. However, such values increase problems with cache coherence.

**set network name-service hosts positive-time-to-live** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter the number of seconds.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service hosts suggested-size

This command changes the internal hash table size.

**set network name-service hosts suggested-size** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter a prime number for optimum efficiency.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service services cache-enable

This command enables the nscd related cache.

**set network name-service services cache-enable** *value*

Syntax Description	Parameters	Description
	<i>value</i>	The boolean value must be either <i>yes</i> or <i>no</i> .

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service services max-db-size

This command sets the maximum allowed size for the service.

**set network name-service services max-db-size** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter the value in number of bytes.

**Command Modes** Administrator (admin:)



**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service services negative-time-to-live

This command sets the time-to-live (TTL) for negative entries or unsuccessful queries in the specified cache for service. So, using this command improves the performance if there are various files owned by user IDs (UIDs) and are unavailable in system databases. For example, files that are available in the Linux kernel sources as root. To reduce the cache coherency problems, the number of such files should be kept to the minimum.

**set network name-service services negative-time-to-live** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter a prime number for optimum efficiency.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service services persistent

This command retains the content of the cache for service over server restarts. This command is useful when *paranoia* mode is configured.

**set network name-service services persistent** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter a value for a service.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service services positive-time-to-live

This command sets the time-to-live (TTL) for positive entries or successful queries in the specified cache for service. If you enter a large value for this command, it increases cache hit rates and reduces mean response times. However, a large value increases issues with cache coherence.

**set network name-service services positive-time-to-live** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter the number of seconds.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service services suggested-size

This command sets the internal hash table size.

**set network name-service services suggested-size** *value*

Syntax Description	Parameters	Description
	<i>value</i>	Enter a prime number for optimum efficiency.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network nic eth0

This command sets the properties of the Ethernet Interface 0. You cannot configure Ethernet interface 1.

```
set network nic eth0 {auto | {en | dis}} {speed | {10 | 100}} {duplex half | {half | full}}
```

Syntax Description	Parameters	Description
	<b>eth0</b>	Specifies Ethernet interface 0.
	<b>auto</b>	Specifies whether auto negotiation gets enabled or disabled.
	<b>speed</b>	Specifies whether the speed of the Ethernet connection: 10 or 100 Mb/s.
	<b>duplex</b>	Specifies half-duplex or full-duplex.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Note** You can enable only one active NIC at a time.



**Caution** If you continue, this command causes a temporary loss of network connections while the NIC gets reset.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network ntp option

This command adds the *noquery* option to the `/etc/config` file.

```
set network ntp option
```

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network pmtud state

This command enables and disables Path MTU Discovery.

**set network pmtud state** {enable | disable}

**Syntax Description****Parameters Description**

**enable** Enables Path MTU Discovery.

**disable** Disables Path MTU Discovery.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system loses network connectivity temporarily.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set network pmtud state enable      W A R N I N G
This will cause the system to temporarily lose network connectivity
Do you want to continue ?
Enter "yes" to continue or any other key to abort
yes
executing...
```

## set network restore

This command configures the specified Ethernet port to use a specified static IP address.

**set network restore eth0** *ip-address network-mask gateway*

Syntax Description	Parameters	Description
	<b>eth0</b>	Specifies Ethernet interface 0.
	<i>ip-address</i>	Represents the IP address of the primary or secondary DNS server, or the network gateway that you want to assign. If you continue, this command causes a temporary loss of network connectivity. If you change the IP address for the primary DNS server, you must also restart the Cisco Tomcat service. For more information, see the <b>utils service</b> command. We also recommend that you restart all nodes whenever any IP address gets changed.
	<i>network-mask</i>	Represents the subnet mask for the server.
	<i>gateway</i>	Specifies the IP address of the default gateway.
	<i>ip-address</i>	Represents the IP address of the primary or secondary DNS server, or the network gateway that you want to assign. If you continue, this command causes a temporary loss of network connectivity. If you change the IP address for the primary DNS server, you must also restart the Cisco Tomcat service. For more information, see the <b>utils service</b> command. We also recommend that you restart all nodes whenever any IP address gets changed.

**Command Modes** Administrator (admin:)

### Usage Guidelines



**Caution** Only use this command option if you cannot restore network connectivity through any other set network commands. This command deletes all previous network settings for the specified network interface, including Network Fault Tolerance. After you run this command, you must restore your previous network configuration manually.



**Caution** The server temporarily loses network connectivity after you run this command.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:set network restore eth0 10.94.150.108 255.255.255.0 10.94.150.1
```

## set network status eth0

This command sets the status of Ethernet 0 to up or down. You cannot configure Ethernet interface 1.

```
set network status eth0 {up | down}
```

Syntax Description	Parameters	Description
	<b>eth0</b>	Specifies Ethernet interface 0.
	<b>up</b>	Sets the status of Ethernet interface 0 to up.
	<b>down</b>	Sets the status of Ethernet interface 0 to down.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system loses network connectivity temporarily.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set network name-service

This command displays name service cache attributes.

```
set network name-service [attribute] [value]
```

Syntax Description	Attribute	Value
	<b>Paranoia</b>	Bool must be either Yes or No. Enabling paranoia mode causes Name Service to restart itself periodically.
	<b>debug-level</b>	If level is higher than 0, Name Service will create some debug output. Higher the level, more verbose the output.
	<b>reload-count</b>	Sets the number of times a cached record is reloaded before it is pruned from the cache. Each cache record has a timeout. When that timeout expires Name Service will either reload it (query the NSS service again if the data hasn't changed) or drop it.

Attribute	Value
<b>restart-interval</b>	Sets the restart interval to time seconds if periodic restart is enabled by enabling paranoia mode. The default value is 3600.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set password complexity minimum-length

This command modifies the value of minimum password length for the OS administration accounts.



**Note** Use this command after you enable the character complexity of passwords.

```
set password complexity minimum-length max-repeat
```

**Syntax Description**

Parameters	Description
<i>value</i>	Enter a value of or greater than 6.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password age

This command modifies the value for password age, in days, for Cisco Collaboration Communication OS (C3OS) accounts.

```
set password age {maximum | minimum} days
```

**Syntax Description**

Parameters	Description
<b>maximum</b>	Specifies the maximum age.
<b>minimum</b>	Specifies the minimum age.

Parameters	Description
<i>days</i>	Specifies the maximum password age and must be greater-than or equal-to 90 days.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password change-at-login

Use this command to force new or existing users to change their password when they sign in to the system the next time.

```
set password change-at-login {disable | enable} userid
```

**Syntax Description**

Parameters	Description
<b>disable</b>	This does not force users to change their password.
<b>enable</b>	This forces users to change their password when they sign in to the system the next time.
<i>userid</i>	Specifies the affected user account.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

By default, this command is enabled for new users, so users have to change their password the first time they sign in to the system.

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: IM and Presence Service on Unified Communications Manager only.

## set password complexity character

Use this command to enable or disable password complexity rules for the type of characters in a password.





**Note** After you enable password complexity, this command also enables password history if it has not already been enabled (for more information, see the **set password history** command). If you had not previously enabled password history, the password history number parameter value gets set to 10. If you previously enabled password history with a value of less than 10, the value gets reset to 10 after you execute this command. If you previously enabled password history with a value of 10 or greater, the value remains unchanged after you execute this command.

**set password complexity character** {**disable** | **enable**} *num-char*

### Syntax Description

Parameters	Description
<b>disable</b>	This turns off password complexity for character types.
<b>enable</b>	This turns on password complexity for character types.
<b>Note</b>	When you disable password complexity, you also turn off <b>password character difference</b> , <b>password character max-repeat</b> , and <b>password history</b> .
<i>num-char</i>	This specifies the number of characters required from each of the four character sets: lowercase, uppercase, numbers, and special characters. <ul style="list-style-type: none"> <li>• Value range: 0-8</li> <li>• Default value: 1</li> </ul>

### Command Modes

Administrator (admin:)

### Usage Guidelines

When you enable password complexity, you must follow these guidelines when you assign a password:

- It must have at least the current setting, num-chars, of lower-case character.
- It must have at least the current setting, num-chars, of uppercase characters.
- It must have at least the current setting, num-chars, of digit characters.
- It must have at least the current setting, num-chars, of special characters.
- You cannot use adjacent characters on the keyboard; for example, qwerty.
- You cannot reuse any of the previous passwords that match the passwords retained by password history.
- By default, the admin user password can be changed only once in a 24-hour day.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password complexity character difference

This command specifies the number of characters that the character sequence in a new password must differ from the character sequence in the old password.

**set password complexity character difference** *num-char*

Syntax Description	Parameters	Description
	<i>num-char</i>	This specifies the number of characters that the character sequence in a new password must differ from the character sequence in the old password. <ul style="list-style-type: none"> <li>Value range: 0-31</li> </ul>

**Command Modes** Administrator (admin:)

**Usage Guidelines** Enter 0 to indicate no difference.



**Note** The maximum password length is 31 characters.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password complexity character max-repeat

This command specifies the number of times you can consecutively repeat a single character in a new password.

**set password complexity character max-repeat** *max-repeat*

Syntax Description	Parameters	Description
	<i>max-repeat</i>	This specifies the number of times you can consecutively repeat a single character in a new password. <ul style="list-style-type: none"> <li>Value range: 0 – 10</li> <li>Default value: 0</li> </ul>

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password expiry maximum-age

This command enables or disables the password expiry maximum age settings for Cisco Collaboration Communication OS (C3OS) Administrator accounts.

**set password expiry maximum-age** {enable | disable}

Syntax Description	Parameters	Description
	<b>enable</b>	Turns on password expiry maximum age settings for Cisco Unified Operating System administrator accounts. The set password expiry enable command sets the value of <b>maximum password age</b> to 3650 days (10 yrs) for Cisco Unified Operating System Administrator accounts.
	<b>disable</b>	Turns off password expiry maximum age settings for Cisco Unified Operating System administrator accounts. The set password expiry disable command results in Cisco Unified Operating System Administrator accounts never expiring.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set password expiry maximum-age disable
Operation Successful.
```

## set password expiry user maximum-age configure

This command modifies the value of the maximum password age for a particular Cisco Collaboration Communication OS Administration account in days.

**set password expiry user maximum-age configure** *userid maximum password age*

Syntax Description	Parameters	Description
	<i>userid</i>	Enter Cisco Collaboration Communication OS (C3OS) Administrator account.
	<i>maximum password age</i>	Enter the maximum password age in days. This value must be equal to or greater than 10 days but less than 3650 days (10 years).

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password expiry minimum-age

This command enables or disables the password expiry minimum age settings for Cisco Unified Operating System Administrator accounts.

**set password expiry minimum-age** {enable | disable}

Syntax Description	Parameters	Description
	<b>enable</b>	Turns on password expiry minimum age settings for Cisco Unified Operating System administrator accounts. The set password expiry enable command sets the value of minimum password age to one day (24 hrs) for Cisco Collaboration Communication OS (C3OS) Administrator accounts.

Parameters	Description
<b>disable</b>	Turns off password expiry minimum age settings for Cisco Collaboration Communication OS (C3OS) administrator accounts. This means that passwords for administrator accounts can be changed at any interval.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set password expiry minimum-age disable
Operation Successful.
```

## set password expiry user maximum-age

This command disables the maximum age password expiry for a particular Cisco Unified Operating System Administrator account.

```
set password expiry user maximum-age {enable | disable}userid
```

**Syntax Description**

Parameters	Description
<b>enable</b>	Turns on the maximum age password expiry settings for a particular Cisco Collaboration Communication OS (C3OS) administrator account. The set password expiry user enable command sets the value of maximum password age to 3650 days (10 yrs) for the Cisco Unified Operating System Administrator account.
<b>disable</b>	Turns on the maximum age password expiry settings for a particular Cisco Collaboration Communication OS (C3OS) administrator account. The set password expiry user enable command sets the value of maximum password age to 3650 days (10 yrs) for the Cisco Unified Operating System Administrator account.
<i>userid</i>	Specifies a particular Cisco Collaboration Communication OS (C3OS) Administrator account.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set password expiry user maximum-age enable
Operation Successful.
```

## set password expiry user minimum-age

This command enables or disables the maximum age password expiry for a particular Cisco Unified Operating System Administrator account.

```
set password expiry user minimum-age {enable | disable} userid
```

**Syntax Description**

Parameters	Description
<b>enable</b>	Turns on the minimum age password expiry settings for a particular Cisco Unified Operating System administrator account.
<b>disable</b>	Turns off the minimum age password expiry settings for a particular Cisco Unified Operating System administrator account.
<i>userid</i>	Specifies a particular Cisco Unified Operating System Administrator account.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Example**

```
admin:set password expiry user minimum-age disable
Operation Successful.
```

## set password history

This command modifies the number of passwords that get maintained in the history for OS admin accounts. New passwords matching remembered passwords get rejected.

**set password history** *number*

Syntax Description	Parameters	Description
	<i>number</i>	Specifies the mandatory number of passwords to maintain in history.

**Command Modes** Administrator (admin:)

- Usage Guidelines**
- To disable, enter 0.
  - Default specifies 10.
  - Upper limit specifies 20.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password inactivity

**set password inactivity** {**enable** | **disable** | **period**} *days*

Syntax Description	Parameters	Description
	<b>enable</b>	Enable the password inactivity globally and update individual OS users according to the setting.
	<b>disable</b>	Disable the password inactivity globally and update individual OS users according to the setting.
	<b>period</b>	Configure the password inactivity period globally and update individual OS users according to the setting.
	<i>days</i>	Specify the number of days of inactivity after a password has expired before the account gets disabled. Valid range is 1 - 99.

**Command Modes** Administrator (admin:)

- Usage Guidelines**
- To enable password inactivity globally, execute the set password inactivity enable command. This command enables the password inactivity globally and updates individual OS users according to the setting.

- To disable password inactivity globally, execute the `set password inactivity disable` command. This command disables the password inactivity globally and updates individual OS users according to the setting.

A user whose account is disabled must contact the system administrator to use the system again.

- To configure the password inactivity period execute the `set password inactivity period days` command. This command configures the password inactivity globally and updates individual OS users according to the setting.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password system bootloader encryptHash

Use this command to configure the encrypted password in the `grub.conf` file for the system boot loader.

### set password system bootloader encryptHash

#### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password user admin

This command allows you to change the administrator password.

### set password user admin

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

The systems prompts you for the old and new passwords.



#### Note

- You can change the password only for the administrator account that you logged in to.
- The password must contain at least six characters, and the system checks it for strength.



**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set password user security

This command allows you to change the security password.

**set password user security****Command Modes**

Administrator (admin:)

**Usage Guidelines**

The systems prompts you for the old and new passwords.



---

**Note** The password must contain at least six characters, and the system checks it for strength.

---

Servers in a cluster use the security password to authenticate communication between servers. You must reset the cluster after you change the security password.



---

**Note** We recommend that you restart each server after the password is changed on that server.

1. Change the security password on the publisher server (first node) and then reboot the server (node).
  2. Change the security password on all the subsequent servers and nodes to the same password that you created on the first node and restart subsequent nodes, including application servers, to propagate the password change.
- 



---

**Note** Failure to reboot the servers (nodes) causes system service problems and problems with the Cisco Collaboration Communication OS (C3OS) Administration windows on the subscriber servers.

---

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## Set replication-sync monitor

This command enables or disables replication monitoring by the Cisco Replication Watcher service. The Cisco Replication Watcher service blocks other services from starting until database replication is setup and functioning normally.

**set replication-sync monitor {enable | disable}**

Syntax Description	Parameters	Description
	<b>enable</b>	Turns on the replication monitoring service.
	<b>disable</b>	Turns off the replication monitoring service

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: IM and Presence Service on Unified Communications Manager only

## set samltrace level

This command sets the SAML trace level.

**set samltrace level** *trace level*

Syntax Description	Parameters	Description
	<i>trace level</i>	Specifies the trace level. The available options are: <ul style="list-style-type: none"> <li>• DEBUG</li> <li>• INFO</li> <li>• WARNING</li> <li>• ERROR</li> <li>• FATAL</li> </ul>

**Note** The default trace level is INFO.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set session maxlimit

This command sets the upper limit for concurrent sessions.

**set session maxlimit** [*value*]

Syntax Description	Parameters	Description
	<b>maxlimit</b>	This command sets the upper limit for concurrent sessions. Acceptable values are 1 - 10. If no upper limit is entered, the default value of 10 is assigned to <code>sshd_config</code> param.
	<i>value</i>	Acceptable values are 1 - 10.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set smtp

This command sets the SMTP server hostname.

**set smtp** *hostname*

Syntax Description	Parameters	Description
	<i>hostname</i>	Represents the SMTP server name.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set strace enable

This command enables the service trace and sets the trace level.

**set strace enable** [*all*]*tracevalue servicename*

Syntax Description	Parameters	Description
	<i>all</i>	Optional parameter to propagate the service trace settings change to all nodes.
	<i>tracevalue</i>	Represents allowed trace values. Allowed trace values are [Info Debug Warn Error Fatal]
	<i>servicename</i>	Represents the service for which the trace is enabled.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## set strace disable

This command disables the service trace.

**set strace disable** [*all*] *servicename*

Syntax Description	Parameters	Description
	<i>all</i>	Optional parameter to propagate the service trace settings change to all nodes.
	<i>servicename</i>	Represents the service for which the trace is enabled.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## set timezone

This command lets you change the system timezone.

**set timezone** *zone*

Syntax Description	Parameters	Description
	<i>zone</i>	Specifies the new timezone. Enter the appropriate string or zone index id to uniquely identify the timezone. To view a list of valid timezones, use the CLI command: <b>show timezone list</b> .

**Command Modes** Administrator (admin:)

**Usage Guidelines** Enter characters to uniquely identify the new timezone. Be aware that the timezone name is case-sensitive.



**Note** Changing the system time zone to US time zone may require system compliance to FCC Call Routing Regulations in US. Unified Communications Manager Administrator must refer the Emergency Call Routing Regulations page and complete necessary configuration.



**Caution** You must restart the system after you change the timezone.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example Setting Timezone to Pacific Time

```
admin:set timezone Pac
```

## set tls min-version

This command sets the minimum version of Transport Layer Security (TLS) protocol.



- Note**
- After you set the minimum TLS version, the system reboots.
  - Configure the minimum TLS version for each node.

**set tls min-version** *tls minVersion*

Syntax Description	Parameters	Description
	<i>tls</i> <i>minVersion</i>	Type one of the following options to set it as the minimum TLS version: <ul style="list-style-type: none"> <li>• 1.0</li> <li>• 1.1</li> <li>• 1.2</li> </ul>

**Command Modes** Administrator (admin:)

### Usage Guidelines

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

#### Example

```
admin: set tls min-version 1.1
```

This command will result in setting minimum TLS version to 1.1 on all the secure interfaces. If you have custom applications that makes secure connection to the system, please ensure they support the TLS version you have chosen to configure.

Also, please refer to the Cisco Unified Reporting Administration Guide to ensure the endpoints in your deployment supports this feature.

```
*****
```

```
Warning: This will set the minimum TLS to 1.1 and the server will reboot.
```

```
*****
```

```
Do you want to continue (yes/no) ? yes
```

```
Successfully set minimum TLS version to 1.1
```

```
The system will reboot in few minutes.
```

## set trace disable

This command unsets trace activity for the specified task.

**set trace disable** *tname*

Syntax Description	Parameters	Description
	<b>disable</b>	Unsets the task trace settings.

Parameters	Description
<i>tname</i>	Represents the task for which you want to disable traces.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set trace enable

This command sets trace activity for the specified task.

**set trace enable** {**Arbitrary** | **Detailed** | **Entry\_exit** | **Error** | **Significant** | **Special** | **State\_Transition**}  
*tname*

**Syntax Description**

Parameters	Description
<b>Arbitrary</b>	Sets task trace settings to the arbitrary level.
<b>Detailed</b>	Sets task trace settings to the detailed level.
<b>Entry_exit</b>	Sets task trace settings to the entry_exit level.
<b>Error</b>	Sets task trace settings to the error level.
<b>Significant</b>	Sets task trace settings to the significant level.
<b>Special</b>	Sets task trace settings to the special level.
<b>State_transition</b>	Sets task trace settings to the state transition level.
<i>tname</i>	Represents the task for which you want to disable traces.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set tlsresumptiontimeout

This command sets the number of seconds after which TLS resumption will not work and sessions are invalidated.

**set tlsresumptiontimeout** *seconds*

### Syntax Description

Parameters	Description
<i>seconds</i>	Enter a value up to 3600 seconds. The TLS sessions are invalid after the configured value.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set tlstrace\*

Unified Communications Manager Release 11.0 onwards, you can enable or disable TLS tracing for services. Currently, Tomcat is the only supported service. Use the CLI commands to view the reasons of connection failure of TLS connections to Unified Communications Manager.

Following TLS-based CLI commands are added for TLS tracing:

## set tlstrace disable

This CLI command disables the TLS tracing for a service.

**set tlstrace disable** *service*

### Syntax Description

Parameters	Description
<i>service</i>	Specifies the service that you use to disable TLS tracing.

### Command Modes

Administrator (admin:)

#### Example

```
admin:set tlstrace disable tomcat
TLS tracing is disabled for: tomcat
```



**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set tlstrace enable**

This CLI command enables the TLS tracing for a service.

**set tlstrace enable** *service*

Syntax Description	Parameters	Description
	<i>service</i>	Specifies the service that you use to enable TLS tracing.

**Command Modes** Administrator (admin:)

**Example**

```
admin:set tlstrace enable tomcat
TLS tracing is enabled for: tomcat
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set web-security**

This command sets the web security certificate information for the operating system.

**set web-security** *orgunit orgname locality state [country] [alternatehostname]*

Syntax Description	Parameters	Description
	<i>orgunit</i>	Represents the organizational unit (OU) name.  You can use this command to enter multiple organizational units. To enter more than one organizational unit name, separate the entries with a comma. For entries that already contain a comma, enter a backslash before the comma that is included as part of the entry. To enter multiple values for organizational unit, enclose them in quotation marks, as shown in the example for this command.  <b>Note</b> For OU's that already contains a backslash, do not enter one more backslash as SLM registration and CSR generation fails during the time of installation.
	<i>orgname</i>	Represents the organizational name.
	<i>locality</i>	Represents the organization location.

Parameters	Description
<i>state</i>	Represents the organization state.
<i>country</i>	(Optional) Represents the organization country.
<i>alternatehostname</i>	(Optional) Specifies an alternate name for the host when you generate a web-server (Tomcat) certificate.  You can use <i>alternatehostname</i> to set subject alternate hostname for self signed certificates. Subject alternate hostname for CSR is defined in the Certificate Management page. If you have set the alternate hostname for CSR using this command, the CSR generation process replaces the set alternate hostname.



**Note** The set web-security command when adding in the alternate hostname will apply and will be added to all future generated CSR's including, Tomcat, CallManager, CAPF, TVS, and IPsec.

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

In case you are planning to rebuild the Unified CM server, ensure that you should use the same OU subject parameters. Else, this will create discrepancies when you execute the command **show web-security**. This is because the platformConfig.xml file will not have the saved parameters information provided before the rebuild as this file is not backed up during DRS backup.

#### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

#### Example

This example shows the web-security command with multiple organizational unit names using comma separators. The certificate has three OU fields:

- OU=accounting
- OU=personnel, CA
- OU=personnel, MA

```
admin:set web-security "accounting,personnel\,CA,personnel\,MA" Cisco Milpitas
CA
set web-security "Voice\Video" "Cisco" "RTP" NC
```

## set webapp session timeout

This command sets the time, in minutes, that can elapse before a web application, such as Unified Communications Manager Administration, times out and logs off the user.

For the new webapp session timeout setting to become effective, you must restart the Cisco Tomcat service. Until you restart the Cisco Tomcat service, the **show webapp session timeout** command reflects the new values, but system continues to use and reflect the old values. This command prompts you to restart the service.



**Caution** Restarting the Cisco Tomcat service ends all active sessions and can affect system performance. Cisco recommends that you only execute this command during off-peak traffic hours.



**Note** This setting gets preserved through a software upgrade and does not get reset to the default value.

**set webapp session timeout** *minutes*

### Syntax Description

#### Parameters Description

Parameters	Description
<i>minutes</i>	Specifies the time, in minutes, that can elapse before a web application times out and logs off the user. <ul style="list-style-type: none"> <li>• Value range: 5-99999 minutes</li> <li>• Default value: 30 minutes</li> </ul>

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## set webapp session maxlimit

This command sets the maximum limit for concurrent web application sessions per user. This applies to the following interfaces:

- Cisco Unified CM Administration
- Cisco Unified Serviceability
- Cisco Unified Reporting

- Cisco Unified Communications Self Care Portal
- Cisco Unified CM IM and Presence Administration
- Cisco Unified IM and Presence Serviceability
- Cisco Unified IM and Presence Reporting

For the session maximum limit setting to become effective, the administrator must restart the Cisco Tomcat service.



**Caution** Restarting the Cisco Tomcat service ends all active sessions and can affect the system performance. Cisco recommends that you only execute this command during off-peak traffic hours.



**Note** This setting gets preserved through a software upgrade and does not get reset to the default value.

**set webapp session maxlimit** *number*

#### Syntax Description

Parameters	Description
<i>number</i>	Specifies the number to limit the concurrent web application sessions. The value ranges from 1 to 10. Default value is 10.  If the <b>utils EnhancedSecurityMode</b> is enabled, then the session limit is restricted to 3. For more details on how to Configure Enhanced Security Mode, see the “FIPS 140-2 Mode Setup” chapter in the <i>Security Guide for Cisco Unified Communications Manager, Release 11.5(1)SUI</i> at <a href="https://www.cisco.com/c/en/us/support/unified-communications/unified-communications-manager-callmanager/products-maintenance-guides-list.html">https://www.cisco.com/c/en/us/support/unified-communications/unified-communications-manager-callmanager/products-maintenance-guides-list.html</a> .
<b>Note</b>	<ul style="list-style-type: none"> <li>• When you exceed the defined sign-in sessions maximum limit, then the interface sign-in page displays the Logon Status message as: The Session limit has already been reached for &lt;username&gt;. Please logout from those sessions or wait 30 minutes for inactive sessions to be automatically closed.</li> <li>• When Enhanced Security Mode is enabled, then the session limit is restricted to 3. However, Administrator can change the session limit using the <b>set webapp session maxlimit</b> command to any value ranging from 1 to 10.</li> </ul>






#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, Unified Communications Manager IM and Presence Service and Cisco Unity Connection.

### Example

This example details on how to **set webapp session maxlimit** to 4:

```
admin:set webapp session maxlimit 4

*****W A R N I N G*****
The Cisco Tomcat service needs to be restarted for the changes to take effect.This will
disconnect active web sessions and all web applications on this node will be unavailable
until the service restarts.This service restart will take several minutes to complete.
Do you want to continue (yes/no) ? yes

*****Restarting Tomcat*****
Service Manager is running
Cisco Tomcat[STOPPING]
Cisco Tomcat[STOPPING]
Cisco Tomcat[STOPPING]
Cisco Tomcat[STOPPING]
Cisco Tomcat[STARTING]
Cisco Tomcat[STARTING]
Cisco Tomcat[STARTED]
The webapp session limit has been successfully set to 4.
```

This example details on how to enable **utils EnhancedSecurityMode**:

```
admin:utils EnhancedSecurityMode enable

The system is operating in NON-FIPS and NOT operating in Enhanced Security Mode.

Enhanced Security Mode can be enabled only when the system is operating in FIPS mode
Do you wish to enable FIPS mode as well (yes/no) ? yes

Warning : This operation will modify the password policies

1>Password Length should be between 14 to 127 characters.
2>Password should have at least 1 lowercase, 1 uppercase, 1 digit and 1 special character.
3)Any of the previous 24 passwords cannot be reused.
4)Minimum age of the password is 1 day and Maximum age of the password is 60 days.
5)Any newly generated password's character sequence will need to differ by at least 4
characters from the old password's character sequence.

Warning : This mode will limit the total number of concurrent web application sessions to
3.

*****
This will change the system to Enhanced Security Mode and will reboot
*****
Do you want to continue (yes/no) ? yes
The protocol for communication with remote syslog server is already set to tcp. No changes
required.

The system is already operating in contact search authentication enable mode; no change
required. Exiting.

The concurrent web application session limit has been successfully set to 3.

Setting password restrictions as part of Enhanced Security Mode enable

Calling fips enable
```

Security Warning : The operation will regenerate certificates for

- 1) CallManager
- 2) Tomcat
- 3) IPsec
- 4) TVS
- 5) CAPF
- 6) SSH
- 7) ITLRecovery

Any third party CA signed certificates that have been uploaded for the above components will need to be re-uploaded.

If the system is operating in mixed mode, then the CTL client needs to be run again to update the CTL file.

If there are other servers in the cluster, please wait and do not change the FIPS settings on any other node until the FIPS operation on this node is complete and the system is back up and running.

\*\*\*\*\*  
 This will change the system to FIPS mode and will reboot.  
 \*\*\*\*\*

## set workingdir

This command sets the working directory for active, inactive, and installation logs.

**set workingdir** {**activelog** | **inactivelog** | **tftp**} *directory*

### Syntax Description

#### Parameters Description

**activelog** Sets the working directory for active logs. Choose a valid sub-directory of activelog.

**inactivelog** Set the working directory for inactive logs. Choose a valid sub-directory of inactivelog.

**tftp** Sets the working directory for TFTP files.

*directory* Represents the current working directory.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.



## CHAPTER 7

# Show Commands

---

- [show account](#), on page 131
- [show accountlocking](#), on page 131
- [show cert default-ca-list](#), on page 132
- [show cert list](#), on page 133
- [show cert list type](#), on page 134
- [show cert own](#), on page 134
- [show cert trust](#), on page 135
- [show cli pagination](#), on page 135
- [show cli session timeout](#), on page 136
- [show csr list](#), on page 136
- [show csr list type](#), on page 137
- [show csr own](#), on page 137
- [show csr own name](#), on page 138
- [show ctl](#), on page 139
- [show cuc cluster status](#), on page 139
- [show cuc config groups](#), on page 139
- [show cuc config settings](#), on page 140
- [show cuc dbconsistency](#), on page 141
- [show cuc dbcontents](#), on page 142
- [show cuc dbschema](#), on page 143
- [show cuc dbserver disk](#), on page 144
- [show cuc dbserver session](#), on page 144
- [show cuc dbserver sessions all](#), on page 145
- [show cuc dbserver sessions list](#), on page 145
- [show cuc dbserver user list](#), on page 146
- [show cuc dbserver user waiting](#), on page 146
- [show cuc dbtable contents](#), on page 146
- [show cuc dbtable list](#), on page 147
- [show cuc dbtable schema](#), on page 148
- [show cuc dbview contents](#), on page 150
- [show cuc dbview list](#), on page 151
- [show cuc dbview schema](#), on page 152
- **[show cuc jetty ssl status](#)** , on page 153

- [show cuc locales](#), on page 153
- [show cuc speechview registration certificate size](#), on page 154
- [show cuc sysagent task list](#), on page 154
- [show cuc sysagent task results](#), on page 155
- [show cuc sysinfo](#), on page 156
- [show cuc tech dbschemaversion](#), on page 157
- [show cuc tech dbserver all](#), on page 158
- [show cuc tech dbserver integrity](#), on page 158
- [show cuc tech dbserver log diagnostic](#), on page 159
- [show cuc tech dbserver log message](#), on page 159
- [show cuc tech dbserver status](#), on page 160
- [show cuc trace levels](#), on page 160
- [show cuc version](#), on page 161
- [show date](#), on page 162
- [show diskusage](#), on page 162
- [show dscp all](#), on page 163
- [show dscp defaults](#), on page 163
- [show dscp marking](#), on page 163
- [show dscp status](#), on page 164
- [show environment fans](#), on page 165
- [show environment power-supply](#), on page 165
- [show environment temperatures](#), on page 165
- [show fileserver transferspeed](#), on page 166
- [show haproxy client-auth](#), on page 166
- [show haproxy num-threads](#), on page 167
- [show hardware](#), on page 168
- [show ipsec information](#), on page 168
- [show ipsec policy\\_group](#), on page 169
- [show ipsec policy\\_name](#), on page 170
- [show ipsec status](#), on page 170
- [show itl](#), on page 170
- [show logins](#), on page 171
- [show key authz encryption](#), on page 172
- [show key authz signing](#), on page 172
- [show license all](#), on page 173
- [show license status](#), on page 173
- [show license summary](#), on page 173
- [show license tech support](#), on page 174
- [show license trace](#), on page 174
- [show license UDI](#), on page 174
- [show license usage](#), on page 175
- [show Login Grace Timeout](#), on page 175
- [show media streams](#), on page 175
- [show memory](#), on page 177
- [show myself](#), on page 177
- [show network all](#), on page 178



- [show network cluster](#), on page 178
- [show network dhcp eth0](#), on page 178
- [show network eth0](#), on page 179
- [show network failover](#), on page 179
- [show network ip\\_conntrack](#), on page 180
- [show network ipprefs](#), on page 180
- [show network ipv6](#), on page 181
- [show network max\\_ip\\_conntrack](#), on page 181
- [show network ntp option](#), on page 182
- [show network route](#), on page 182
- [show network status](#), on page 183
- [show network name-service attributes](#), on page 183
- [show network name-service cache-stats](#), on page 184
- [show network name-service {hosts|services} attributes](#), on page 185
- [show open files all](#), on page 185
- [show open files process](#), on page 186
- [show open files regexp](#), on page 186
- [show open ports all](#), on page 186
- [show open ports regexp](#), on page 187
- [show packages](#), on page 187
- [show password](#), on page 188
- [show password complexity character](#), on page 189
- [show password complexity length](#), on page 189
- [show password expiry](#), on page 189
- [show password expiry user](#), on page 190
- [show password expiry user list](#), on page 190
- [show perf counterhelp](#), on page 191
- [show perf list categories](#), on page 191
- [show perf list classes](#), on page 191
- [show perf list counters](#), on page 192
- [show perf list instances](#), on page 192
- [show perf query class](#), on page 193
- [show perf query counter](#), on page 193
- [show perf query instance](#), on page 194
- [show perf query path](#), on page 195
- [show process list](#), on page 195
- [show process load](#), on page 196
- [show process name](#), on page 197
- [show process name process-name ,](#) on page 197
- [show process open](#), on page 198
- [show process open-fd](#), on page 198
- [show process pid](#), on page 199
- [show process search](#), on page 199
- [show process user](#), on page 200
- [show process using-most cpu](#), on page 200
- [show process using-most memory](#), on page 201

- [show registry](#), on page 201
- [show risdb list](#), on page 202
- [show risdb query](#), on page 203
- [show samltrace level](#), on page 203
- [show session maxlimit](#), on page 204
- [show smtp](#), on page 204
- [show stats io](#), on page 204
- [show status](#), on page 205
- [show tech activesql](#), on page 206
- [show tech all](#), on page 206
- [show tech ccm\\_service](#), on page 206
- [show tech database](#), on page 207
- [show tech dberrcode](#), on page 207
- [show tech dbhighcputasks](#), on page 208
- [show tech dbintegrity](#), on page 208
- [show tech dbschema](#), on page 208
- [show tech dbinuse](#), on page 209
- [show tech dbstateinfo](#), on page 209
- [show tech devdefaults](#), on page 210
- [show tech dumpCSVandXML](#), on page 210
- [show tech gateway](#), on page 211
- [show tech locales](#), on page 211
- [show tech network all](#), on page 211
- [show tech network hosts](#), on page 212
- [show tech network interfaces](#), on page 212
- [show tech network resolv](#), on page 213
- [show tech network routes](#), on page 214
- [show tech network sockets](#), on page 214
- [show tech notify](#), on page 215
- [show tech params](#), on page 215
- [show tech prefs](#), on page 215
- [show tech procedures](#), on page 216
- [show tech repltimeout](#), on page 216
- [show tech routepatterns](#), on page 217
- [show tech routeplan](#), on page 217
- [show tech runtime](#), on page 217
- [show tech sqlhistory](#), on page 218
- [show tech systables](#), on page 218
- [show tech system](#), on page 219
- [show tech table](#), on page 220
- [show tech triggers](#), on page 220
- [show tech version](#), on page 220
- [show timezone config](#), on page 221
- [show timezone list](#), on page 221
- [show tls trace](#), on page 222
- [show tls min-version](#), on page 222

- [show tlsresumptiontimeout](#), on page 223
- [show trace](#), on page 223
- [show ups status](#), on page 223
- [show version active](#), on page 224
- [show version inactive](#), on page 224
- [show vos version](#) , on page 225
- [show web-security](#), on page 225
- [show webapp session timeout](#), on page 226
- [show workingdir](#), on page 226
- [show logins unsuccessful](#), on page 226

## show account

This command lists current administrator accounts, except the primary administrator account.

### show account

---

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## show accountlocking

This command displays the current account locking settings.

### show accountlocking

---

**Command Modes** Administrator (admin:)

#### Requirements

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

#### Example

```
admin:show accountlocking
Account Lockout is enabled
Unlock Time : 300 seconds
Retry Count : 3 attempts
```

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## show cert default-ca-list

This command displays all the default CA certificates, which are bundled with Unified Communications Manager and IM and Presence Service.

**show cert default-ca-list****Command Modes**

Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager and IM and Presence Service.

**Example**

```
admin:show cert default-ca-list
```

Common Name	Trust Stores	Purpose
"VeriSign Class 3 Secure Server CA - G3"	tomcat-trust	This certificate is used by UCM to communicate with Cisco if Call-Home feature is enabled.
"CAP-RTP-002"	CallManager-trust, CAPF-trust	This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM using the MIC when associated with a secure profile
"Cisco Manufacturing CA"	CallManager-trust, CAPF-trust	This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM using the MIC when associated with a secure profile.
"CAP-RTP-001"	CallManager-trust, CAPF-trust	This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM using the MIC when associated with a secure profile
"ACT2 SUDI CA"	CallManager-trust, CAPF-trust	This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM

"Cisco Manufacturing CA SHA2"	CallManager-trust, CAPF-trust	using the MIC when associated with a secure profile.  This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM using the MIC when associated with a secure profile.
"Cisco Root CA 2048"	CallManager-trust, CAPF-trust	This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM using the MIC when associated with a secure profile.
"Cisco Root CA M2"	CallManager-trust, CAPF-trust	This certificate was used to sign the MIC installed on Cisco endpoint. Presence of this certificate allows the end point to communicate securely with UCM using the MIC when associated with a secure profile.

## show cert list

This command displays certificate trust lists.

```
show cert list {own | trust}
```

Syntax Description	Parameters	Description
	<b>own</b>	Specifies owned certificates.
	<b>trust</b>	Specifies trusted certificates.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:cert list own
```

## show cert list type

This command displays the available selected type certificate files.

**show cert list type** {**own** | **trust**}

Syntax Description	Parameters	Description
	<b>own</b>	Specifies owned certificates.
	<b>trust</b>	Specifies trusted certificates.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## show cert own

This command displays certificate contents.

**show cert own** *filename*

Syntax Description	Parameters	Description
	<b>own</b>	Specifies owned certificates.
	<i>filename</i>	Represents the name of the certificate file.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## show cert trust

This command displays certificate contents.

**show cert trust** *filename*

Syntax Description	Parameters	Description
	<b>trust</b>	Specifies trusted certificates.
	<i>filename</i>	Represents the name of the certificate file.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## show cli pagination

This command displays the status of automatic CLI automatic pagination.

**show cli pagination**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:show cli pagination
Automatic Pagination : Off.
```

## show cli session timeout

This command displays the CLI session timeout value, which is the amount of time, in minutes, that can elapse before a CLI session times out and disconnects.

### show cli session timeout

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## show csr list

This command displays Certificate Sign Request contents and certificate trust lists.

### show csr list {own | trust}

#### Syntax Description

Parameters	Description
<b>own</b>	Shows a list of owned Certificate Sign Requests.
<b>trust</b>	Shows a list of trusted Certificate Sign Requests.

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

The certificate name can be obtained by using the **show cert list own** command.

#### Requirements

Command privilege level: 1

Allowed during upgrade:

Applies to: Unified Communications Manager, IM and Presence service on Unified Communications Manager, Cisco Unity Connection

#### Example

```
admin: show csr list own
tomcat/tomcat.csr
Vipr-QuetzalCoatl/Vipr-QuetzalCoatl.csr
.....
```



.....  
 .....

## show csr list type

This command displays the selected own Certificate Sign Request files.

**show csr list type own**

Syntax Description	Parameters	Description
	<b>own</b>	Shows a list of owned Certificate Sign Requests.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence service on Unified Communications Manager, Cisco Unity Connection

## show csr own

This command displays Certificate Sign Request (CSR) contents and certificate trust lists.

**show csr own name**

Syntax Description	Parameters	Description
	<i>name</i>	The name of the CSR file.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The certificate name can be obtained by using the **show cert list own** command.

### Requirements

Command privilege level: 1

Applies to: Unified Communications Manager, IM and Presence service on Unified Communications Manager, Cisco Unity Connection

### Example

```
admin:show csr own tomcat/tomcat.csr
[
```

```
[
-----BEGIN CERTIFICATE SIGN REQUEST-----
MIIDrDCCAxUCBENEUewwDQYJKoZIhvcNAQEEBQAwwgEbmTQwMgYDVQQGEytVbmFibGUgdG8gZm1u
ZCBDb3VudHJ5IGluIHBSYXRmb3JtIGRhdGF1YXNlMTIwMAYDVQQIEy1VbmFibGUgdG8gZm1uZCBT
dGF0ZSBpb3BibG9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
b24gaW4gcGxhdGZvc0gZGF0YWJhc2UxMDAuBGNVBAoTJ1VuYWJsZSB0byBmaW5kIE9yZyBpb3BibG
bGF0Zm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
bSBkYXRhYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
NTQwMjhaMIIBGzE0MDIGA1UEBHMV5hYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
YXRhYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
c2UxNTAzBGNVBAcTLFVuYWJsZSB0byBmaW5kIE9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
MTAwLgYDVQQKEydVbmFibGUgdG8gZm1uZCBPcmcgYW4gcGxhdGZvc0gZGF0YWJhc2UxMTAvBgNV
BAStKFVuYWJsZSB0byBmaW5kIFVuaXQgaW4gcGxhdGZvc0gZGF0YWJhc2UxZARBGNVBAW5kIE9y
ZHItY2NtMzYwZm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9yYm9y
J7bexSnC3PuDGncxT3Au4zpGgMaQRL+mk+dAt8gDzffKz8uUkUoibcUhvqk4h3FoTEM+6qgFWVMk
gSNUU+1i9MST4m1aq5hCP87G1jtPbnCXEsFXaKH+gxBq5eBvmmzm01D/otXrsfsmSt1AgMBAAEw
DQYJKoZIhvcNAQEEBQAwwgEYEAkwDyOoUDiZv1A0JVTNF3VuUqv4nSJLgafB6WFlDnh+3yqBWwfgN
```

## show csr own name

This command displays Certificate Sign Request (CSR) own certificate files.

**show csr own** *name* *name of certificate sign request*

Syntax Description	Parameters	Description
	<i>name</i>	The name of the CSR file.
	<i>name of certificate sign request</i>	The name of the certificate sign request.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The certificate name can be obtained by using the **show cert list own** command.

### Requirements

Command privilege level: 1

Applies to: Unified Communications Manager, IM and Presence service on Unified Communications Manager, Cisco Unity Connection

## show ctl

This command displays the contents of the Certificate Trust List (CTL) file on the server. It notifies you if the CTL is invalid.

**show ctl**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show cuc cluster status

This command shows the status of the servers in the cluster.

**show cuc cluster status**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc config groups

This command displays a list of the valid configuration group names.

**show cuc config groups** [page]

---

### Syntax Description

Parameters	Description
<b>page</b>	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

---

### Command Modes

Administrator (admin:)

---

### Usage Guidelines

To see a list of the settings for a specified group, run the command **show cuc config settings**.

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes  
 Applies to: Cisco Unity Connection

**Example**

```
admin: show cuc config groups
```

```
CiscoLicensing
ConfigurationAssistant
Conversations
Directory
Groupware
LogMgr
Messaging
:
:
Telephony
```

## show cuc config settings

This command displays the settings and values for a specified group of Connection configuration settings.

**show cuc config settings** *group\_name* **page**

Syntax Description	Parameters	Description
	<i>group_name</i>	Specifies the name of the configuration group whose settings you want to display. To see a list of valid group names, run the command <b>show cuc config groups</b> . Be aware that group names are case sensitive.
	<i>page</i>	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes  
 Applies to: Cisco Unity Connection

**Configuration Settings for the Group SA**

```
admin: show cuc config settings SA
```

```
SA Setting          Value
```

```

-----
SessionTimeout      20
Use24HrClockFormat  0

```

## show cuc dbconsistency

This command checks the tables and indexes of a specified database for inconsistencies.

**show cuc dbconsistency** [*database\_name*]

### Syntax Description

Parameters	Description
<i>database_name</i>	Specifies the name of the database that you want to check. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>-Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>-Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>-Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always unitymbxdb1.</li> <li>• <b>unityrptdb</b>-Contains audit log data.</li> </ul>

### Command Modes

Administrator (admin:)

### Usage Guidelines

After the command completes, the system saves detailed information in a log file and displays a summary of the results, including the location of the log file. Use the **file** commands to display the contents of the file.



**Caution** Checking database consistency makes a significant impact on system performance. Run this command only when little or no system activity is occurring. After the operation begins, you can not cancel it. Do not restart the server during the operation; the operation must complete successfully before Connection will function properly.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example of a Consistency Check of the unityrptdb Database

```
admin: show cuc dbconsistency unityrptdb
```

```
Checking consistency of unityrptdb tables. Please wait.
```

```
Consistency check of unityrptdb tables successful.
```

```
Validation of unityrptdb indexes successful.
```

```
Output is in file: cuc/cli/consistency_unityrptdb_070404-123636.txt
```

## show cuc dbcontents

This command exports the data from a specified database to a CSV file.

```
show cuc dbcontents [database_name]
```

Syntax Description	Parameters	Description
	<i>database_name</i>	Specifies the name of the database whose data you want to export to a CSV file. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>-Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>-Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>-Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always unitymbxdb1.</li> <li>• <b>unityrptdb</b>-Contains audit log data.</li> </ul>

**Command Modes** Administrator (admin:)

**Usage Guidelines** After the command completes, the location of the CSV file displays. Use the **file** commands to display the contents of the file.



**Caution** Saving the contents of a database to a CSV file affects system performance. Run this command only when little or no system activity is occurring.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example of Exporting the Data From the unitydirdb Database to a CSV File and Displays the Location of the File

```
admin: show cuc dbcontents unitydirdb
```

This operation may take a few minutes to complete. Please wait.

Output is in file: cuc/cli/contents\_unitydirdb\_070404-124027.csv

## show cuc dbschema

This command exports the SQL statements that are necessary to replicate the schema for a specified database to a file.

```
show cuc dbschema [database_name]
```

### Syntax Description

Parameters	Description
<i>database_name</i>	<p>Specifies the name of the database whose schema you want to export. Be aware that database names are case sensitive. Connection databases include:</p> <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>-Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>-Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>-Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always unitymbxdb1.</li> <li>• <b>unityrptdb</b>-Contains audit log data.</li> </ul>

### Command Modes

Administrator (admin:)

### Usage Guidelines

After the command completes, the location of the file displays. Use the **file** commands to display the file.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example of Exporting the Schema of the unitydirdb Database to a File and Displays the Location of the File

```
admin: show cuc dbschema unitydirdb
```

Output is in file: cuc/cli/schema\_unitydirdb\_061013-115815.sql

## show cuc dbserver disk

This command displays summary information about informix storage space for all Connection databases on the current server.

**show cuc dbserver disk** [**page**] [**file**]

### Syntax Description

Parameters	Description
[ <b>page</b> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.
[ <b>file</b> ]	Saves the output to a file. If you include this option, the summary includes the location of the file. Be aware that <b>file</b> is case sensitive.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc dbserver session

This command displays summary information about a specified informix database user session.

**show cuc dbserver session** *session\_id* [**page**] [**file**]

### Syntax Description

Parameters	Description
<i>session_id</i>	Specifies the database user session for which you want to display summary information. To get a list of current sessions, use either the <b>show cuc dbserver sessions list</b> command or the <b>show cuc dbserver user list</b> command.
[ <b>page</b> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.
[ <b>file</b> ]	Saves the output to a file. If you include this option, the summary includes the location of the file. Be aware that <b>file</b> is case sensitive.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1



Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc dbserver sessions all

This command displays summary information about all the current Informix database user sessions.

**show cuc dbserver sessions all** [page] [file]

### Syntax Description

Parameters	Description
[page]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.
[file]	Saves the output to a file. If you include this option, the summary includes the location of the file. Be aware that <b>file</b> is case sensitive.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc dbserver sessions list

This command displays a list of the current Informix database user sessions.

**show cuc dbserver sessions list** [page]

### Syntax Description

Parameters	Description
[page]	Causes the output to display one page at a time. Be aware that page is case sensitive.

### Command Modes

Administrator (admin:)

### Usage Guidelines

The names of internal database users generally correspond with the names of Connection components. Run this command before you run the **show cuc dbserver session** command to obtain the required session id. Results are sorted by session id.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc dbserver user list

This command displays a list of the active Connection internal database users.

**show cuc dbserver user list** [**page**]

Syntax Description	Parameters	Description
	[ <b>page</b> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The names of internal database users generally correspond with the names of Connection components. Results get sorted first by database and then by user.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc dbserver user waiting

This command displays a list of the Connection internal users that are waiting for a resource.

**show cuc dbserver user waiting** [**page**]

Syntax Description	Parameters	Description
	[ <b>page</b> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The names of the internal database users generally correspond with the names of Connection components.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## show cuc dbtable contents

This command exports the contents of a specified Connection table to a CSV file.

**show cuc dbtable contents** {*database\_name* *table\_name*}

Syntax Description	Parameters	Description
	<i>database_name</i>	Specifies the database that contains the table whose contents you want to export to a CSV file. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>—Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>—Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>—Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b>.</li> <li>• <b>unityrptdb</b>—Contains audit log data.</li> </ul>
	<i>table_name</i>	Specifies the table whose contents you want to export to a CSV file.
	<b>Note</b>	For a list of the tables in a specified database, use the <b>show cuc dbtable list</b> command. Be aware that table names are case sensitive.

**Command Modes** Administrator (admin:)

**Usage Guidelines** After the command completes, the location of the CSV file displays. Use the **file** commands to display the contents of the file.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

#### Example

```
admin: show cuc dbtable contents unitydirdb tbl_cos
```

```
Output is in file: cuc/cli/contents_tbl_cos_1013-113910.csv
```

## show cuc dbtable list

This command displays a list of the tables in a specified database.

**show cuc dbtable list** *database\_name* [**page**]

Syntax Description	Parameters	Description
	<i>database_name</i>	Specifies the database for which you want a list of tables. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>—Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>—Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>—Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b>.</li> <li>• <b>unityrptdb</b>—Contains audit log data.</li> </ul>
	[ <b>page</b> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

#### Example

```
admin: show cuc dbtable list unitydirdb
```

```
tbl_accountlogonpolicy
tbl_agency
tbl_agencyextensionrange
tbl_alias
tbl_alternatename
tbl_broadcastmessage
tbl_broadcastmessagerecipient
...
tbl_waveformat
```

## show cuc dbtable schema

This command displays a description for a specified table and a list of the columns in the table.

```
show cuc dbtable schema {database_nametable_name} [page]
```

Syntax Description	Parameters	Description
	<i>database_name</i>	<p>Specifies the database that contains the table show schema you want to display. Be aware that database names are case sensitive.</p> <p>Connection databases include:</p> <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>—Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>—Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>—Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b>.</li> <li>• <b>unityrptdb</b>—Contains audit log data.</li> </ul>
	<i>table_name</i>	<p>Specifies the table whose schema you want to display.</p> <p><b>Note</b> For a list of the tables in a specified database, use the <b>show cuc dbtable list</b> command. Be aware that table names are case sensitive.</p>
	[ <i>page</i> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example of Displaying the Schema for the Table `tbl_user` in the `unitydirdb` Database

```
admin: show cuc dbtable schema unitydirdb tbl_cos
```

A collection of service privileges for subscribers that control access to features and use of the system into classes. Class of Service objects determine which features a subscriber is licensed to use, the maximum length of their greetings and messages, what numbers they are allowed to dial, and what options are available to the subscriber among other things.

```
Columns:
displayname
movetodeletefolder
accessunifiedclient
...
accesslivereply
```

## show cuc dbview contents

This command saves the results from a specified SQL view in a CSV file.

```
show cuc dbview contents {database_nameview_name}
```

Syntax Description	Parameters	Description
	<i>database_name</i>	Specifies the database that contains the view whose results you want to save to a file. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>—Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>—Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>—Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b>.</li> <li>• <b>unityrptdb</b>—Contains audit log data.</li> </ul>
	<i>view_name</i>	Specifies the view whose results you want to save to a file.
	<b>Note</b>	For a list of the views in a specified database, use the <b>show cuc dbview list</b> command. Be aware that view names are case sensitive.

**Command Modes** Administrator (admin:)

**Usage Guidelines** After the command completes, the location of the CSV file displays. Use the file commands to display the contents of the file.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

The following example saves the results from the view `vw_cos`, in the database `unitydirdb`, to a CSV file.

```
admin: show cuc dbview contents unitydirdb vw_cos_061013-113910.csv
```

## show cuc dbview list

This command displays a list of the views in a specified database.

```
show cuc dbview list database_name [page]
```

**Syntax Description**

Parameters	Description
<i>database_name</i>	Specifies the database for which you want a list of views. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>—Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>—Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>—Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b>.</li> <li>• <b>unityrptdb</b>—Contains audit log data.</li> </ul>
[ <i>page</i> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**Example**

The following example displays a list of the views in the `unitydirdb` database.

```
admin: show cuc dbview list unitydirdb
```

```

vw_agency
vw_agencyextensionrange
vw_alias
vw_alternatename
vw_broadcastmessage
vw_broadcastmessagerecipient
vw_callaction
...
vw_waveformat

```

## show cuc dbview schema

This command displays the schema for a specified view.

**show cuc dbview schema** *{database\_nameview\_name}* [**page**]

Syntax Description	Parameters	Description
	<i>database_name</i>	Specifies the database that contains the view for which you want to display the schema. Be aware that database names are case sensitive. Connection databases include: <ul style="list-style-type: none"> <li>• <b>unitydirdb</b>—Contains the directory and configuration data.</li> <li>• <b>unitydyndb</b>—Contains dynamic data that Connection uses internally.</li> <li>• <b>unitymbxdb1</b> to <b>unitymbxdb5</b>—Contains the data about the current voice messages in the corresponding mailbox store, including pointers to the audio files that are stored in the file system. If only one mailbox store is configured, the name of the mailbox store database is always <b>unitymbxdb1</b>.</li> <li>• <b>unityrptdb</b>—Contains audit log data.</li> </ul>
	<i>view_name</i>	Specifies the view for which you want to display the schema. <p><b>Note</b> For a list of the views in a specified database, use the show cuc dbview list command. Be aware that view names are case sensitive.</p>
	[ <b>page</b> ]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example

The following example displays the schema for the view vw\_user in the database unitydirdb.

```
admin: show cuc dbview schema unitydirdb vw_cos
```



```
A simple view for tbl_Cos.
```

```
Columns:  
objectid  
accessfaxmail  
accessstts  
callholdavailable  
callscreenavailable  
canrecordname  
...  
requiresecuremessages
```

## show cuc jetty ssl status

This command allows you to check the status of SSL (Enabled/Disabled) on the Jetty server for notifications.

```
show cuc jetty ssl status
```

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example

```
admin: show cuc jetty ssl status
```

```
Command completed successfully.  
SSL notification is DISABLED
```

## show cuc locales

This command displays a list of the locales currently installed.

```
show cuc locales
```

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

```
admin: show cuc locales

Installed Locale Package  Locale
-----
uc-locale-en_GB-6.0.0.0-0  en-GB
uc-locale-fr_CA-6.0.0.0-0  fr-CA
```

## show cuc speechview registration certificate size

This command displays the current certificate bit size used for Speech to Text service registration and Voicemail transcription with Nuance server.

**show cuc speechview registration certificate size****Command Modes**

Administrator (admin:)

**Usage Guidelines**

To view the current certificate bit size, use the **show cuc speechview registration certificate size** (Cisco Unity Connection Only) command.

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only.

## show cuc sysagent task list

This command displays a list of the Sysagent tasks.

**show cuc sysagent task list [page]****Syntax Description**

Parameters	Description
[page]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

To run a sysagent task, use the run cuc sysagent task command. If the value of the Is Singleton column is Y for a specified task, the task can only be run on the primary server in a multi-server cluster. If this server is standalone, then all tasks run on this server.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

```
admin: show cuc sysagent task list
```

Task Name	Is Singleton
-----	-----
Data.BroadcastMessagePurge	N
Ums.CleanDeletedMessagesTask	Y
Ums.CleanDirectoryStreamFilesTask	Y
Ums.CleanOrphanAttachmentFilesTask	Y
...	
Data.UpdateDatabaseStats	N

## show cuc sysagent task results

This command displays the times at which the specified task started and completed, with the most recent time listed first.

```
show cuc sysagent task results task_name [page]
```

**Syntax Description****Parameters Description**

*task\_name* Specifies the task for which you want to display information when the task starts and completes.

**Note** For a list of task names, run the show cuc sysagent task list command. Be aware that task names are case sensitive.

[*page*] Causes the output to display one page at a time. Be aware that **page** is case sensitive.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

To run a Sysagent task, use the **run cuc sysagent task** command.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example

The following example displays the times at which the Sysagent task Umss.CleanDeletedMessagesTask started and completed.

```
admin: show cuc sysagent task results Umss.CleanDeletedMessagesTask
```

Time Started	Time Completed
-----	-----
2006-10-25 17:31:45.689	2006-10-25 17:31:45.785
2006-10-25 17:16:45.702	2006-10-25 17:16:45.742
2006-10-25 17:01:45.690	2006-10-25 17:01:45.730

## show cuc sysinfo

This command displays a summary of hardware and software system information for the current Connection server, including the version installed on the active and inactive partitions; whether a cluster is configured; QOS settings; hardware specifications; the amount of used and free disk space on the active, inactive, and common partitions; licensing information; and so on.

### show cuc sysinfo

#### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Cisco Unity Connection

### Example

```
admin: show cuc sysinfo

Gather Data/Time : Wed Oct 21 09:45:29 PDT 2009

Connection Install Information:

Host Name : connection1

Version:

Active Version : 8.0.0.98000-210
```

```

Inactive Version : 8.0.0.98000-201

High Availability (this server is) : Pri_Single_Server

Publisher : connection1.cisco.com - 10.10.10.10

Subscriber(s) : None

QOS Settings :

Call Signaling DSCP : CS3

Media Signaling DSCP : EF

Hardware :

HW Platform      : 7825I3

Processors      : 1

Type            : Family: Core 2

CPU Speed       : 2130

Memory         : 2048

Object Id       : 1.3.6.1.4.1.9.1.746

OS Version      : UCOS 4.0.0.0-31

...

```

## show cuc tech dbschemaversion

This command displays the schema version information for each database.

**show cuc tech dbschemaversion** [**page**]

### Syntax Description

Parameters	Description
[page]	Causes the output to display one page at a time. Be aware that <b>page</b> is case sensitive.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

```
admin: show cuc tech dbschemaversion

unitydirdb

=====

Schema Version   Product Version   Date
-----
1.2.363          2.1               2007-02-13 19:10:50.0
```

## show cuc tech dbserver all

This command runs all the show cuc tech commands in sequence and saves the results in a text file.

**show cuc tech dbserver all****Command Modes**

Administrator (admin:)

**Usage Guidelines**

After the command completes, detailed information gets saved in a text file and the location of the text file displays. Use the file commands to display the contents of the file.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**Example**

```
admin: show cuc tech dbserver all

Output is in file: cuc/cli/dbserverall_061013-111801.txt
```

## show cuc tech dbserver integrity

This command checks the integrity of the Informix database server storage space structure.

**show cuc tech dbserver integrity****Command Modes**

Administrator (admin:)

**Usage Guidelines**

After the command completes, detailed information gets saved in a text file, and a summary of the results displays, including the location of the file. Use the file commands to display the contents of the file.

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes  
 Applies to: Cisco Unity Connection

**Example**

```
admin: show cuc tech dbserver integrity
Database system catalog tables were successfully validated.
Database disk extents were successfully validated.
Database reserved pages were successfully validated.
Output is in file: cuc/cli/integrity_061013-95853.txt
```

## show cuc tech dbserver log diagnostic

This command checks for the existence of Informix assertion-failure and shared-memory-dump logs.

**show cuc tech dbserver log diagnostic**


---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** If the logs exist, their location displays. Use the file commands to display the contents of the files.

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes  
 Applies to: Cisco Unity Connection only.

**Example**

```
admin:show cuc tech dbserver log diagnostic
The following Informix logs are available for the UC database server:
core/af.3599c
core/af.36858
```

## show cuc tech dbserver log message

This command displays the end of the Informix message log.

**show cuc tech dbserver log message** [*lines*] [{*page*}]

---

Syntax Description	Parameters	Description
	<i>lines</i>	Specifies the number of lines that display at the end of the Informix message log. If the lines parameter is not included, the last 20 lines of the log are displayed.

---

Parameters	Description
page	(Optional) Causes the output to display one page at a time. Be aware that page is case sensitive.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only.

**Example**

```
admin:show cuc tech dbserver log message
Message Log File: online.ciscounity.log
18:09:01 Fuzzy Checkpoint Completed: duration was 0 seconds, 6 buffers
not flushed.
18:09:01 Checkpoint loguniq 57, logpos 0x208418, timestamp: 0x33b807
18:09:01 Maximum server connections 159
18:14:01 Fuzzy Checkpoint Completed: duration was 0 seconds, 6 buffers
not flushed.
18:14:01 Checkpoint loguniq 57, logpos 0x20a57c, timestamp: 0x33b9fc
```

## show cuc tech dbserver status

This command saves a detailed status report of the database server instance to a file.

**show cuc tech dbserver status****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only.

**Example**

```
admin:show cuc tech dbserver status
Output is in file: cuc/cli/status_061013-95031.txt
```

## show cuc trace levels

This command displays a list of all the diagnostic traces and trace levels that are currently enabled.



**show cuc trace levels [page]**

Syntax Description	Parameters	Description
	<b>page</b>	(Optional) Causes the output to display one page at a time. Be aware that page is case sensitive.

**Command Modes** Administrator (admin:)

**Usage Guidelines** To enable or disable specified traces and trace levels, use the set cuc trace (Cisco Unity Connection only) command.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only.

**Example**

```
admin:show cuc trace levels
Trace Name Levels
-----
Arbiter -
AudioStore 0
AxlAccess -
BulkAdministrationTool 0
CCL 10,11
CDE 3,14
CDL 11,13,15,17
::
VirtualQueue -
```

## show cuc version

This command displays the Cisco Unity Connection version that is currently installed on the active and inactive partitions.

**show cuc version**

**Command Modes** Administrator (admin:)

**Usage Guidelines** This command always displays the version in the active partition. If the active partition contains an upgrade, the command also shows the version in the inactive partition. The current Engineering Special also displays.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only.

**Example**

```
admin:show cuc version
Active version: 7.0.1.10000-323
Inactive version: 7.0.0.39700-277
```

## show date

This command displays the date and time on the server.

**show date****Command Modes**

Administrator (admin:)

**Example**

```
admin: show date
Sat Jul 17 01:28:57 IST 2010
```

## show diskusage

This command displays disk usage information about specific directories.

```
show diskusage activelog {activelog | common | inactivelog | install | tftp | tmp} filename
filename{directory | sort}
```

**Syntax Description**

Parameters	Description
<b>filename</b> <i>filename</i>	Saves the output to a specified file. These files are stored in the platform/cli directory. To view saved files, use the file view activelog command.
<b>directory</b>	Displays the directory sizes only.
<b>sort</b>	Sorts the output on the basis of file size. File sizes display in 1024-byte blocks.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show dscp all

This command displays the current DSCP traffic markings on all the ports. It displays the DSCP markings in decimal and hexadecimal. If the value corresponds to a class then it displays the correct class. If the value does not correspond to a class, then it displays N/A.

### show dscp all

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager and Cisco Unity Connection

## show dscp defaults

This command displays the default factory DSCP settings. These values take effect if the **set dscp defaults** command is executed.

### show dscp defaults

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager and Cisco Unity Connection

## show dscp marking

This command displays the current DSCP traffic markings for a particular DSCP value.

### show dscp marking *value*

#### Syntax Description

Parameters	Description
<i>value</i>	DSCP value. You can enter the name of a well-known DSCP class, or a numeric value in decimal or hexadecimal format. Precede hexadecimal values with 0x or 0X.

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** The valid class names as defined by DSCP are:

- Class Selector: values **CS0**, **CS1**, **CS2**, **CS3**, **CS5**, **CS6** **CS7**

The class selector (CS) values correspond to IP Precedence values and are fully compatible with IP Precedence.

- Expedited Forwarding: value **EF**

EF PHB is ideally suited for applications such as VoIP that require low bandwidth, guaranteed bandwidth, low delay, and low jitter.

- Best Effort: value **BE**

Also called default PHB, this value essentially specifies that a packet be marked with 0x00, which gets the traditional best-effort service from the network router.

- Assured Forwarding: values **AF11**, **AF12**, **AF13**, **AF21**, **AF22**, **AF23**, **AF41**, **AF42**, **AF43**

There are four types of Assured Forwarding classes, each of which has three drop precedence values. These precedence values define the order in which a packet is dropped (if needed) due to network congestion. For example, packets in AF13 class are dropped before packets in the AF12 class.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show dscp status

This command displays the current DSCP traffic markings.

**show dscp status** {**enabled** | **disabled**}

---

### Syntax Description

#### Parameters Description

---

**enabled** Filters the output to show only DSCP traffic markings that are enabled. If you do not specify a status, this filter is the default option.

---

**disabled** Filters the output to show only DSCP traffic markings that are disabled.

---



---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show environment fans

This command shows the status of the fan sensors.

**show environment fans**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show environment power-supply

This command shows the status of the power supply for MCS-7845, MCS-7835, MCS-7825H3/H4, and MCS-7816H3 servers—those with redundant power supply or embedded health hardware.

**show tlstrace**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show environment temperatures

This command retrieves the status of the temperature sensors.

**show environment temperatures**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show fileserver transferspeed

This command shows the reading and writing speed between the IM and Presence Service node and the external file server. It involves copying a large file onto the mounted directory and then copying it back onto the node. As a result, this command may have a performance impact on the node from which it is run.

### show fileserver transferspeed

#### Command Modes

Administrator (admin:)

#### Requirements

Applies to: IM and Presence Service on Unified Communications Manager.

#### Example

```
admin:show fileserver transferspeed
```

```
WARNING: This command involves copying a large file to and from the mounted directory. It can impact the performance of the system.
```

```
Do you want to continue? (y/n):y
```

```
Creating a file to perform the test, please wait...
```

```
Copying the file onto the mounted file system. Please note the writing speed recorded below.
262144+0 records in
262144+0 records out
1073741824 bytes (1.1 GB) copied, 28.9302 s, 37.1 MB/s
```

```
Copying the file from the mounted file system. Please note the reading speed recorded below.
262144+0 records in
262144+0 records out
1073741824 bytes (1.1 GB) copied, 67.7504 s, 15.8 MB/s
```

```
Clean-up finised
admin:
```

## show haproxy client-auth

This command displays the client authentication configured on the specified port.

```
show haproxy client-auth portnum
```

Parameter	Description
<i>portnum</i>	Enter the port number to view the client authentication configured on the specified port.  <b>Note</b> The supported port numbers are 6971, 6972 and 9443.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**Administrator can execute the **help show haproxy client-auth <portnum>** command to view the help content.**Requirements**

Command privilege level: 0

Applies to: Unified Communications Manager

**Example**

```
admin:show haproxy client-auth 9443
```

```
Client authentication on the port 9443 is currently set to optional
```

```
admin:show haproxy client-auth 9456
Enter valid values for the port.
Suggested values are 6971, 6972 and 9443
Executed command unsuccessfully
```

```
admin:help show haproxy client-auth 9443
show haproxy client-auth help:
This command will display client-auth for the specified port.
Example:
admin:show haproxy client-auth 6971
Client authentication on the port 6971 is currently set to required.
```

## show haproxy num-threads

This command displays the number of HAProxy threads.

**show haproxy num-threads****Command Modes**

Administrator (admin:)

**Usage Guidelines**Administrator can execute the **help show haproxy num-threads** command to view the help content.**Requirements**

Command privilege level: 0

Applies to: Unified Communications Manager

**Example**

```
admin:show haproxy num-threads
HAProxy process running 2 threads
admin:help show haproxy num-threads
```

```
show haproxy num-threads:
This command updates the number of threads started by HaProxy service.
Example:
admin:show haproxy num-threads
```

## show hardware

This command displays hardware-related information about the platform.

**show hardware**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

The following information is displayed:

- Platform
- Serial number
- BIOS build level
- BIOS manufacturer
- Active processors
- RAID controller status
- Disk partition details

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show ipsec information

This command displays detailed information about the specified ipsec policy.

```
show ipsec information {policy_grouppolicy_name}
```



Syntax Description	Parameters	Description
	<i>policy_group</i>	
	<i>policy_name</i>	

**Command Modes** Administrator (admin:)

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

### Example

```
admin:show ipsec information test test1
PolicyGroup           : test
PolicyName            : test1
Type                  : transport
Source Address        : 10.94.171.3
Source Type           : ip
Destination Address   : 10.94.1.2
Destination Type      : ip
Protocol              : tcp
Source Port           : Any
Destination Port      : Any
Remote Port           : Any
Authentication Method : psk
Destination Certificate : null
PSK                   : cisco
Phase 1 Life Time     : 3600
Encryption Algorithm  : des
Hash Algorithm        : sha1
Phase 1 DH Value      : null
Phase 2 Life Time     : 3600
ESP                   : null_enc
AH                    : hmac_sha1
Phase 2 DH Value      : null
Peer Type             : null
Status                : disabled
Source Certificate     : null
```

## show ipsec policy\_group

This command displays all the ipsec policy group on the node.

**show ipsec policy\_group**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show ipsec policy\_name

This command displays the list of ipsec policy names that exist in the specified policy group.

```
show ipsec policy_name policy_group
```

Syntax	Description
<b>Parameters</b>	<b>Description</b>
<i>policy_group</i>	Specifies the policy group name.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show ipsec status

```
show ipsec status
```

**Command Modes** Administrator (admin:)

**Usage Guidelines** **Requirements**

Command privilege level:

Allowed during upgrade:

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## show itl

This command displays the ITL file contents or prints an error message if the ITL file is invalid.

```
show itl
```

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show logins

This command lists recent logins to the server

**show login** [*number*]

**Syntax Description****Parameters Description**

*number* Specifies the number of the most recent logins to display. The default is 20.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show logins successful

This command shows the previous successful logins.

**show logins successful** [{*last n*}]

**Syntax Description****Parameters Description**

*last n* (Optional) Represents the last number of logins. By default, the value of this variable is 20.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show logins unsuccessful

Use this command to list recent unsuccessful login attempts to the following web applications:

- On Unified Communications Manager
  - Disaster Recovery System
  - Cisco Unified OS Administration
- On IM and Presence Service
  - IM and Presence Disaster Recovery System
  - Unified IM and Presence OS Administration

**show logins unsuccessful** [*number*]

Syntax Description	Parameters	Description
	<i>number</i>	Specifies the number of most recent logins to display. The default is 20.

### Command Modes

Administrator (admin)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to Unified Communications Manager and IM and Presence Service

## show key authz encryption

Run this command on any Unified Communications Manager node to view the OAuth signing key checksum that Unified Communications Manager uses to authenticate Cisco Jabber clients.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager and the IM and Presence Service.

## show key authz signing

Run this command on any Unified Communications Manager node to view the OAuth signing key checksum that Unified Communications Manager uses to authenticate Cisco Jabber clients.

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager and the IM and Presence Service.

## show license all

This command displays license status, license usage, UDI, and the agent version.

**show license all**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show license status

This command displays the smart licensing status.

**show license status**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show license summary

This command displays the smart licensing status and the license usage details.

**show license summary**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show license tech support

This command displays smart licensing status, product information, and product version.

**show license tech support**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show license trace

This command traces the content of smart agent-related logs to the console.

**show license trace**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show license UDI

This command displays all members in the Unique Device Identification(UDI) structure that are not NULL. Following are the list of UDI instances displayed for Unified Communications Manager:

- PID—Product Identifier
- SN—Serial Number
- UUID—Universal Unique Identifier

**show license UDI**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show license usage

This command displays the entitlements that are currently in use.

**show license usage**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## show Login Grace Timeout

This command shows the login Grace Timeout.

**show Login Grace Timeout**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show media streams

This command captures information on current media stream connections.

**show media streams** [*options*]

**Syntax Description****Parameters Description**

*options* Enter one of the following options:

- **file fname**: Limit (valid characters alphanumeric [a-Z, A-Z, 0-9, (-) ad , (\_)]. Default: mediainfo
- **count #**: Range 1-1000; Default: 2
- **sleep #**: Range 1-300 seconds; Default 5
- **device** {ALL | ANN | CFB | CRA | MOH | MTP} Default: device ALL
- **info**: Displays extra information
- **buffers**: Displays buffer usage information.
- **trace**: Activates extra trace from media driver to system log.

**Note** Ignore any kernel messages that display on the console screen when **show media streams trace** is entered.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

**Example**

```
admin: show media streams info buffers
```

Resulting file /platform/log/mediainfo.txt contains:

```
Time: 2008.03.04 11:01:42
I/F Ver=5, #Apps: Free= 7, Alloc= 4, #Conf: Free= 12, #Streams: Free= 40
Buffer Size = 652, Allocated Buffers= 1, Free Buffers = 5147
Buffer Size = 8192, Allocated Buffers= 0, Free Buffers = 450
App ID= 332, Cfg=CFB, Dead App Timer=86400, Active=Yes, Streams: Available= 92 Active=
4
Conf ID = 16777225, Type = Two No Sum, Streams: Tx = 2, Rx = 2, Active = Yes
Rx Stream: PktCnt= 5979, PID=16777653, PktSz=20ms, Payld=uLaw, IP=10.89.80.178:24652,
MCast=N, Mute=N, UsrMd=N, Actv=Y, QdPkts=2, PktOR=0, DtmfPL=0 DiscTimeSlice= 0 DiscPkts= 0
10:59:42
Buffer Size = 652, Used Buffers = 1
Buffer Size = 8192, Used Buffers = 0
Rx Stream: PktCnt= 6179, PID=16777651, PktSz=20ms, PayId=uLaw, IP=10.89.80.178:24650,
MCast=N, Mute=N, UsrMd=N, Actv=Y, QdPkts=0, PktOR=0, DtmfPL=0 DiscTimeSlice= 0 DiscPkts= 0
10:59:38
Buffer Size = 652, Used Buffers = 0
Buffer Size = 8192, Used Buffers = 0
Tx Stream: PktCnt= 5988, PID=16777653, PktSz=20ms, Payld=uLaw,
IP=10.13.5.189:29450 (24652), MCast=N, Mute=N, UsrMd=N, Actv=Y, DtmfPL=0, DtmfQ=0 10:59:42
Buffer Size = 652, Used Buffers = 0
Buffer Size = 8192, Used Buffers = 0
```



```
Tx Stream: PktCnt= 6193, PID=16777651, PktSz=20ms, Payld=uLaw,
IP=10.13.5.182:28516(24650), MCast=N, Mute=N, UsrMd=N, Actv=Y, DtmfPL=0, DtmfQ=0 10:59:42
Buffer Size = 652, Used Buffers = 0
Buffer Size = 8192, Used Buffers = 0
App ID= 331, Cfg=ANN, Dead App Timer=86400, Active=Yes, Streams: Available= 96 Active=
0
App ID= 330, Cfg=MOH, Dead App Timer=86400, Active=Yes, Streams: Available= 658 Active=
0
App ID= 329, Cfg=MTP, Dead App Timer=86400, Active=Yes, Streams: Available= 96 Active=
0
```

## show memory

This command displays information about the onboard memory.

```
show memory {count | modules | size}
```

Syntax Description	Parameters	Description
	<b>count</b>	Displays the number of memory modules on the system.
	<b>modules</b>	Displays detailed information about all the memory modules.
	<b>size</b>	Displays the total amount of physical memory.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show myself

This command displays information about the current account.

```
show myself
```

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show network all

This command shows network information for listening and nonlistening sockets.

**show network all** [**detail**] [**page**] [**search** *srchtext*]

Syntax Description	Parameters	Description
	<b>detail</b>	Shows additional information.
	<b>page</b>	Displays information one page at a time.
	<b>search</b> <i>srchtext</i>	Searches for <i>srchtext</i> in the output.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network cluster

This command lists nodes in the network cluster and also shows the remaining timer value when you enable Dynamic Cluster Configuration.

**show network cluster**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network dhcp eth0

This command shows DHCP status information.

**show network dhcp eth0**

**Command Modes** Administrator (admin:)

**Usage Guidelines** The **eth0** parameter displays Ethernet port 0 settings, including DHCP configurations and options.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network eth0

This command shows network information for ethernet 0.

**show network eth0** [**detail**] [**search** *srchtxt*]

Syntax Description	Parameters	Description
	<b>detail</b>	Shows additional information.
	<b>search</b> <i>srchtxt</i>	Searches for <i>srchtxt</i> in the output.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The **eth0** parameter displays Ethernet port 0 settings

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network failover

This command shows Network Fault Tolerance information.

**show network failover** [**detail**] [**page**]

Syntax Description	Parameters	Description
	<b>detail</b>	Shows additional information.
	<b>page</b>	Shows information one page at a time.

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network ip\_contrack

This command shows ip\_contrack usage information.

**show network ip\_contrack**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network ipprefs

This command shows the list of ports that have been requested to be opened or translated in the firewall.

**show network ipprefs** {all | enabled | public}

---

**Syntax Description**

Parameters	Description
<b>all</b>	Shows all incoming ports that may be used on the product.
<b>enabled</b>	Shows all incoming ports that are currently opened.
<b>public</b>	Shows all incoming ports that are currently opened for a remote client.

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

**Example**

```

admin:show network ipprefs public
Application IPProtocol PortValue HashLimit (max:rate) H-Status ConnLimit C-Status Type
XlatedPort Status Description
-----
sshhd      tcp      22      1500:25/second  enabled  -      disabled public
-          enabled sftp and ssh
tomcat     tcp      443     4000:50/second  disabled 300    enabled public
8443      enabled secure web
tomcat     tcp      80      4000:50/second  disabled 300    enabled public
8080

```

## show network ipv6

This command shows IPv6 network routes and network settings.

```
show network ipv6 {route | settings}
```

Syntax Description	Parameters	Description
	<b>route</b>	Shows all IPv6 routes.
	<b>settings</b>	Shows all IPv6 network settings.

**Command Modes** Administrator (admin:)

**Usage Guidelines**

**Note** IPv6 is not supported in Cisco Business Edition 5000.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Unity Connection

## show network max\_ip\_contrack

This command shows max\_ip\_contrack information.

```
show network max_ip_contrack
```

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network ntp option

This command displays the security option that is configured in the `/etc/config` file.

**show network ntp option****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network route

This command shows network routing information.

**show network route** [**detail**] [**search** *srchtext*]

**Syntax Description**

Parameters	Description
<b>detail</b>	Shows additional information.
<b>search</b> <i>srchtext</i>	Searches for the <i>srchtext</i> in the output.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show network status

This command shows active internet connections.

**show network status** [**detail**] [**listen**] [**process**] [**all**] [**nodns**][**search** *stext*]

Syntax Description	Parameters	Description
	<b>detail</b>	Shows additional information.
	<b>listen</b>	Shows only listening sockets.
	<b>process</b>	Shows the process ID and name of the program to which each socket belongs.
	<b>all</b>	Shows both listening and nonlistening sockets.
	<b>nodns</b>	Shows numerical addresses without any DNS information.
	<b>search</b> <i>stext</i>	Searches for the <i>stext</i> in the output.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

This example displays active internet connections.

```
admin: show network status
```

## show network name-service attributes

This command displays name service cache general attributes.

**show network name - service attributes**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

**Example:**

```
admin:show network name-service hosts attributes
enable-cache          yes
positive-time-to-live 3600
negative-time-to-live 20
```

Successful

## show network name-service cache-stats

This command displays name service cache statistics.

**show network name-services[host][services] cache-stats**

Syntax	Description
<b>hosts</b>	host services cache.
<b>services</b>	services service cache.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

**Example:**

```
admin:show network name-service hosts cache-stats
yes cache is enabled
    no cache is persistent
    yes cache is shared
    211 suggested size
    216064 total data pool size
    272 used data pool size
    3600 seconds time to live for positive entries
    20 seconds time to live for negative entries
    0 cache hits on positive entries
    0 cache hits on negative entries
    2 cache misses on positive entries
    0 cache misses on negative entries
    0% cache hit rate
    2 current number of cached values
    2 maximum number of cached values
    0 maximum chain length searched
    0 number of delays on rdlock
    0 number of delays on wrlock
    0 memory allocations failed
    yes check /etc/hosts for changes
```

Successful



## show network name-service {hosts|services} attributes

This command displays name service cache attributes.

**show networkname - service{hosts|services} attributes**

Syntax Description	Parameters	Description
	<b>hosts</b>	hosts services cache.
	<b>services</b>	services service cache.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

Example:

```
admin:show network name-service hosts attributes
enable-cache                yes
positive-time-to-live       3600
negative-time-to-live       20
suggested-size              211
persistent                  no
max-db-size                  33554432
```

Successful

## show open files all

This command shows all open files on the system.

**show open files all**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show open files process

The command shows open files that belong to a specified process.

**show open files process** *processID*

Syntax Description	Parameters	Description
	<i>processID</i>	Specifies a process.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show open files regexp

This command shows open files that match the specified regular expression.

**show open files regexp** *reg\_exp*

Syntax Description	Parameters	Description
	<i>reg_exp</i>	Specifies a regular expression.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show open ports all

This command shows all open ports on the system.

**show open ports all**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show open ports regexp

This command shows open ports that match the specified regular expression.

**show open ports regexp** *reg\_exp*

**Syntax Description**

Parameters	Description
<i>reg_exp</i>	Specifies a regular expression.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show packages

This command displays the name and version for installed packages.

**show packages** {**active** | **inactive**} *name* [**page**]

**Syntax Description**

Parameters	Description
<b>active</b>	Specifies active packages.
<b>inactive</b>	Specifies inactive packages.
<i>name</i>	Specifies the package name. To display all active or inactive packages, use the wildcard character, *.
<b>page</b>	Shows the output one page at a time

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password

This command shows information about the configured password.

**show password** {**age** | **history** | **inactivity**}

Syntax Description	Parameters	Description
	<b>age</b>	Shows information about the configured password age parameters
	<b>history</b>	Shows the number of passwords that the history maintains for OS administration accounts.
	<b>inactivity</b>	Shows the status of the password inactivity for OS accounts. Password inactivity is the number of days of inactivity after a password has expired before the account is disabled.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password change-at-login

This command shows whether a user is forced to change passwords after the user signs in to the system the next time.

**show password change-at-login** *userid*

Syntax Description	Parameters	Description
	<i>userid</i>	Specifies the user account that you want to show.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password complexity character

This command displays the status of the password complexity rules—whether they are disabled or enabled. If the password complexity rules are enabled, this command displays the shows their current configuration.

**show password complexity character**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password complexity length

This command displays the minimum length of passwords that need to be used for Cisco OS administrator accounts. The default minimum length of a password is six characters.

**show password complexity length**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password expiry

This command shows the configured password expiration parameters.

**show password expiry** {**maximum-age** | **minimum-age**}

Syntax Description	Parameters	Description
	<b>maximum-age</b>	Shows the maximum number of days for set password expiry.
	<b>minimum-age</b>	Shows the minimum number of days for set password expiry.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password expiry user

This command shows the configured password expiration parameters for the specified user.

**show password expiry user** {**maximum-age** | **minimum-age**} *userid*

Syntax Description	Parameters	Description
	<b>maximum-age</b>	Shows the maximum number of days for set password expiry.
	<b>minimum-age</b>	Shows the minimum number of days for set password expiry.
	<i>userid</i>	Specifies the user account that you want to show.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show password expiry user list

This command shows the password maximum age and password minimum age for each CLI user in the system.

**show password expiry user**

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf counterhelp

This command displays information about the specified perfmon counter.

**show perf counterhelp** *class-name counter-name*

Syntax Description	Parameters	Description
	<i>class-name</i>	Represents the class name that contains the counter.
	<i>counter-name</i>	Represents the counter that you want to view.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If the class name or counter name contains white spaces, enclose the name in double quotation marks.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf list categories

This command lists the categories in the perfmon system.

**show perf list categories**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf list classes

This command lists perfmon classes (objects).

**show perf list classes** [**{cat** *category*}] [**{detail}**]

Syntax Description	Parameters	Description
	<b>cat</b>	Displays perfmon classes for the specified category.
	<i>category</i>	
	<b>detail</b>	Displays detailed information.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf list counters

This command lists perfmon counters for the specified perfmon class.

**show perf list counters** *class-name* [{**detail**}]

Syntax Description	Parameters	Description
	<i>class-name</i>	Represents the class name that contains the counter.
	<b>detail</b>	Displays detailed information.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If the class name contains white spaces, enclose the name in double quotation marks.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf list instances

This command lists the perfmon instances for the specified perfmon class.

**show perf list instances** *class-name* [{**detail**}]



Syntax Description	Parameters	Description
	<i>class-name</i>	Represents the class name that contains the counter.
	<b>detail</b>	Displays detailed information.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If the class name contains white spaces, enclose the name in double quotation marks.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf query class

This command queries a perfmon class and displays all the instances and counter values of each instance.

**show perf query class** *class-name* [{,*class-name*...}]

Syntax Description	Parameters	Description
	<i>class-name</i>	Represents the class name that contains the counter.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If the class name contains white spaces, enclose the name in double quotation marks.

You can specify a maximum of five classes for each command.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf query counter

This command queries the specified counter or counters and displays the counter value of all instances.

**show perf query counter** *class-name counter-name* [{,*counter-name*...}]

**Syntax Description****Parameters**   **Description**

<i>class-name</i>	Represents the class name that contains the counter.
<i>counter-name</i>	Represents the counter that you want to view.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

If the class name or counter name contains white spaces, enclose the name in double quotation marks.

You can specify a maximum of five counters for each command.



**Note** The output that this command returns depends on the number of endpoints that is configured in the Route Groups in Unified Communications Manager.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf query instance

This command queries the specified instance and displays all its counter values.

**show perf query instance** *class-name instance-name* [{*instance-name...*}]**Syntax Description****Parameters**   **Description**

<i>class-name</i>	Represents the class name that contains the counter.
<i>instance-name</i>	Specifies the perfmon instance to view.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

If the class name contains white spaces, enclose the name in double quotation marks.

You can specify a maximum of five instances for each command.

This command does not apply to singleton perfmon classes.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show perf query path

This command queries a specified perfmon path.

**show perf query path** *path-spec* [{*path-spec*...}]

### Syntax Description

Parameters	Description
<i>path-spec</i>	Specifies a perfmon path.

### Command Modes

Administrator (admin:)

### Usage Guidelines

For an instance-based perfmon class, you must specify *path-spec* as follows:

*class-name(instance-name)\counter-name*

For a non instance-based perfmon class (a singleton), you must specify *path-spec* as follows:

*class-name\counter-name*

You can specify a maximum of five paths for each command.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

```
admin: show perf query path "Cisco Phones(phone-0)\CallsAttempted","Cisco Unified
Communications Manager\TlChannelsActive"
```

## show process list

This command displays a list of all the processes and critical information about each process and visually indicates the child-parent relationships between the processes.

**show process list** [{**file** *filename*}] [{**detail**}]

### Syntax Description

Parameters	Description
<b>file</b>	Outputs the results to the file that is specified by the filename variable.
<i>filename</i>	Specifies the filename.

Parameters	Description
<b>detail</b>	Displays detailed output.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process load

This command displays the current load on the system.

```
show process load [{cont}] [{clear}] [{noidle}] [{num number}] [{thread}] [{cpu | memory | time}] [{page}]
```

**Syntax Description**

Parameters	Description
<b>cont</b>	Repeats the command continuously.
<b>clear</b>	Clears the screen before displaying output.
<b>noidle</b>	Ignores the idle or zombie processes.
<b>num number</b>	Displays the number of processes that are specified by number. The default number of processes equals 10. Set <i>number</i> to all to display all processes.
<b>thread</b>	Displays threads.
<b>cpu</b>	Sorts output by CPU usage. This is the default sorting.
<b>memory</b>	Sorts output by memory usage.
<b>time</b>	Sorts output by time usage.
<b>page</b>	Displays the output in pages.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process name

This command displays the details of processes that share the same name and indicates their parent-child relationship.

```
show process name process [{file filename}]
```

Syntax Description	Parameters	Description
	<i>process</i>	Specifies the name of a process.
	<b>file</b> <i>filename</i>	Outputs the results to the file that is specified by <i>filename</i> .

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process name process-name

The command shows the details of processes that share the same name. This commands displays parent-child relationship.

```
show process name process name [{file vm detail cont}]
```

Syntax Description	Parameters	Description
	<i>process name</i>	Specifies the name of a process.
	<b>file</b>	(Optional) Shows the file name where the output is to be received.
	<b>vm</b>	(Optional) Shows the virtual memory of the process.
	<b>detail</b>	(Optional) Shows the details, such as page fault, virtual memory, and start time of the process.
	<b>cont</b>	(Optional) Repeats the command continuously.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process open

This command lists the open file descriptors for a comma separated list of process IDs.

**show process open file**

Syntax Description	Parameters	Description
	<b>file</b>	(Optional) Shows the file name where the output is to be received.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process open-fd

This command lists the open file descriptors for a comma-separated list of process IDs.

**show process open-fd process-id [{,process-id2}]**

Syntax Description	Parameters	Description
	<i>process-id</i>	Specifies the process-id.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process pid

This command shows a specific process number or command name.

```
show process pid pid [{file filename}]
```

Syntax Description	Parameters	Description
	<i>pid</i>	Specifies the process ID number of a process.
	<b>file</b> <i>filename</i>	Outputs the results to the file that is specified by <i>filename</i> .

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process search

This command searches for the pattern that the regular expression *regexp* specifies in the output of the operating system-specific process listing.

```
show process search regexp [{file filename}]
```

Syntax Description	Parameters	Description
	<i>regexp</i>	Represents a regular expression.
	<b>file</b> <i>filename</i>	Outputs the results to the file that is specified by <i>filename</i> .

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process user

This command retrieves details of processes that share the user name and displays parent-child relationship.

```
show process user username [{file detail detail detail cont}]
```

### Syntax Description

Parameters	Description
<i>username</i>	Specifies the username.
<b>file</b> <i>filename</i>	Outputs the results to the file that is specified by <i>filename</i> .
<i>vm</i>	(Optional) Shows the virtual memory of the process.
<i>detail</i>	(Optional) Shows the details, such as page fault, virtual memory, and start time of the process.
<i>cont</i>	(Optional) Repeats the command continuously.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process using-most cpu

This command displays a list of the most CPU-intensive processes.

```
show process using-most cpu [{ number }] [{ file filename | [{ cont }] }
```

### Syntax Description

Parameters	Description
<i>number</i>	Specifies the number of processes to display. The default specifies 5.
<b>file</b> <i>filename</i>	Outputs the results to the file that is specified by <i>filename</i> .
<b>cont</b>	Repeats the command continuously.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0



Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show process using-most memory

This command displays a list of the most memory-intensive processes.

```
show process using-most memory [ { number } ] [ { file filename } [ { cont } ] ]
```

Syntax Description	Parameters	Description
	<i>number</i>	Specifies the number of processes to display. The default specifies 5.
	<b>file</b> <i>filename</i>	Outputs the results to the file that is specified by <i>filename</i> .
	<b>cont</b>	Repeats the command continuously.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show registry

This command displays the contents of the registry.

```
show registry system component [ { name } ] [ { page } ]
```

Syntax Description	Parameters	Description
	<i>system</i>	Represents the registry system name.
	<i>component</i>	Represents the registry component name.
	<i>name</i>	Represents the name of the parameter to show.
	<b>page</b>	Displays one page at a time.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If the name is “page,” and you want to display the output one page at a time, use the command **show registry system component name page page**

To show all components in a system, enter the wildcard character \* in the command: **show registry system \***

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

This example shows the contents of the cm system, dbl/sdi component.

```
admin:show registry cm dbl/sdi
system = cm
  component = dbl/sdi
    tracelevel=127
    enable=1
    outputdebugstringflag=0
    numminutes=1440
    tracefile=/var/log/active/cm/trace/dbl/sdi/dbl.log
    numfiles=250
    numlines=10000
```

## show risdb list

This command displays the tables that are supported in the Realtime Information Service (RIS) database.

**show risdb list** [{file *filename*}]

### Syntax Description

Parameters	Description
<b>file</b>	Outputs the information to a file.
<i>filename</i>	

### Command Modes

Administrator (admin:)

### Usage Guidelines

The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the filename does not contain the “.” character.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

**Example**

This command displays a list of all RIS database tables.

```
admin: show risdb list
```

## show risdb query

This command displays the contents of the specified RIS tables.

```
show risdb query table1 table2 table3 ...[{file filename}]
```

**Syntax Description**

Parameters	Description
<i>table1</i>	Specifies the name of a table.
<b>file</b> <i>filename</i>	Outputs the information to a file.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

The file option saves the information to `platform/cli/filename.txt`. Ensure that the filename does not contain the “.” character.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show samltrace level

This command displays the trace level that is currently configured.

```
show samltrace level
```

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection.

## show session maxlimit

This command shows the upper limit for concurrent SSH sessions.

**show session maxlimit**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show smtp

This command displays the name of the SMTP host.

**show smtp**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

```
admin:show smtp
SMTP hostname: mail.cisco.com
```

## show stats io

This command displays the IO statistics.

**show stats io** [**kilo**] [**detail**] [**page**] [**file filename**]

---

### Syntax Description

Parameters	Description
<b>kilo</b>	Displays statistics in kilobytes.

Parameters	Description
<b>detail</b>	Displays detailed statistics on every available device on the system and overrides the <b>kilo</b> option.
<b>page</b>	Displays one page at a time.
<b>file</b> <i>filename</i>	Outputs the information to a file specified by <i>filename</i>

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the filename does not contain the “.” character.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show status

This command displays basic platform status.

**show status****Command Modes**

Administrator (admin:)

**Usage Guidelines**

This command displays the following basic platform status:

- hostname
- date
- timezone
- locale
- product version
- platform version
- CPU usage
- memory and disk usage

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech activesql

This command displays the active queries to the database taken at one minute intervals as far back as the logs allow.

**show tech activesql**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech all

This command displays the combined output of all **show tech** commands.

**show tech all** [{page}] [{file filename}]

---

### Syntax Description

Parameters	Description
<b>page</b>	Displays one page at a time.
<b>file</b> <i>filename</i>	Outputs the information to a file.

---

### Command Modes

Administrator (admin:)

---

### Usage Guidelines

The file option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the "." character

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech ccm\_service

This command displays information about all services that can run on the system.

**show tech ccm\_service**


---

**Command Modes** Administrator (admin:)
**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech database

This command shows information about the database.

**show tech database** {**dump** | **sessions**}

---

**Syntax Description**

Parameters	Description
<b>dump</b>	Creates a CSV file of the entire database.
<b>sessions</b>	Redirects the session and SQL information of the present session IDs to a file.

---

**Command Modes** Administrator (admin:)
**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dberrcode

This command displays information (from the database log files) about the error code that is specified.

**show tech dberrcode** *errorcode*

---

**Syntax Description**

Parameters	Description
<i>errorcode</i>	Specifies the error code as a positive integer.

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** If the error code is a negative number, enter it without the minus sign (-).

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dbhighcputasks

This command displays the currently running high cost tasks and high CPU-intensive tasks.

**show tech dbhighcputasks****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dbintegrity

This command displays the database integrity.

**show tech dbintegrity****Command Modes**

Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dbschema

This command displays the database schema in a CSV file.

**show tech dbschema** [{car | cm}]**Syntax Description**

Parameters	Description
car	Represents the car database.
cm	Represents the cm database.



**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dbinuse

This command displays the database in use.

**show tech dbinuse** [{car | cm}]

**Syntax Description**

Parameters	Description
car	Represents the car database.
cm	Represents the cm database.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dbstateinfo

This command displays the state of the database.

**show tech dbstateinfo** [{car | cm}]

**Syntax Description**

Parameters	Description
car	Represents the car database.
cm	Represents the cm database.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech devdefaults

This command displays the device defaults table.

### show tech devdefaults

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech dumpCSVandXML

This command provides detailed information for customer support in the case of a standard upgrade condition.

### show tech dumpCSVandXML

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

You can get this file in the following ways:

1. Use the `file view activelog cm/trace/dbl/xmlcsv.tar` command to view the contents of the file.
2. Use the `file get activelog cm/trace/dbl/xmlcsv.tar` command to download the file.
3. Use RTMT: **Trace and Log Central** > **Collect Files** > **Cisco Database Cli Output** > **Install and upgrade log**.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech gateway

This command displays the gateway table from the database.

**show tech gateway**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech locales

This command displays the locale information for devices, device pools, and end users.

**show tech locales**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech network all

This command displays all network tech information.

**show tech network all** [{**page**}] [{**search** *text*}] [{**file** *filename*}]

---

**Syntax Description**

Parameters	Description
<b>page</b>	Displays one page at a time.
<b>search</b> <i>text</i>	Searches the output for the string that <i>text</i> specifies. Be aware that the search is case insensitive.
<b>file</b> <i>filename</i>	Outputs the information to a file.

---

**Command Modes** Administrator (admin:)

**Usage Guidelines** The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech network hosts

This command displays information about hosts configuration.

**show tech network hosts** [**page**] [**search** *text*] [**file** *filename*]

**Syntax Description**

Parameters	Description
<b>page</b>	Displays one page at a time.
<b>search</b> <i>text</i>	Searches the output for the string that <i>text</i> specifies. Be aware that the search is case insensitive.
<b>file</b> <i>filename</i>	Outputs the information to a file.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech network interfaces

This command displays information about the network interfaces.

**show tech network interfaces** [**page**] [**search** *text*] [**file** *filename*]

Syntax Description	Parameters	Description
	<b>page</b>	Displays one page at a time.
	<b>search</b> <i>text</i>	Searches the output for the string that text specifies. Be aware that the search is case insensitive.
	<b>file</b> <i>filename</i>	Outputs the information to a file.
Command Modes	Administrator (admin:)	
Usage Guidelines	The <b>file</b> option saves the information to <code>platform/cli/filename.txt</code> . Ensure that the file name does not contain the “.” character	
	<b>Requirements</b>	
	Command privilege level: 0	
	Allowed during upgrade: Yes	
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection	

## show tech network resolv

This command displays information about hostname resolution.

```
show tech network resolv [{page}] [{search text}] [{file filename}]
```

Syntax Description	Parameters	Description
	<b>page</b>	Displays one page at a time.
	<b>search</b> <i>text</i>	Searches the output for the string that text specifies. Be aware that the search is case insensitive.
	<b>file</b> <i>filename</i>	Outputs the information to a file.
Command Modes	Administrator (admin:)	
Usage Guidelines	The <b>file</b> option saves the information to <code>platform/cli/filename.txt</code> . Ensure that the file name does not contain the “.” character	
	<b>Requirements</b>	
	Command privilege level: 1	
	Allowed during upgrade: Yes	
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection	

## show tech network routes

This command displays information about network routes.

```
show tech network routes [{page}] [{search text}] [{file filename}]
```

### Syntax Description

Parameters	Description
<b>page</b>	Displays one page at a time.
<b>search</b> <i>text</i>	Searches the output for the string that <i>text</i> specifies. Be aware that the search is case insensitive.
<b>file</b> <i>filename</i>	Outputs the information to a file.

### Command Modes

Administrator (admin:)

### Usage Guidelines

The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech network sockets

This command displays the list of open sockets.

```
show tech network sockets {numeric}
```

### Syntax Description

Parameters	Description
<b>numeric</b>	Displays the numerical addresses of the ports instead of determining symbolic hosts. This parameter is equivalent to running the Linux shell <b>numeric [-n]</b> command.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech notify

This command displays the database change notify monitor.

```
show tech notify [search pattern_to_match]
```

Syntax Description	Parameters	Description
	<i>search pattern_to_match</i>	Represents the string that needs to be searched in the command output.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech params

This command displays the database parameters.

```
show tech params {all | enterprise | service}
```

Syntax Description	Parameters	Description
	<b>all</b>	Displays all the database parameters.
	<b>enterprise</b>	Displays the database enterprise parameters.
	<b>service</b>	Displays the database service parameters.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech prefs

This command displays database settings.

**show tech prefs****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech procedures

This command displays the CAR or CM procedures that are in use for the database.

**show tech procedures** {**car** | **cm**}**Syntax Description**

Parameters	Description
<b>car</b>	Specifies the CAR procedures.
<b>cm</b>	Specifies the CM procedures.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech repltimeout

This command displays the replication timeout.

**show tech repltimeout****Command Modes**

Administrator (admin:)

**Usage Guidelines**

When you increase the replication timeout, ensure that as many servers as possible in a large system are included in the first round of replication setup. If you have the maximum number of servers and devices, set the replication timeout to the maximum value. Be aware that this delays the initial set up of replication to give all servers time to get ready for setup.



**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech routepatterns

This command displays the route patterns that are configured for the system.

**show tech routepatterns**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech routeplan

This command displays the route plans that are configured for the system.

**show tech routeplan**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech runtime

This command displays CPU usage information at the time the command is run.

**show tech runtime** {all | cpu | disk | env | memory} page file *filename*

Syntax Description	Parameters	Description
	<b>all</b>	Displays all runtime information.
	<b>cpu</b>	Displays CPU usage information at the time the command is run.
	<b>disk</b>	Displays system disk usage information.
	<b>env</b>	Displays environment variables.
	<b>memory</b>	Displays memory usage information.
	<b>page</b>	Displays one page at a time.
	<b>file</b> <i>filename</i>	Outputs the information to a specified file.
	<b>Note</b>	This option saves the information to platform/cli/<filename>.txt. Ensure that the file name does not contain the "." character.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## show tech sqlhistory

This command prints the history of SQL statements executed.

**show tech sqlhistory****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech systables

This command displays the name of all tables in the sysmaster database.

**show tech systables**

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech system

This command displays all the system information.

**show tech system** {**all** | **bus** | **hardware** | **host** | **kernel modules** | **software** | **tools**} **page file** *filename***Syntax Description**

Parameters	Description
<b>all</b>	Displays all the system information.
<b>bus</b>	Displays information about the data buses on the server.
<b>hardware</b>	Displays information about the server hardware.
<b>host</b>	Displays information about the server.
<b>kernel modules</b>	Lists the installed kernel modules.
<b>software</b>	Displays information about the installed software versions.
<b>tools</b>	Displays information about the software tools on the server.
<b>page</b>	Displays one page at a time.
<b>file</b> <i>filename</i>	Outputs the information to a file. This option saves the information to platform/cli/<filename>.txt. Ensure that the file name does not contain the "." character.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech table

This command displays the contents of the specified database table.

**show tech table** *table\_name* [**page**]

Syntax Description	Parameters	Description
	<i>table_name</i>	Represents the name of the table to display.
	<b>page</b>	Displays the output one page at a time.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech triggers

This command displays table names and the triggers that are associated with those tables.

**show tech triggers**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tech version

This command displays the version of the installed components.

**show tech version** [**page**]

Syntax Description	Parameters	Description
	<b>page</b>	Displays one page at a time.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show timezone config

This command displays the current timezone settings.

**show timezone config**

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show timezone list

This command displays the available timezones.

**show timezone list** [{page}]

Syntax Description	Parameters	Description
	<b>page</b>	Displays the output one page at a time.

**Command Modes** Administrator (admin:)

**Usage Guidelines** Although the list of available time zones includes **Factory**, Unified Communications Manager does not support the **Factory** timezone.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tls trace

This command shows the status of TLS trace for a service.

```
show tls trace [ { service } ]
```

Syntax Description	Parameters	Description
	<i>service</i>	Represents the TLS tracing status of a service. It is a mandatory parameter.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show tls min-version

This command shows the minimum configured version of Transport Layer Security (TLS) protocol.

```
show tls min-version
```

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

#### Example

```
admin:show tls min-version
Configured TLS minimum version: 1.0
```

## show tlsresumptiontimeout

This command shows the TLS session resumption timeout.

**show tlsresumptiontimeout**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show trace

This command displays trace information for a particular task.

**show trace** [*task\_name*]

### Syntax Description

Parameters	Description
<i>task_name</i>	Represents the name of the task for which you want to display the trace information.

### Command Modes

Administrator (admin:)

### Usage Guidelines

If you do not enter a parameter, the command returns a list of available tasks.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

```
admin: show trace cdps
```

## show ups status

This command shows the current status of the USB-connected APC smart-UPS device and starts the monitoring service if this service is not already started.

**show ups status****Command Modes**

Administrator (admin:)

**Usage Guidelines**

This command provides full status only for 7835-H2 and 7825-H2 servers.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show version active

This command displays the software version on the active partition.

**show version active****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show version inactive

This command displays the software version on the inactive partition

**show version inactive****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection



## show vos version

With Unity Connection 12.0(1) and later, Unity Connection supports a specific ISO that is separated from the Unified CM ISO. However, Unity Connection will provide all the latest VOS changes. To see the VOS version integrated with Unity Connection *show vos version* CLI is introduced.

This command displays the VOS version stored in the active and inactive partitions. If there is no VOS version in the inactive partition, it displays "**VOS version not available**".

For more information, see "Support for Cisco Unity Connection ISO" section of the *Release Notes for Cisco Unity Connection 12.0(1)* available at

<http://www.cisco.com/c/en/us/support/unified-communications/unity-connection/products-release-notes-list.html>

### show vos version

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** This command always displays the VOS version in the active partition. If the active partition contains an upgrade, the command also shows the VOS version in the inactive partition.



---

**Note** If you are upgrading from Cisco Unity Connection 11.5(1) or earlier version to 12.0(1) or later, the inactive partition does not contain the information of VOS version.

---

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

### Example

```
admin:show vos version
Active version: 12.0.1.10000-1
Inactive version: VOS version not available
```

## show web-security

This command displays the contents of the current web-security certificate.

### show web-security

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show webapp session timeout

This command displays the webapp session timeout value, which is the amount of time, in minutes, that can elapse before a web application times out and logs off the user.

### show webapp session timeout

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show workingdir

This command retrieves the current working directory for activelog, inactivelog, install, and TFTP.

### show workingdir

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## show logins unsuccessful

Use this command to list recent unsuccessful login attempts to the following web applications:

- On Unified Communications Manager
  - Disaster Recovery System
  - Cisco Unified OS Administration
- On IM and Presence Service

- IM and Presence Disaster Recovery System
- Unified IM and Presence OS Administration

**show logins unsuccessful** [*number*]

Syntax Description	Parameters	Description
	<i>number</i>	Specifies the number of most recent logins to display. The default is 20.

**Command Modes** Administrator (admin)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to Unified Communications Manager and IM and Presence Service

**show logins unsuccessful**



## CHAPTER 8

# Unset Commands

- [unset ipsec policy\\_group](#), on page 229
- [unset ipsec policy\\_name](#), on page 229
- [unset network cluster subscriber details](#), on page 230
- [unset network cluster subscriber dynamic-cluster-configuration](#), on page 230
- [unset network dns options](#), on page 231
- [unset network domain](#), on page 231
- [unset network ntp options](#), on page 232
- [unset network ipv6 gateway](#), on page 232
- [unset network ipv6 static\\_address](#), on page 233

## unset ipsec policy\_group

This command disables the ipsec policy on the specified group.

```
unset ipsec policy_group policy_group
```

---

### Syntax Description

---

Parameters	Description
------------	-------------

---

<i>policy_group</i>	Specifies the group name.
---------------------	---------------------------

---

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## unset ipsec policy\_name

This command disables the ipsec policy with the specified name.

```
unset ipsec policy_name policy_group policy_name
```

---

**Syntax Description**


---

**Parameters Description**


---

*policy\_group* Specifies the name of a particular ipsec policy group to disable.

---

*policy\_name* Specifies the policy name to disable.

---



---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## unset network cluster subscriber details

This command shows the message that you need to delete a subscriber node from the GUI instead of the command prompt.

**unset network cluster subscriber details**


---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to Unified Communications Manager, IM and Presence Service on Communications Manager, and Cisco Unity Connection

**Message to delete the subscriber from GUI**

```
admin: unset network cluster subscriber details
Please use the Cisco Unified Communications Manager on the first node.
Navigate to System > Server and click "Find".
Unable to del: NULL
Executed command unsuccessfully.
```

## unset network cluster subscriber dynamic-cluster-configuration

This command disables Dynamic Cluster Configuration on the publisher. The value of **Dynamic Cluster Configuration** option is set to zero on publisher.

**unset network cluster subscriber dynamic-cluster-configuration**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## unset network dns options

This command unsets DNS options.

**unset network dns options** [**{timeout}**] [**{attempts}**] [**{rotate}**]

### Syntax Description

Parameters	Description
<b>timeout</b>	Sets the wait time before the system considers a DNS query as failed to the default.
<b>attempts</b>	Sets the number of DNS attempts to make before the system fails to the default.
<b>rotate</b>	Sets the method for selecting a nameserver to the default. This affects how loads are distributed across nameservers.

**Usage Guidelines** Running this command causes an automatic system restart.

**Command Modes** Administrator (admin:)

**Usage Guidelines** You are asked to confirm that you want to execute this command.



**Caution** If you continue, the system loses network connectivity temporarily.

### Requirements

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## unset network domain

This command unsets the domain name and restarts the server.

**unset network domain**

**Command Modes** Administrator (admin:)

**Usage Guidelines**

You are asked to confirm that you want to execute this command.

**Requirements**

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

**Example**

```
admin: unset network domain
cmdSetIp.domain.name.change.warning
Continue (y/n)?
trying to restart system...
Warning: Restart could take up to 5 minutes...
Shutting down Service Manager. Please wait...
```

## unset network ntp options

This command unsets the domain name and restarts the server.

**unset network ntp options****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## unset network ipv6 gateway

This command unsets the IPv6 gateway on the server.

**unset network ipv6 gateway** [*{reboot}*]**Syntax Description**

Parameters	Description
<i>reboot</i>	Reboots the server after applying the change.
<b>Note</b>	By default, the reboot on the server does not happen.

**Command Modes**

Administrator (admin:)



**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## unset network ipv6 static\_address

This command unsets the IPV6 static address.

```
unset network ipv6 static_address [{reboot}]
```

**Syntax Description**

Parameters	Description
<i>reboot</i>	Reboots the server after applying the change.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, Cisco Unity Connection

**Example**

```
admin: admin:unset network ipv6 static_address
      W A R N I N G
The Server must be rebooted for these changes to take effect.
Please make sure that you reboot this server.
IPv6 static address was removed.
```

`unset network ipv6 static_address`



## CHAPTER 9

# Utils Commands

---

- [utils auditd](#), on page 240
- [utils BE6000Mode enable](#), on page 240
- [utils BE6000Mode disable](#), on page 241
- [utils BE6000Mode status](#), on page 241
- [utils branding enable](#), on page 241
- [utils branding disable](#), on page 242
- [utils branding status](#), on page 242
- [utils contactsearchauthentication disable](#), on page 242
- [utils contactsearchauthentication enable](#), on page 242
- [utils contactsearchauthentication status](#), on page 243
- [utils core analyze](#), on page 243
- [utils core list](#), on page 244
- [utils capf cert import](#), on page 244
- [utils capf set keep\\_alive](#), on page 244
- [utils capf stale-lsc](#), on page 245
- [utils create report](#), on page 245
- [utils create report database](#), on page 246
- [utils ctl](#), on page 246
- [utils cuc activate CUSRSV](#), on page 248
- [utils cuc auto ITL download](#), on page 248
- [utils cuc cluster activate](#), on page 249
- [utils cuc cluster deactivate](#), on page 250
- [utils cuc cluster makeprimary](#), on page 250
- [utils cuc cluster overwrittenb](#), on page 250
- [utils cuc cluster renegotiate](#), on page 251
- [utils cuc create report](#), on page 251
- [utils cuc dbreplication 01\\_tear\\_down](#) , on page 252
- [utils cuc dbreplication 02\\_define\\_servers](#) , on page 253
- [utils cuc dbreplication 03\\_define\\_db\\_template](#), on page 253
- [utils cuc dbreplication 04\\_sync\\_database](#), on page 254
- [utils cuc dbreplication reset\\_all](#), on page 255
- [utils cuc encryption](#), on page 255
- [utils cuc jetty ssl disable](#), on page 256

- [utils cuc jetty ssl enable](#), on page 257
- [utils cuc networking clear\\_replication](#), on page 258
- [utils cuc networking dscp](#), on page 258
- [utils cuc reset password](#), on page 259
- [utils cuc set PinExpiry\\_PromptTime “Authentication Rule Name”](#), on page 259
- [utils dbreplication dropadmindb](#), on page 260
- [utils dbreplication forcedatasyncsub](#), on page 260
- [utils dbreplication quickaudit](#), on page 261
- [utils dbreplication rebuild](#), on page 262
- [utils dbreplication repair](#), on page 262
- [utils dbreplication repairreplicate](#), on page 263
- [utils dbreplication repairtable](#), on page 264
- [utils dbreplication reset](#), on page 264
- [utils dbreplication runtimestate](#), on page 265
- [utils dbreplication setprocess](#), on page 265
- [utils dbreplication setrepltimeout](#), on page 266
- [utils dbreplication status](#), on page 267
- [utils dbreplication stop](#), on page 268
- [utils imdb\\_replication replication status](#), on page 268
- [utils diagnose](#), on page 269
- [utils disaster\\_recovery backup network](#), on page 269
- [utils disaster\\_recovery cancel\\_backup](#), on page 270
- [utils disaster\\_recovery device add network](#), on page 270
- [utils disaster\\_recovery device delete](#), on page 271
- [utils disaster\\_recovery device list](#), on page 271
- [utils disaster\\_recovery estimate\\_tar\\_size](#), on page 272
- [utils disaster\\_recovery history](#), on page 272
- [utils disaster\\_recovery jschLogs operation](#), on page 273
- [utils disaster\\_recovery prepare restore pub\\_from\\_sub](#), on page 273
- [utils disaster\\_recovery restore network](#), on page 274
- [utils disaster\\_recovery schedule add](#), on page 274
- [utils disaster\\_recovery schedule](#), on page 275
- [utils disaster\\_recovery schedule delete](#), on page 275
- [utils disaster\\_recovery schedule disable](#), on page 276
- [utils disaster\\_recovery schedule list](#), on page 276
- [utils disaster\\_recovery show\\_backupfiles](#), on page 277
- [utils disaster\\_recovery show\\_registration](#), on page 277
- [utils disaster\\_recovery status](#), on page 278
- [utils EnhancedSecurityMode disable](#), on page 278
- [utils EnhancedSecurityMode enable](#), on page 278
- [utils EnhancedSecurityMode status](#), on page 279
- [utils filebeat config](#), on page 279
- [utils filebeat disable](#), on page 280
- [utils filebeat enable](#), on page 280
- [utils filebeat status](#), on page 280
- [utils filebeat tls](#), on page 281

- `utils fior`, on page 281
- `utils fior disable`, on page 282
- `utils fior enable`, on page 282
- `utils fior list`, on page 282
- `utils fior start`, on page 283
- `utils fior status`, on page 283
- `utils fior stop`, on page 284
- `utils fior top`, on page 284
- `utils fips`, on page 284
- `utils fips_common_criteria`, on page 286
- `utils firewall ipv4 debug`, on page 286
- `utils firewall ipv4`, on page 287
- `utils firewall ipv4 list`, on page 288
- `utils firewall ipv4 status`, on page 288
- `utils firewall ipv6 debug`, on page 288
- `utils firewall ipv6`, on page 289
- `utils firewall ipv6 list`, on page 290
- `utils firewall ipv6 status`, on page 290
- `utils ha failover`, on page 291
- `utils ha fallback`, on page 291
- `utils haproxy set {required|optional|disable} client-auth`, on page 292
- `utils haproxy set num-threads`, on page 294
- `utils ha recover`, on page 295
- `utils ha status`, on page 296
- `utils ils showpeerinfo`, on page 297
- `utils import config`, on page 297
- `utils iostat`, on page 298
- `utils iothrottle`, on page 299
- `utils itl reset`, on page 299
- `utils ipsec restart`, on page 300
- `utils ldap config`, on page 301
- `utils managementAgent alarms minpushLevel`, on page 302
- `utils managementAgent alarms pushfrequency`, on page 302
- `utils managementAgent alarms pushnow`, on page 303
- `utils network arp delete`, on page 303
- `utils network arp set`, on page 303
- `utils network arp list`, on page 304
- `utils network capture`, on page 305
- `utils network capture-rotate`, on page 306
- `utils network connectivity`, on page 307
- `utils network host`, on page 308
- `utils network ipv6 host`, on page 308
- `utils network ipv6 traceroute`, on page 309
- `utils network ipv6 ping`, on page 309
- `utils network ping`, on page 310
- `utils network traceroute`, on page 310

- [utils network name-service {hosts|services} cache invalidate](#), on page 311
- [utils ntp auth symmetric-key](#), on page 311
- [utils ntp auth auto-key](#), on page 313
- [utils ntp server add](#), on page 316
- [utils ntp server delete](#), on page 317
- [utils ntp config](#), on page 319
- [utils ntp restart](#), on page 319
- [utils ntp server list](#), on page 320
- [utils ntp start](#), on page 320
- [utils ntp status](#), on page 320
- [utils os kerneldump](#) , on page 321
- [utils os kerneldump ssh](#), on page 321
- [utils os kerneldump status](#), on page 322
- [utils os secure](#) , on page 322
- [utils os secure dynamic-policies compile](#), on page 323
- [utils os secure dynamic-policies list](#), on page 323
- [utils os secure dynamic-policies load](#), on page 324
- [utils os secure dynamic-policies remove](#), on page 324
- [utils os secure dynamic-policies show](#), on page 325
- [utils os secure dynamic-policies start-recording](#), on page 325
- [utils os secure dynamic-policies stop-recording](#), on page 326
- [utils PlatformWebAccess disable](#), on page 326
- [utils PlatformWebAccess enable](#), on page 327
- [utils PlatformWebAccess status](#), on page 327
- [utils processCoreDumps disable](#), on page 328
- [utils processCoreDumps enable](#), on page 328
- [utils processCoreDumps status](#), on page 328
- [utils remote\\_account create](#), on page 329
- [utils remote\\_account disable](#), on page 329
- [utils remote\\_account enable](#), on page 329
- [utils remote\\_account status](#), on page 330
- [utils remotesyslog set protocol tcp](#), on page 330
- [utils remotesyslog set protocol udp](#), on page 330
- [utils remotesyslog set protocol tls](#), on page 331
- [utils remotesyslog show protocol](#), on page 331
- [utils reset\\_application\\_ui\\_administrator\\_name](#), on page 332
- [utils reset\\_application\\_ui\\_administrator\\_password](#), on page 332
- [utils restore\\_application\\_ui\\_administrator\\_account](#), on page 333
- [utils rosters list limited](#), on page 333
- [utils rosters list full](#), on page 333
- [utils rosters list watchers](#), on page 334
- [utils rosters list contacts](#), on page 334
- [utils rosters delete](#), on page 334
- [utils scheduled-task disable](#), on page 335
- [utils scheduled-task enable](#) , on page 335
- [utils scheduled-task list](#), on page 335

- `utils set urlpattern disable`, on page 336
- `utils set urlpattern enable`, on page 336
- `utils service`, on page 337
- `utils service list`, on page 337
- `utils service auto-restart`, on page 338
- `utils service start`, on page 339
- `utils service stop`, on page 339
- `utils snmp config 1/2c community-string`, on page 339
- `utils snmp config 1/2c inform`, on page 340
- `utils snmp config 1/2c trap`, on page 341
- `utils snmp config 3 inform`, on page 341
- `utils snmp config mib2`, on page 342
- `utils snmp config 3 trap`, on page 342
- `utils snmp config 3 user`, on page 343
- `utils snmp get`, on page 344
- `utils snmp get 1`, on page 344
- `utils snmp get 2c`, on page 345
- `utils snmp get 3`, on page 346
- `utils snmp hardware-agents`, on page 346
- `utils snmp test`, on page 347
- `utils snmp walk`, on page 348
- `utils snmp walk 1`, on page 349
- `utils snmp walk 2c`, on page 350
- `utils snmp walk 3`, on page 350
- `utils soap realservice test`, on page 351
- `utils sso`, on page 351
- `utils sso recovery-url`, on page 352
- `utils system restart`, on page 352
- `utils system shutdown`, on page 353
- `utils system switch-version`, on page 353
- `utils system boot`, on page 354
- `utils system upgrade`, on page 354
- `utils system upgrade cluster`, on page 357
- `utils system enableAdministration`, on page 360
- `utils update dst`, on page 361
- `utils users validate`, on page 362
- `utils vmtools refresh`, on page 362
- `utils vmtools status`, on page 363
- `utils vmtools switch open`, on page 363
- `utils vmtools switch native`, on page 364
- `utils system boot status`, on page 364
- `utils system upgrade dataexport initiate`, on page 364
- `utils system upgrade dataexport status`, on page 365
- `utils system upgrade dataexport cancel`, on page 365
- `utils ucmgmt agent disable`, on page 366
- `utils ucmgmt agent enable`, on page 366

- [utils ucmgmt agent remove](#), on page 367
- [utils ucmgmt agent restart](#), on page 367
- [utils ucmgmt agent status](#), on page 367
- [utils ucmgmt agent verification](#), on page 368
- [utils ucmgmt config export](#), on page 368
- [utils ucmgmt config import](#), on page 369
- [utils ucmgmt organization](#), on page 369
- [utils ucmgmt proxy add](#), on page 370
- [utils ucmgmt proxy clear](#), on page 371
- [utils ucmgmt proxy force add](#), on page 371
- [utils ucmgmt proxy list](#), on page 372

## utils auditd

This command starts, stops, and provides the status of the system auditing service.

**utils auditd** {**enable** | **disable** | **status**}

### Syntax Description

Parameters	Description
<b>enable</b>	Enables the collection of audit logs. When enabled, the system monitors and records user actions as well as Linux events such as the creation and removal of users, as well as the editing and deleting of files .
<b>disable</b>	Disables the collection of audit logs.
<b>status</b>	Displays the status of audit log collection. We recommend that you retrieve the audit log by using the Real-Time Monitoring Tool, but you can also retrieve it by using the CLI.

### Command Modes

Administrator (admin:)

### Usage Guidelines

After the service has been enabled, it monitors and logs activity on the system. Be aware that the system auditing service logs a lot of information. Care must be taken not to overfill the disk.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils BE6000Mode enable

Run this command to enable BE6000 mode on Unified Communications Manager.

### Command Modes

Administrator (admin:)



**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils BE6000Mode disable

Run this command to disable BE6000 mode on Unified Communications Manager.

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils BE6000Mode status

Run this command to see the Status of BE6000 mode on Unified Communications Manager.

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils branding enable

Run this command to enable branding on this node.

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Applies to: Cisco Unified Communications Manager, IM and Presence Service, or Cisco Unity Connection.

## utils branding disable

Run this command to disable branding on this node.

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Applies to: Unified Communications Manager, IM and Presence Service, or Cisco Unity Connection.

## utils branding status

Run this command to see the status of whether branding is enabled or disabled on this node.

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Applies to: Unified Communications Manager, IM and Presence Service, or Cisco Unity Connection.

## utils contactsearchauthentication disable

This command disables the secure contact search authentication mode. After this mode is disabled, you need to reset the phone for the changes to take effect.

**utils contactsearchauthentication disable**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils contactsearchauthentication enable

This command enables the secure contact search authentication mode. After this mode is enabled, reset the phone for the changes to take effect.

**utils contactsearchauthentication enable**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils contactsearchauthentication status

This command shows whether the system is operating in contact search authentication enable mode or contact search authentication disable mode.

**utils contactsearchauthentication status**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils core analyze

This command generates a backtrace for a core file, a thread list, and the current value of all CPU registers.

**utils core {active | inactive} analyze [core\_filename]**

Syntax Description	Parameters	Description
	<b>active</b>	Specifies an active version
	<b>inactive</b>	Specifies an inactive version
	<i>core_filename</i>	Specifies the name of the core file from which to generate the stack trace.

**Command Modes** Administrator (admin:)

**Usage Guidelines**

This command creates a file of the same name as the core file, with a .txt extension, in the same directory as the core file. After you execute this command on a core file created by cimserver, an unexpected message displays. This message is a known limitation of the command.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils core list

This command displays all active or inactive core files.

**utils core {active | inactive} list**

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils capf cert import

**utils capf cert import**

Use this command to upload signed phone certificates to your system.

**Usage Guidelines**

You can choose to import your signed certificates through either FTP or TFTP.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils capf set keep\_alive

Run this command to set the keep\_alive timer for all connections between the Certificate Authority Proxy Function (CAPF) service and endpoints. The system default is 15 minutes.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils capf stale-lsc

**utils capf stale-lsc** {**delete** | **list**}

This command helps you manage your system's stale LSC certificates.

Syntax Description	Parameters	Description
	<b>delete</b>	Deletes all stale LSC certificates from your system.
	<b>list</b>	Lists all stale LSC certificates on the system.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils create report

This command creates reports about the server in the platform/log directory.

**utils create report** {**csa** | **hardware** | **platform** | **security**}

Syntax Description	Parameters	Description
	<b>csa</b>	Collects all the files required for the Cisco Security Agent (CSA) diagnostics and assembles them into a single CSA diagnostics file. You can retrieve this file using the <b>file get</b> command.
	<b>hardware</b>	Creates a system report that contains disk array, remote console, diagnostic, and environmental data.
	<b>platform</b>	Collects the platform configuration files into a TAR file.
	<b>security</b>	Collects the diagnostic reports and creates a TAR file that you can download for troubleshooting purposes. You can retrieve this file with the <b>file get</b> command.

**Command Modes** Administrator (admin:)

**Usage Guidelines**

You are prompted to continue after you enter the command.

After you create a report, use the command **file get activelog platform/log/filename** command, to get the report. where *filename* specifies the report filename that displays after the command completes.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils create report database

This command collects all log the files that are needed for database troubleshooting.

**utils create report** {*csa* | **hardware** | **platform** | **security**}

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils ctl

**utils ctl** {**set-cluster mixed-mode** | **set-cluster non-secure-mode** | **update CTLFile**}

This command changes the cluster security mode or updates the CTL file in each of the nodes.

**Syntax Description**

Parameters	Description
<b>set-cluster mixed-mode</b>	<p>Updates the CTL file and sets the cluster to mixed mode (db secure mode is set to 1).</p> <p>If the cluster is already in mixed mode, this command shows that Unified Communications Manager is in mixed mode and Autoregistration is active. You need to confirm your action.</p> <p><b>Note</b> To enable mixed-mode, ensure that the Communications Manager is registered with the Cisco Smart Software Manager or Cisco Smart Software Manager satellite and the Registration Token received from the Smart account or Virtual account has Allow export-controlled functionality enabled while registering with this cluster.</p>

Parameters	Description
<b>set-cluster non-secure-mode</b>	Updates the CTL file and set the cluster to non-secure mode. If the cluster is already in mixed mode, this command shows that Unified Communications Manager is in non-secure mode.
<b>update CTLFile</b>	Updates the CTL file in each of the nodes of the cluster.  <b>Note</b> To update the CTLFile in mixed-mode, ensure that the Unified Communications Manager is registered with the Cisco Smart Software Manager or Cisco Smart Software Manager satellite and the Registration Token received from the Smart account or Virtual account has Allow export-controlled functionality enabled while registering with this cluster.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The CLI must be executed on the publisher. On all other nodes, this CLI command is disabled.



**Note** Ensure that you reset all the Encrypted and Authenticated phones for the CTL file updates to take effect.

**Requirements**

- Command privilege level: 1
- Allowed during upgrade: Yes
- Applies to: Unified Communications Manager.

## utils ctl reset localkey

This command is used to regenerate the CTL file and sign it with the secondary SAST role (CallManager). Use this command when the ITLRecovery certificate that was used to sign the original CTL file has changed and the endpoints are locked out.

**utils ctl reset {localkey}**

**Syntax Description** **localkey** Generates a new CTL file, updates the CTL file on the publisher. The command signs the CTL file with CallManager key.

**Command Modes** Administrator (admin:)

## Usage Guidelines



### Note

- You must run this command on the Unified Communications Manager publisher node.
- After the endpoints receive the new CTL file, which is signed by CallManager Key and contains the new ITLRecovery certificate, execute the CTL update command (utils ctl update CTLFile) again to sign it with the ITLRecovery certificate. The CTL file is regenerated but signed by the new ITLRecovery certificate, which is now trusted by the endpoint.

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils cuc activate CUSRSV

This command converts the standalone Cisco Unity Connection server to Cisco Unity Connection SRSV server.

### utils cuc activate CUSRSV

#### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

## utils cuc auto ITL download

This command allows Unity Connection to disable the functionality of automatically downloading CallManager certificate for Cisco Unity Connection.

**utils cuc auto ITL download { enable | disable | status }**

### Syntax Description

Parameters	Description
enable	Enables the functionality of automatically downloading the CallManager certificates on port-group reset. By default, the functionality is enabled.



Parameters	Description
disable	Disables the functionality of automatically downloading the CallManager certificates. When disabled, you need to upload the certificates manually.
status	Displays the status of the functionality.



**Note** In case of a cluster, the CLI commands are executed only on publisher server.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Cisco Unity Connection

### Example

```
admin:utils cuc auto ITL download enable
```

After successful execution,Unity Connection will download trust list from the TFTP server automatically.

For this, you must do the following:

1. Configure TFTP server for Next Generation enabled port groups through Cisco Unity Connection Administration
  2. Restart the Connection Conversation Manager on all nodes in the cluster
- Auto downloading of ITL enabled successfully

## utils cuc cluster activate

This command activates this server in a Cisco Unity Connection cluster.

### utils cuc cluster activate

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## utils cuc cluster deactivate

This command deactivates this server in a Cisco Unity Connection cluster.

**utils cuc cluster deactivate**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## utils cuc cluster makeprimary

This command forces the specified server to take the primary server status in a Cisco Unity Connection cluster.

**utils cuc cluster makeprimary**

---

### Syntax Description

---

#### Parameters Description

Parameters	Description
<b>server</b>	Specifies the name of the server to take the primary server status in a Cisco Unity Connection cluster.

---



---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## utils cuc cluster overwrittenb

This command overwrites the data on the server with the data on the other server in a Cisco Unity Connection cluster.

**utils cuc cluster overwrittenb**

---

### Command Modes

Administrator (admin:)

---

### Usage Guidelines

This command overwrites the database on the server on which you run this command with the database from the other server in the Connection cluster. Replication restarts after the database is overwritten. This method is used when you restore one server from a backup and must copy the restored data to the other server.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## utils cuc cluster renegotiate

This command creates a cluster relationship with the publisher server in a Connection cluster after the server was replaced or the Connection was reinstalled on the publisher server. This command overwrites all data on the publisher server with data from the subscriber server and initializes replication between the servers.

**utils cuc cluster renegotiate**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

Run this command on the subscriber server in a Connection cluster to set up a trust with a publisher server that has been replaced or on which Connection has been reinstalled.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

## utils cuc create report

This command collects data that is helpful to technical support staff for troubleshooting the system. Data collected includes version information, cluster status, service information, database information, trace files, log files, disk information, memory information, and restart information.

**utils cuc create report**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

After the command completes, detailed information gets saved in a .zip file, and the location of the zip file displays. Use the **file get** command to move the file to a computer on which you can uncompress the file and view the contents.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only

**Example**

```

admin: utils cuc create report
Getting unity connection version. Please wait...Done
Getting cluster status. Please wait...Done
Getting service information. Please wait...Done
Getting installed locales. Please wait...Done
Getting database schema version. Please wait...Done
Getting database integrity. Please wait...Done
Getting database diagnostic log. Please wait...Done
Getting database message log. Please wait...Done
Getting trace files. Please wait...Done
Getting log files. Please wait...Done
Getting platform status. Please wait...Done
Compressing 75 files. Please wait...Done
Output is in file: cuc/cli/systeminfo_080318-140843.zip
To free disk space, delete the file after copying it to another computer

```

## utils cuc dbreplication 01\_tear\_down

This command breaks the replication and connectivity between two Unity Connection servers in a cluster. Running this command on both the servers ensures ideal cleanup before establishing a good replication between the servers.

**utils cuc dbreplication 01\_tear\_down****Command Modes**

Administrator (admin:)

**Usage Guidelines**

In case of long Unity Connection database CDR queue buildup, this command cleans the buildup for providing clean ground to establish server connectivity and replication between the two servers in the cluster.




---

**Note** It is recommended to :

- Take the system backup before running the command.
  - Collect the screen log information along with command line logs if the command fails and escalate it to Cisco TAC.
  - Ensure that only Cisco TAC runs the command.
  - Run the command on the server with obsolete data as the synchronization process deletes the data that clashes with the information on the other server.
- 

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

## utils cuc dbreplication 02\_define\_servers

This command establishes the network connectivity between the two Unity Connection servers in a cluster.

**utils cuc dbreplication 02\_define\_servers**

### Command Modes

Administrator (admin:)

### Usage Guidelines

You can use this command to track and report the CDR traffic from one server to another in a Unity Connection cluster. During SBR process, this command helps in defining the roles of the two server in a cluster.



---

**Note** It is recommended to :

- Take the system backup before running the command.
- Collect the screen log information along with command line logs if the command fails and escalate it to Cisco TAC.
- Ensure that only Cisco TAC runs the command.
- Run the command on the server with obsolete data as the synchronization process deletes the data that clashes with the information on the other server.



---

**Note** You should run this command on the server that has obsolete data in a Unity Connection cluster.

---

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

## utils cuc dbreplication 03\_define\_db\_template

This command creates the replication record of the set of tables in Unity Connection databases for replication synchronization. This command also negotiates the table templates of Unity Connection database on which the replication scheme needs to be established.

**utils cuc dbreplication 03\_define\_db\_template**

### Command Modes

Administrator (admin:)

### Usage Guidelines

This command lists all the tables and defines templates on basis of which the data is negotiated and synchronized between the two servers in a Unity Connection cluster.



---

**Note** It is recommended to :

- Take the system backup before running the command.
  - Collect the screen log information along with command line logs if the command fails and escalate it to Cisco TAC.
  - Ensure that only Cisco TAC runs the command.
  - Run the command on the server with obsolete data as the synchronization process deletes the data that clashes with the information on the other server.
- 

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

## utils cuc dbreplication 04\_sync\_database

This command synchronizes the database from the remote server to the server on which the command is executed.

### utils cuc dbreplication 04\_sync\_database

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

You should run this command on the server that has obsolete data in a Unity Connection cluster to copy the recent data from the remote server on the current server.



---

**Note** It is recommended to :

- Take the system backup before running the command.
  - Collect the screen log information along with command line logs if the command fails and escalate it to Cisco TAC.
  - Ensure that only Cisco TAC runs the command.
  - Run the command on the server with obsolete data as the synchronization process deletes the data that clashes with the information on the other server.
- 

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

# utils cuc dbreplication reset\_all

This command performs all the tasks, such as tear down and defining servers required to reset database replication between the two servers in a Unity Connection cluster.

## utils cuc dbreplication reset\_all

### Command Modes

Administrator (admin:)

### Usage Guidelines

This command executes the following commands sequentially to successfully reset database replication between the two servers in a Unity Connection cluster:

- utils cuc dbreplication01\_tear\_down
- utils cuc dbreplication 02\_define\_servers
- utils cuc dbreplication 03\_define\_db\_template
- utils cuc dbreplication 04\_sync\_database



**Note** It is recommended to :

- Take the system backup before running the command.
- Collect the screen log information along with command line logs if the command fails and escalate it to Cisco TAC.
- Ensure that only Cisco TAC runs the command.
- Run the command on the server with obsolete data as the synchronization process deletes the data that clashes with the information on the other server.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

# utils cuc encryption

This command enables, disables and provides the status of the encryption on Cisco Unity Connection.

**utils cuc encryption { enable | disable | status }**

### Syntax Description

Parameters	Description
enable	Enables the encryption on Unity Connection. When enabled, Unity connection allows you to use the security features.

Parameters	Description
disable	Disables the encryption on Unity Connection. When disabled, you can not use the security features in Unity Connection.
status	Displays the encryption status of the Unity Connection.

**Usage Guidelines**

When you enable the encryption on Unity Connection, make sure the following:

- The Cisco Unity Connection is registered with Cisco Smart Software Manager (CSSM) or Cisco Smart Software Manager satellite.
- Export Control Functionality is enabled for the product.

For more information on how to register and enable the Export Control Functionality for Cisco Unity Connection, see "Configuring Cisco Smart Software Licensing in Unity Connection" section of "Managing Licenses" chapter of *Install, Upgrade and Maintenance Guide for Cisco Unity Connection Release 12.x* available at

["https://www.cisco.com/c/en/us/td/docs/voice\\_ip\\_comm/connection/12x/install\\_upgrade/guide/b\\_12xcuciumg.html"](https://www.cisco.com/c/en/us/td/docs/voice_ip_comm/connection/12x/install_upgrade/guide/b_12xcuciumg.html).



**Note** In case of cluster, the CLI is executed only on publisher server.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Cisco Unity Connection

**Example**

```
admin:utils cuc encryption enable
After successful execution, restart the following services on all nodes in the cluster
```

```
1.Connection Conversation Manager
2.Connection IMAP Server
```

```
Do you want to proceed (yes/no)? yes
Encryption enabled successfully
```

## utils cuc jetty ssl disable

This command allows you to set the status of SSL (Disabled) on the Jetty Server for notifications.

**utils cuc jetty ssl disable**

**Command Modes**

Administrator (admin:)



**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

```
admin: utils cuc jetty ssl disable
```

After successful execution of this command restart of Jetty server is required, which will result in loss of current event subscriptions. Are you sure?

```
Enter (yes/no)? yes
```

Command completed successfully.

Please restart Connection Jetty Service.

In case of cluster, run this command on the other node also.

## utils cuc jetty ssl enable

This command allows you to enable the SSL on the Jetty Server for notifications.

**utils cuc jetty ssl enable****Usage Guidelines**

When you enable the SSL on the Jetty server, make sure the following:

- You are using the Restricted version of Cisco Unity Connection.
- The encryption is enabled on the Cisco Unity Connection.



**Note** In Evaluation Mode, you are not allowed to run the CLI command.

For more information, see "Cisco Unity Connection- Restricted and Unrestricted Version" chapter of Security Guide for Cisco Unity Connection Release 12.x available at

[https://www.cisco.com/c/en/us/td/docs/voice\\_ip\\_comm/connection/12x/security/b\\_12xcucsecx.html](https://www.cisco.com/c/en/us/td/docs/voice_ip_comm/connection/12x/security/b_12xcucsecx.html).

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection

**Example**

```
admin: utils cuc jetty ssl enable
```

After successful execution of this command restart of Jetty server is required, which will result in loss of current event subscriptions. Are you sure?

```
Enter (yes/no)? yes
```

```
Command completed successfully.
Please restart Connection Jetty Service.
In case of cluster, run this command on the other node also.
```

## utils cuc networking clear\_replication

This command stops all Digital Networking replication activities on the server.

### utils cuc networking clear\_replication

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

This command stops the Connection Digital Networking Replication Agent and Connection SMTP service, deletes the drop, queue, and pickup replication folders, clears the status of in-progress directory pushes to or pulls from this server, and restarts the Connection Digital Networking Replication Agent and Connection SMTP service. Depending on the size of the replication folders, this operation may take several minutes.

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Cisco Unity Connection

## utils cuc networking dscp

This command causes Connection either to start or to stop including a DSCP value of 18 in packets sent between the Connection servers in a cluster, so a router configured to prioritize packets based on their DSCP value can prioritize Connection data and voice messages.

```
utils cuc networking dscp {on | off}
```

#### Syntax Description

Parameters	Description
<b>on</b>	Causes Connection to start including a DSCP value of 18 packets sent over the network.
<b>off</b>	Causes to stop including a DSCP value of 18 in packets sent over the network. 18 is the default value.

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

This command makes the DSCP value available in the packets being passed between the Connection servers in a cluster. For the information to be used, you must configure the router. The command lets you control whether a DSCP value is included in outgoing packets, but you can not change the value.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only

## utils cuc reset password

This command resets the password for a specified user account. If Connection locked the account because of too many failed sign-in attempts, this command also unlocks the account.

**utils cuc reset password**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Cisco Unity Connection only

**Example**

```
admin: utils cuc reset password jdoe
Enter password:
Re-enter password:
jdoe
07/29/2008 12:41:14.704 : Update SUCCEEDED
```

## utils cuc set PinExpiry\_PromptTime "Authentication Rule Name"

This Command enables the Cisco Unity Connection telephone user interface (touchtone conversation) PIN feature and allows you to update the time interval during when the conditional expiry warning prompt will be played.

**Requirements**

If the value is set to:

- 0: disabled
- 1: enabled
- Enter the time interval

For more information on `utils cuc set PinExpiry_PromptTime "Authentication Rule Name"` CLI command, see the Cisco Unity Connection telephone user interface (touchtone conversation) PIN section in Release Notes for Cisco Unity Connection 10.0(1).

## utils dbreplication dropadmindb

This command drops the Informix syscdr database on any server in the cluster.

### utils dbreplication dropadmindb

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

You should run this command only if database replication reset or cluster reset fails and replication cannot be restarted.

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication forcedatasyncsub

This command forces a subscriber server to have its data restored from data on the publisher server.

**utils dbreplication forcedatasyncsub** *nodename* [**offloadpub**] [*timeoutvalue*]

#### Syntax Description

Parameters	Description
<i>nodename</i>	Specifies a particular subscriber server to have its data restored from data on the publisher server. Enter <b>a11</b> to restore data on all subscriber servers.
<b>offloadpub</b>	Minimizes the usage of the publisher server during the forcedatasyncsub process. <b>Note</b> Adding this option increases the time taken for forcedatasyncsub to finish.
<i>timeoutvalue</i>	Specifies the recovery timeout value for each node in minutes (should be greater than the default timeout). Default: 40 minutes.

#### Command Modes

Administrator (admin:)

#### Usage Guidelines

Use this command before you run the **utils dbreplication repair** command several times; but the utils dbreplication status command still shows non-dynamic tables that aren't in sync.



**Note** Don't run this command if only dynamic tables are out of sync; dynamic tables can be out of sync during normal system operation.

You can run this command only from the publisher server. Enter **all** to force sync on all subscriber servers in the cluster. If only one subscriber server is out of sync, use the *nodename* parameter.



**Note** This command erases all existing data on the subscriber server and replaces it with the database from the publisher server. This erasure makes it impossible to determine the root cause for the subscriber server tables going out of sync.

Reboot the subscriber node after the **utils dbreplication forcedatasyncsub** command is executed.



**Note** Cisco DB service will be in the stopped state in the subscriber node where the **utils dbreplication forcedatasyncsub** command is executed; unless reboot on the subscriber(s) is performed.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication quickaudit

This command runs a quick database check on selected content on dynamic tables.

**utils dbreplication quickaudit** {*nodename* | **all**}

**Syntax Description**

Parameters	Description
<i>nodename</i>	Specifies the node on which the quick audit should be run.
<b>all</b>	Causes the audit to be run on all nodes

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication rebuild

This command is used to set up database replication across the cluster and runs the following commands on the specified nodes:

- **utils dbreplication stop**
- **utils dbreplication dropadmindb** or **dropadmindbforce**
- **utils dbreplication reset**

**utils dbreplication rebuild** *{[nodename] | all}*

### Syntax Description

#### Parameters Description

- |                 |  |
|-----------------|--|
| <i>nodename</i> | Specifies the node or nodes on which database replication will be rebuilt.       |
| <b>all</b>      | Specifies that database replication will be rebuilt on all nodes in the cluster. |

### Command Modes

Administrator (admin:)

### Usage Guidelines



**Caution** This command can affect performance of other nodes in your cluster. We recommend that you run this command during a system maintenance window.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication repair

This command repairs database replication.

**utils dbreplication repair** *{nodename | all}*

### Syntax Description

#### Parameters Description

- |                 |   |
|-----------------|---|
| <i>nodename</i> | Specifies a particular subscriber server for data repair.   |
| <b>all</b>      | Causes data repair to take place on all subscriber servers. |

### Command Modes

Administrator (admin:)

**Usage Guidelines**

If the command **utils dbreplication status** shows that servers are connected but one or more tables have data that is out of sync, the **utils dbreplication repair** repairs the data on the subscriber servers so that the data is in sync with the data on the publisher server.

Specify **all** to repair all nodes in the cluster, or if only one subscriber server is out of sync, specify the *nodename* parameter.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

# utils dbreplication repairreplicate

This command repairs mismatched data between cluster nodes and changes the node data to match the publisher data.

**utils dbreplication repairreplicate** *replicatename* [{*nodename* | **all**}]

**Syntax Description**

Parameters	Description
<i>replicatename</i>	Specifies the replicate to repair.
<i>nodename</i>	Specifies the node on which to repair replication.
<b>all</b>	Specifies to fix replication on all nodes.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

The parameter *nodename* may not specify the publisher; any subscriber node name is acceptable.



**Note** This command can be executed on the publisher.



**Note** This command does not repair replication setup

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication repairable

This command repairs mismatched data between cluster nodes and changes the node to match the publisher data.

**utils dbreplication repairable** *tablename* [{*nodename* | **all**}]

### Syntax Description

Parameters	Description
<i>tablename</i>	Specifies the table to repair
<i>nodename</i>	Specifies the node on which to repair replication.
<b>all</b>	Specifies to fix replication on all nodes.

### Command Modes

Administrator (admin:)

### Usage Guidelines



**Note** This command does not repair replication setup.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication reset

This command resets and restarts database replication. You can use this command to rebuild replication when the system has not set up replication properly.

**utils dbreplication reset** {*nodename* | **all**}

### Syntax Description

Parameters	Description
<i>nodename</i>	Specifies a particular subscriber server to on which to have replication rebuilt.
<b>all</b>	Specifies that all subscriber servers in the cluster have replication rebuilt.



**Command Modes** Administrator (admin:)

**Usage Guidelines** This command is the best option to use when servers show an RTMT state of 4. If only one subscriber server shows an RTMT state of 4, you may reset that server by specifying the *hostname* parameter. To reset the entire cluster, use the **all** parameter.



**Tip** Before you run this command, first run the command **utils dbreplication stop** on all subscriber servers that are reset and then on the publisher server.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication runtimestate

This command monitors progress of the database replication process and provides replication state in the cluster.

**utils dbreplication runtimestate** *nodename*

Syntax Description	Parameters	Description
	<i>nodename</i>	Specifies the node to monitor.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If you provide a node name, the system provides the replication state from the context of the selected node.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication setprocess

This command improves replication performance of clusters that have nodes separated by WANs with delay (Clustering over WAN configuration).

**utils dbreplication setprocess** [*process*]

**Syntax Description****Parameters Description**

<b>process</b>	The new database replication . Ensure that the value is between 1 and 40. Default value: 1
----------------	---

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Caution**

Setting the PROCESS option to near maximum consumes more system resources.

Changes made to this setting after an upgrade but before the switch-over to the new version will need to be manually re-applied.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## utils dbreplication setreptimeout

This command sets the timeout for database replication on large clusters.

**utils dbreplication setreptimeout** *timeout*

**Syntax Description****Parameters Description**

<i>timeout</i>	The new database replication timeout, in seconds. Ensure that the value is between 300 and 3600. Default value: 300 (5 minutes)
----------------	--

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

After the first subscriber server requests replication with the publisher server, the system sets this timer. After the timer expires, the first subscriber server, plus all other subscriber servers that requested replication within that time period, begin data replication with the publisher server in a batch. If you have several subscriber servers, batch replication is more efficient than individual server replication. For large clusters, you can use the command to increase the default timeout value, so that more subscriber servers are included in the batch.

**Tip**

Cisco recommends that you restore this value back to the default of 300 (5 minutes) after you finish upgrading the entire cluster, and the subscriber servers have successfully set up replication.



**Note** After you upgrade the publisher server and restart it on the upgraded partition, you should set this timer value before you switch the first subscriber server to the new release. After the first subscriber server requests replication, the publisher server sets the replication timer based on the new value.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication status

This command shows the status of database replication and indicates whether the servers in the cluster are connected and the data is in sync.

**utils dbreplication status** {all | node | replicate}

Syntax Description	Parameters	Description
	all	Specifies to show the status of all servers.
	node	Specifies the node for which to show status.
	replicate	Specifies the replicate for which to show status.

**Command Modes** Administrator (admin:)

**Usage Guidelines**



**Note** You should run this command only on the first node (publisher server) of a cluster.

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils dbreplication stop

This command stops the automatic setup of database replication. Run this command on subscriber and publisher servers before executing the CLI command **utils dbreplication reset**. You can run this command on the subscriber servers simultaneously, before you run it on the publisher server.

```
utils dbreplication stop {nodename | all}
```

Syntax Description	Parameters	Description
	<i>nodename</i>	Specifies the name of the node on which to stop the automatic setup of database replication.
	<b>all</b>	Stops database replication on all nodes.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils imdb\_replication replication status

This command validates that In Memory Database (IMDB) replication between the node pairs in each subcluster of the deployment has run correctly.

The command performs writes and reads on IMDB tables in each relevant Datastore using a utility from the calling IM and Presence Service node.

```
utils imdb_replication status
```

**Command Modes** Administrator (admin:)

### Usage Guidelines

For the utility to run successfully, ports 6603, 6604, and 6605 must be opened on any firewalls that are configured between the nodes on the IM and Presence Service clusters.

This is not required for the normal operation of the IMDB.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: IM and Presence Service

## utils diagnose

This command enables you to diagnose and attempt to automatically fix system problems.

**utils diagnose** { **fix** | **list** | **test** | **version** } [*module\_name*]

Syntax Description	Parameters	Description
	<b>fix</b>	Runs all diagnostic commands and attempts to fix problems.
	<b>hcs</b>	Lists all the diagnostic commands available for HCS services.
	<b>list</b>	Lists all available diagnostic commands.
	<b>module</b>	Runs a single diagnostic command or group of commands and attempts to fix problems.
	<b>test</b>	Runs all diagnostic commands but does not attempt to fix problems.
	<b>version</b>	Displays the diagnostic framework version.
	<i>module_name</i>	Specifies the name of a diagnostics module.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0 for **version** and 1 for all other parameters

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery backup network

Displays information about the backup files that are stored on a remote server.

**utils disaster\_recovery backup network** [*featurelist*][*path*][*servername*][*username*]

Syntax Description	Parameters	Description
	[ <i>featurelist</i> ]	Specifies a list of features to back up, separated by commas.
	[ <i>path</i> ]	Represents the location of the backup files on the remote server.
	[ <i>servername</i> ]	Represents the IP address or hostname of the server where you stored the backup files.
	[ <i>username</i> ]	Represents the username that is needed to log in to the remote server.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system prompts you to enter the password for the account on the remote server.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery cancel\_backup

This command cancels the ongoing backup.

**utils disaster\_recovery cancel\_backup** [*confirm*]

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

After you enter the command, you must confirm that you want to cancel the backup. Enter **Y** to cancel the backup or any other key to continue the backup.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

**Example**

```
admin: utils disaster_recovery cancel_backup yes
Cancelling backup...
Backup cancelled successfully.
```

## utils disaster\_recovery device add network

This command adds the backup network device.

**utils disaster\_recovery device add network** *devicename path server\_name/ip\_address username*  
[*Number\_of\_backups*]

**Syntax Description**

Parameters	Description
<i>devicename</i>	Specifies the name of the backup device to be added (mandatory).
<i>path</i>	Specifies the path to retrieve the backup device (mandatory).
<i>server_name/ip_address</i>	Specifies the hostname or IP address of the server where the backup file is stored (mandatory).
<i>username</i>	Specifies the userid required to connect to the remote machine (mandatory).

Parameters	Description
[ <i>Number_of_backups</i> ]	Specifies the number of backups to store on the Network Directory (default 2). This parameter is optional.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

**Example**

```
admin: utils disaster_recovery device add network networkDevice /root 10.77.31.116 root 3
```

## utils disaster\_recovery device delete

This command deletes the specified device.

**utils disaster\_recovery device delete**  
*device\_name*\*

**Syntax Description**

Parameters	Description
<i>device_name</i>	Name of the device to be deleted.
*	Deletes all existing devices except for the ones associated to a schedule.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery device list

Displays the device name, device type, and device path for all the backup devices.

**utils disaster\_recovery device list**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery estimate\_tar\_size

This command provides the estimated size of last successful backup from SFTP or local device.

**utils disaster\_recovery estimate\_tar\_size** **utils disaster\_recovery device list**

**Syntax Description**

Parameters	Description
<b>featurelist</b>	Specifies a list of features to back up, separated by commas.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery history

This command displays the history of previous backups and restores.

**utils disaster\_recovery history** [*operation*]

**Syntax Description**

Parameters	Description
<i>operation</i>	Specifies backup or restore.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level:

Allowed during upgrade:



Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

### Example

```
admin: utils disaster_recovery history backup
Tar Filename: Backup Device: Completed On: Result: Backup Type: Features Backed Up:
2009-10-30-14-53-32.tar TAPE Fri Oct 30 14:55:31 CDT 2009 ERROR MANUAL
2009-12-10-10-30-17.tar TAPE Thu Dec 10 10:35:22 CST 2009 SUCCESS MANUAL CDR_CAR,CCM
```

## utils disaster\_recovery jschLogs operation

This command enables and disables the detailed JSch logging.

**utils disaster\_recovery jschLogs operation** [*operation*]

Syntax Description	Parameters	Description
	<i>operation</i>	Specifies the name of operation—enable or disable.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery prepare restore pub\_from\_sub

This command handles the tasks to prepare for restore of a publisher node from a subscriber node.



**Note** This command is applicable only when a publisher node is rebuilt and restored from the subscriber node database. A specific procedure is used for restore instead of restoring the data from the remote backup source. After a publisher node is rebuilt, you must use this command prior to the insertion of process node information.

**utils disaster\_recovery prepare restore pub\_from\_sub**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery restore network

This command restores a remote server. You must restore the Unified Communications Manager publisher node before you restore subscriber nodes in the same cluster. If you are restoring IM and Presence Service nodes, you must restore the database publisher node before you restore subscriber nodes in the same cluster.

**utils disaster\_recovery restore network** *restore\_server tarfilename devicename*

### Syntax Description

Parameters	Description
<i>restore_server</i>	Specifies the hostname of the remote server that you want to restore.
<i>tarfilename</i>	Specifies the name of the file to restore.
<i>devicename</i>	Specifies the name of the device on which to restore files.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery schedule add

This command adds the configured schedules.

**utils disaster\_recovery schedule add** *schedulename devicename featurelist datetime frequency*

### Syntax Description

Parameters	Description
<i>schedulename</i>	Represents the name of the scheduler (mandatory).
<i>devicename</i>	Represents the name of the device for which scheduling is done (mandatory).
<i>featurelist</i>	Represents the comma-separated feature list to back up (mandatory).
<i>datetime</i>	Represents the date when the scheduler is set (mandatory). Format specified (yyyy/mm/dd-hh:mm) 24-hr clock.
<i>frequency</i>	Represents the frequency at which the schedule is set to take a backup. Examples: once, daily, weekly and monthly.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery schedule

This command enables or disables the specified schedule.

**utils disaster\_recovery schedule** {enable | disable} [*schedulename*]

**Syntax Description**

Parameters	Description
<b>enable</b>	Enables the specified schedule.
<b>disable</b>	Disables the specified schedule.
<i>schedulename</i>	Represents the name of the scheduler.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

**Example**

```
admin: utils disaster_recovery schedule enable schedule1
Schedule enabled successfully.
```

## utils disaster\_recovery schedule delete

This command deletes the configured schedules.

**utils disaster\_recovery schedule delete** *schedulename*

**Syntax Description**

Parameters	Description
<i>schedulename</i>	Represents the name of the schedule that is to be deleted.

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery schedule disable

This command disables the configured schedules.

**utils disaster\_recovery schedule disable** *schedulename*

---

**Syntax Description**

---

Parameters	Description
------------	-------------

<i>schedulename</i>	Represents the name of the schedule that is to be disabled.
---------------------	---

---



---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery schedule list

Displays the schedules that are configured.

**utils disaster\_recovery schedule list**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

**Example**

```
admin: utils disaster_recovery schedule list
schedule name device name Schedule Status
-----
schedule1      device 1      enabled
schedule2      device 2      disabled
```

## utils disaster\_recovery show\_backupfiles

This command retrieves the information of backup files, which are available at storage location.

**utils disaster\_recovery show\_backupfiles** *devicename*

**Syntax Description****Parameters Description**

*devicename* Represents the name of the device to show backup files at the storage location.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery show\_registration

This command displays the registered features and components on the specified server.

**utils disaster\_recovery show\_registration** *hostname*

**Syntax Description****Parameters Description**

*hostname* Specifies the server for which you want to display registration information.

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils disaster\_recovery status

This command displays the status of the current backup or restore job.

**utils disaster\_recovery status** *operation*

Syntax Description	Parameters	Description
	<i>operation</i>	Specifies the name of the ongoing operation: backup or restore.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils EnhancedSecurityMode disable

The command disables the EnhancedSecurityMode mode on the system. The system reboots after this mode is disabled.

**utils EnhancedSecurityMode disable**

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils EnhancedSecurityMode enable

The command enables the EnhancedSecurityMode mode on the system. The system reboots after this mode is enabled.

**utils EnhancedSecurityMode enable**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils EnhancedSecurityMode status

The command displays whether the system is operating in EnhancedSecurityMode or non-EnhancedSecurityMode mode.

**utils EnhancedSecurityMode status**

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils filebeat config

The command configures the Logstash server details for downloading the information.

**utils filebeat config IP address port number log type**

Syntax Description	Parameters	Description
	<b>IP address</b>	Enter the IP address of the Logstash server.
	<b>port number</b>	Enter the port number of Logstash server.
	<b>log type</b>	Enter the log type that you have to uploaded to the Logstash server.

You can also secure the FileBeat service by enabling TLS. The following prompt is displayed after setting the parameters.

```
Do you wish to secure the filebeat service by enabling TLS?
```

```
Enter (yes/no) ?
```

Enter **Yes** to enable TLS.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils filebeat disable

The command disables the filebeat configuration on the system.

**utils filebeat disable**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils filebeat enable

The command enables the filebeat configuration on the system.

**utils filebeat enable**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils filebeat status

The command shows whether the filebeat is running or not and its configuration values.

**utils filebeat status**

---

**Command Modes**

Administrator (admin:)



**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils filebeat tls

This command configures Transport Layer Security (TLS) 1.2 as the protocol for communication between the FileBeat client and the logstash server. This enables a secure connection between the FileBeat client and the logstash server, which is a requirement for compliance with Common Criteria guidelines.

In Common Criteria Mode, strict host name verification is implemented. Hence, it is required to configure the server with a fully qualified domain name (FQDN) which matches the certificate.

**utils filebeat tls** {enable | disable | status}

**Syntax Description**

Parameters	Description
<b>enable</b>	Enables a secure connection between the FileBeat client and the logstash server.
<b>disable</b>	Disables the TLS for FileBeat client.
<b>status</b>	Displays the status for TLS.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

A security certificate has to be uploaded from logstash server to the tomcat trust store on Unified Communications Manager and IM and Presence Service.

## utils fior

This command allows you to monitor the I/O on the server. The File I/O Reporting service provides a kernel-base daemon for collecting file I/O per process.

**utils fior**

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior disable

This command disables I/O statistics monitoring and deletes all the monitoring data collected on the system. Use this command to disable monitoring and free up disk space that is used by the monitoring data.

### utils fior disable

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior enable

This command enables I/O statistics monitoring.




---

**Note** Use this command before monitoring begins.

---

### utils fior enable

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior list

This command displays a list of the I/O events for all processes.

### utils fior list

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior start

This command starts the I/O statistics utility monitoring and data collection. After the monitoring starts, the I/O statistics data is collected in the platform logs. This data can range up to 25 MB per day. Data is rotated after 7 days of data collection. This data is deleted after you disable the I/O statistics utility monitoring.



---

**Note** Enable the I/O statistics utility monitoring begins before the monitoring begins.

---

**utils fior start**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior status

This command provides the status of the I/O statistics monitoring utility.

**utils fior status**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior stop

This command stops the I/O statistics monitoring and data collection. However, this command does not delete the collected data.




---

**Note** If I/O statistics are no longer needed, disable the cleanup of the monitoring data from the platform logs.

---

### utils fior stop

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fior top

This command displays a list of I/O statistics for I/O bound processes at the time that you run this command.

### utils fior top

#### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fips




---

**Caution** FIPS mode is only supported on releases that have been through FIPS compliance. Be warned that FIPS mode should be disabled before you upgrade to a non-FIPS compliance version of Unified Communications Manager.

For information about which releases are FIPS compliant and to view their certifications, see the *FIPS 140* document at <https://www.cisco.com/c/en/us/solutions/industries/government/global-government-certifications/fips-140.html>.

---

This command enables, disables, or displays the status of FIPS 140-2 mode. FIPS 140-2 mode is disabled by default; only an administrator can enable FIPS.

**utils fips** {**enable** | **disable** | **status**}

Syntax Description	Parameters	Description
	<b>enable</b>	Activates FIPS 140-2 mode.
	<b>disable</b>	Deactivates FIPS 140-2 mode.
	<b>status</b>	Displays the status of FIPS 140-2 mode.

**Command Modes** Administrator (admin:)

**Usage Guidelines** Before enabling FIPS mode, we recommend that you perform a system backup. If FIPS checks fail at start-up, the system halts and requires a recovery CD to be restored.

Consider the following information before you enable FIPS 140-2 mode:

- When you switch from non-FIPS to FIPS mode, the MD5 and DES protocols will not be functional.
- After FIPS mode is enabled on a server, please wait until the server reboots and the phones re-register successfully before enabling FIPS on the next server.
- In FIPS mode, the IM and Presence Service uses Red Hat Openswan (FIPS validated) in place of Racoon (non-FIPS validated). If the security policies in Racoon contain functions that are not FIPS approved, the CLI command asks you to redefine the security policies with FIPS approved functions and abort.



**Note** Certificates and SSH key are regenerated automatically, in accordance with FIPS requirements.

Consider the following information before you disable FIPS 140-2 mode: In multiple server clusters, each server must be disabled separately; FIPS mode is not disabled cluster-wide but on a per server basis.

Consider the following information after you enable FIPS 140-2 mode: If you have a single server cluster and chose to apply "Prepare Cluster for Rollback to pre 8.0" enterprise parameter before enabling FIPS mode, disable this parameter after making sure that all the phones registered successfully with the server.

Consider the following information before you enable or disable FIPS 140-2 mode for IM and Presence Service: After you enable or disable FIPS 140-2 mode for IM and Presence Service, the Tomcat certificate is regenerated and the node reboots. The Intercluster Sync Agent syncs the new Tomcat certificate across the cluster; this can take up to 30 minutes. Until the new Tomcat certificate is synced across the cluster, an IM and Presence Service subscriber node cannot access information from the IM and Presence Service database publisher node. For example, a user who is logged into the Cisco Unified Serviceability GUI on a subscriber node will not be able to view services on the IM and Presence Service database publisher node. Users will see the following error message until the sync is complete: `Connection to server cannot be established (certificate exception)`

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils fips\_common\_criteria

This command configures the Common Criteria mode in the system.

```
utils fips_common_criteria {enable | disable | status}
```

Syntax Description	Parameters	Description
	<b>enable</b>	Enables the Common Criteria mode in the system
	<b>disable</b>	Disables the Common Criteria mode in the system When Common Criteria mode is disabled, a prompt is displayed to set the minimum TLS version.
	<b>status</b>	Displays the status of Common Criteria mode in the system

**Command Modes** Administrator (admin:)

**Usage Guidelines** Secure connections using TLS version 1.0 are not permitted after enabling the Common Criteria mode. FIPS mode will be enabled while enabling Common Criteria mode. Enabling or disabling Common Criteria mode does not require certificates to be regenerated. However, enabling or disabling FIPS does require rebooting of the system along with regeneration of certificates.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service



**Note** This CLI command is not applicable to Cisco Unity Connection.

## utils firewall ipv4 debug

This command turns IPv4 firewall debugging on or off. If you do not enter a time parameter, this command turns on debugging for 5 minutes.

```
utils firewall ipv4 debug {off[time]}
```

Syntax Description	Parameters	Description
	<b>off</b>	Turns off the IPv4 firewall debugging. If you do not enter the time parameter, this command disables the firewall for 5 minutes.
	<i>time</i>	(Optional) Sets the duration for which the firewall debugging is to be enabled in the following formats: <ul style="list-style-type: none"> <li>• Minutes: 0–1440m</li> <li>• Hours: 0–23h</li> <li>• Hours and minutes: 0–23h 0–60m</li> </ul>

Command Modes	Administrator (admin:)
	<b>Requirements</b>
	Command privilege level: 1
	Allowed during upgrade: Yes
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv4

This commands enables and disables IPv4 firewall.

**utils firewall ipv4** {**enable** | **disable**[*time*]}

Syntax Description	Parameters	Description
	<b>enable</b>	Turns on the IPv4 firewall.
	<b>disable</b>	Turns off the IPv4 firewall. If you do not enter the time parameter, this command disables the firewall for 5 minutes.
	<i>time</i>	(Optional) Sets the duration for which the firewall is to be disabled in the following formats: <ul style="list-style-type: none"> <li>• Minutes: 0–1440m</li> <li>• Hours: 0–23h</li> <li>• Hours and minutes: 0–23h 0–60m</li> </ul>

Command Modes	Administrator (admin:)
	<b>Requirements</b>
	Command privilege level: 1
	Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv4 list

This commands displays the current configuration of the IPv4 firewall.

### utils firewall ipv4 list

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv4 status

This command displays the current status of the IPv4 firewall.

### utils firewall ipv4 status

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv6 debug

This command turns IPv6 firewall debugging on for the configured time period. The default value of time period is 5 minutes.



---

**Note** IPv6 is not supported in Cisco Business Edition 5000.

---

**utils ipv6 firewall debug** {off[time]}



Syntax Description	Parameters	Description
	<b>off</b>	(Optional) Turns off the IPv6 firewall debugging. If you do not enter the time parameter, this command disables the firewall as per the default time period value.
	<i>time</i>	(Optional) Sets the duration for which the firewall debugging is to be enabled in the following formats: <ul style="list-style-type: none"> <li>• Minutes: 0–1440m</li> <li>• Hours: 0–23h</li> <li>• Hours and minutes: 0–23h 0–60m</li> </ul>

Command Modes	Administrator (admin:)
	<b>Requirements</b>
	Command privilege level: 1
	Allowed during upgrade: Yes
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv6

This commands enables and disables IPv6 firewall.



**Note** IPv6 is not supported in Cisco Business Edition 5000.

**utils firewall ipv6** {**enable** | **disable**[*time*]}

Syntax Description	Parameters	Description
	<b>enable</b>	Turns on the IPv6 firewall.
	<b>disable</b>	Turns off the IPv6 firewall. If you do not enter the time parameter, this command disables the firewall for 5 minutes.
	<i>time</i>	(Optional) Sets the duration for which the firewall is to be disabled in the following formats: <ul style="list-style-type: none"> <li>• Minutes: 0–1440m</li> <li>• Hours: 0–23h</li> <li>• Hours and minutes: 0–23h 0–60m</li> </ul>

Command Modes	Administrator (admin:)
---------------	------------------------

**Usage Guidelines**

You can use this command to enable or disable firewall tables. If you are testing the Unified Communications Manager for compliance with the USGv6 Profile, you must disable the IPv6 firewall tables for a duration of 23 hours before you begin the test.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv6 list

This commands displays the current configuration of the IPv6 firewall.




---

**Note** IPv6 is not supported in Cisco Business Edition 5000.

---

**utils firewall ipv6 list****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils firewall ipv6 status

This command displays the current status of the IPv6 firewall.




---

**Note** IPv6 is not supported in Cisco Business Edition 5000.

---

**utils firewall ipv6 status****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils ha failover

This command initiates a manual failover for a specified node, where the Cisco Server Recovery Manager stops the critical services on the failed node and moves all users to the backup node.

For IM and Presence Service nodes, the backup node must be another IM and Presence Service. Two servers must be assigned to the same presence redundancy group before you specify the backup server. The back-up server you specify is the other server that is assigned to the presence redundancy group.

**utils ha failover** {node name}

Syntax Description	Parameters	Description
	<b>node name</b>	Specifies the node on which to perform the manual failover.

**Command Modes** Administrator (admin:)

### Requirements

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

### Failover Example

```
admin: ha failover shorty-cups
Initiate Manual Failover for Node > shorty-cups
Request SUCCESSFUL.
Subcluster Name: DefaultCluster
Node 1 Name : kal-cup1 State: Taking Over Reason: On Admin Request
Node 2 Name : shorty-cups State: Failover Reason: On Admin Request
```

## utils ha fallback

This command initiates a manual fallback for a specified node, where the Cisco Server Recovery Manager restarts the critical services on the active node and moves users back to the active node.

**utils ha fallback** *node name*

Syntax Description	Parameters	Description
	<i>node name</i>	Specifies the node on which to perform a manual fallback.

**Command Modes** Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

**Fallback Example**

```
admin: ha fallback shorty-cups
Initiate Manual fallback for Node >shorty-cups<
Request SUCCESSFUL.
Subcluster Name: DefaultCluster
Node 1 Name : kal-cup1 State: Falling Back Reason: On Admin Request
Node 2 Name : shorty-cups State: Taking Back Reason: On Admin Request
```

# utils haproxy set {required|optional|disable} client-auth

This command sets the value of client authentication on a specified port. The supported values for authentication are Required, Optional, or Disable.

The following table depicts the default values for the ports.

*Table 2: Default Values for the Ports*

Port	Default Value
6971	Optional
6972	Optional
9443	Required



**Warning** Setting the client authentication to anything other than default value could have serious implications. Please change these values only as per Cisco TAC team advise.

**utils haproxy set {required | optional | disable} client-auth *portnum***

**Syntax Description**

Parameter	Description
<i>portnum</i>	Enter the port number to set HAProxy client authentication.  <b>Note</b> The supported port numbers are 6971, 6972 and 9443.
<b>required</b>	Sets the value of client authentication to “required” on a specified port.
<b>optional</b>	Sets the value of client authentication to “optional” on a specified port.

Parameter	Description
disable	Sets the value of client authentication to “disable” on a specified port.

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

- If the user enters a *portnum* value other than 6971, 6972 or 9443, an error message is displayed to enter a valid port number.
- Administrator can execute the **help utils haproxy set optional client-auth** command to view the help content.
- The configured client-auth value for the *portnum* is retained during the upgrades and while performing a backup using Disaster Recovery System (DRS) and restore.
- If you set client authentication to “required”, then server requests for a certificate from the clients. The client must present the requested certificate to the server. Hence, the request can forward to the further services.
- If you set client authentication to “optional”, then server requests for a certificate from the clients. Although if the client does not present the requested certificate to the server, the request can forward to the further services.
- If you set client authentication to “disable”, then the server will not request for a certificate from the clients.
- The HAProxy process restarts when you execute this command.

**Requirements**

Command privilege level: 1

Applies to: Unified Communications Manager

**Example**

```
admin:utils haproxy set required client-auth 6971
```

```
This command will result in the HA Proxy service set the client authentication as per your specification and restart the HAProxy process. Restarting of the HAProxy process might result in momentary disconnection of all Phones and Jabber clients that are accessing this service for secure configuration file downloads. It is recommended this operation be performed during off-busy hours and ensure there are no TFTP operations in progress.
Warning: Setting the client authentication to anything other than default value could have serious implications.
Please change these values only as per Cisco TAC team's advise
Do you want to continue (yes/no) ? yes

Successfully set client authentication to required

HAProxy Process already running .. restarting
```

```

admin:

admin:utils haproxy set disable client-auth 6972

HAProxy client authentication is already set to
disable on port 6972 . No action will be taken.

admin:utils haproxy client-auth set 1234 disable
Please enter valid values for the port.
Supported values are 6971, 6972 and 9443

admin:help utils haproxy set required client-auth 6971

utils haproxy set required client-auth
This command updates the value of client authentication
as required on specified port.
Example:
admin:utils haproxy set required client-auth 6971
HAProxy client authentication is already set to
required on port 6971. No action will be taken.
admin:

```

## utils haproxy set num-threads

This command sets the number of threads, spawn by the HAProxy service.



**Warning** Setting this parameter to anything other than default value could have serious implications. Please change these values only as per Cisco TAC team's advice.

**utils haproxy set num-threads** *numThreads*

Syntax Description	Parameter	Description
	<i>numThreads</i>	Enter the number of HAProxy threads to be configure.
	<b>Note</b>	The default value is 1. The supported values for the number of threads are 1, 2, 3 and 4.

**Command Modes** Administrator (admin:)

- Usage Guidelines**
- If the user enters a *numThreads* value other than 1, 2, 3 or 4, an error message is displayed to enter a valid number of HAProxy threads.
  - Administrator can execute the **help utils haproxy set num-threads** command to view the help content.
  - The configured numThreads value is retained during the upgrades as well as while performing a backup using Disaster Recovery System (DRS) and restore.
  - The HAProxy process restarts when you execute this command.

**Requirements**

Command privilege level: 1

Applies to: Unified Communications Manager

**Example**

```
admin:utils haproxy set num-threads 3
```

```
This command will result in the HAProxy service spawn as many threads
as you have specified and restart the HAProxy process. Restarting of
the HAProxy process might result in momentary disconnection of all
Phones and Jabber clients that are accessing this service for
secure configuration file downloads and authenticated users data
access. It is recommended this operation be performed during
off-busy hours and ensure there are no TFTP operations in progress.
Warning: Setting this parameter to anything other than default
value could have serious implications. Please change these values
only as per Cisco TAC team's advise
Do you want to continue (yes/no) ? yes
```

```
Successfully set number of HAProxy threads to 3
```

```
Restarting HAProxy process
admin:
```

```
admin:utils haproxy set num-threads 5
Please enter a valid number of HAProxy threads.
Supported values are 1, 2, 3 and 4
```

# utils ha recover

This command initiates a manual recovery of the presence redundancy group (when nodes are in a Failed state), where IM and Presence restarts the Cisco Server Recovery Manager service in that presence redundancy group.

**utils ha recover** *presence redundancy group name*

Syntax Description	Parameters	Description
	<i>presence redundancy group name</i>	Specifies the presence redundancy group on which to monitor HA status. If no presence redundancy group name is provided, all cluster information is provided.

**Command Modes** Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

**Recover Example**

```
admin: ha recover DefaultCluster
Stopping services... Stopped
Starting services... Started
admin:
```

## utils ha status

This command displays the HA status for a specified presence redundancy group.

**utils ha status** *presence redundancy group name*

Syntax Description	Parameters	Description
	<i>presence redundancy group name</i>	Specifies the presence redundancy group for which to monitor HA status. If no presence redundancy group name is provided, all cluster information is displayed.

**Command Modes**

Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

**Status Example with HA Not Enabled**

```
admin: ha status
Subcluster Name: DefaultCluster
Node 1 Name : kal-cup1 State: Unknown Reason: High Availability Not Enabled
Node 2 Name : shorty-cups State: Unknown Reason: High Availability Not Enabled
```

**Status Example with HA Enabled**

```
admin: ha status
Subcluster Name: DefaultCluster
Node 1 Name : kal-cup1 State: Normal
Node 2 Name : shorty-cups State: Normal
```

**Status Example with a Critical Service Down**

```
admin: ha status
Subcluster Name: DefaultCluster
Node 1 Name : kal-cup1 State: Failed Over with Critical Services not Running Reason:
Critical Service Down
Node 2 Name : shorty-cups State: Running in Backup Mode Reason: Critical Service Down
```



**Status Example Failed**

```
admin: ha status
Subcluster Name: DefaultCluster
Node 1 Name : kal-cup1 State: Failed Reason: Critical Service Down
Node 2 Name : shorty-cups State: Failed Reason: Critical Service Down
```

## utils ils showpeerinfo

This command returns the peer info vector for either a single cluster in an ILS network, or for all the clusters in an ILS network.

**utils ils showpeerinfo** *clustername*

Syntax Description	Parameters	Description
	<i>clustername</i>	Specifies the fully qualified domain name of the publisher node for a Unified Communications Manager cluster in an ILS network.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The peer info vector contains information about a cluster in an ILS network. The available information includes clustername, cluster ID and IP addresses for the cluster nodes. If you want information about a specific cluster in an ILS network, enter the *clustername* parameter. If you want information on all the clusters in the network, leave the *clustername* parameter empty

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager

## utils import config

This command takes data from the platformConfig.xml file on the virtual floppy drive and modifies the system to match the configuration file. The system reboots after the command successfully completes.

**utils import config**

**Command Modes** Administrator (admin:)

**Usage Guidelines** This command can be executed on any VMware deployment.

1. Power on the VMware.
2. Use the Answer File Generator (AFG) tool ( [http://www.cisco.com/web/cuc\\_afg/index.html](http://www.cisco.com/web/cuc_afg/index.html) ) to create a platformConfig.xml file.

3. Insert the Config.xml file into a virtual floppy instance (see [http://kb.vmware.com/selfservice/microsites/search.do?language=en\\_US&cmd=displayKC&externalId=1739](http://kb.vmware.com/selfservice/microsites/search.do?language=en_US&cmd=displayKC&externalId=1739) for directions).
4. Mount the .flp file in the floppy drive of the new VMware.
5. Sign in to the CLI of the VM (with console or SSH) and execute the **utils import config** command.  
The command cycles through all of the data found in the xml file and if data is found that is different than what is currently set on the VM, it modifies the VM to match the new data.
6. The system reboots with the new identity.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## Execute utils import config in VMware Deployment

### Procedure

---



---

## utils iostat

This command displays the iostat output for the given number of iterations and intervals.

**utils iostat** {**interval** | **iterations** | **filename**}

### Syntax Description

Parameters	Description
<b>interval</b>	Sets the seconds between two iostat readings. You must set this value if you are using the iteration parameter
<b>iterations</b>	Sets the number of iostat iterations. You must set this value if you are using the interval parameter.
<b>filename</b>	Redirects the output to a file.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils iothrottle

This command allows you to manage and monitor IO throttling on the server.

**utils iothrottle** {**enable** | **disable** | **status**}

Syntax Description	Parameters	Description
	<b>Enable</b>	Enables I/O throttling enhancements which lowers the impact of upgrades on an active system.
	<b>Disable</b>	Disables I/O throttling enhancements.
	<b>Status</b>	Displays the status of I/O throttling enhancements.

**Command Modes** Administrator (admin:)

**Usage Guidelines** Disabling I/O throttling enhancements can adversely affect the system during upgrades.

### Requirements

Command privilege level: 1 for **Enable** and **Disable**, 0 for **Status**

## utils itl reset

This command is used when endpoints are unable to validate their configuration files.

**utils itl reset** {**localkey** | **remotekey**}

Syntax Description	Parameters	Description
	<b>localkey</b>	Generates a new ITL file by taking the existing ITL file on the publisher. The command replaces the signature of that ITL file and signs the new ITL file with the CallManager certificate key.
	<b>remotekey</b>	Generates a new ITL file after importing the PKCS 12 bag that contains the recovery certificate key pair from the remote location. It then signs the newly generated ITL file with the recovery private key.
	<b>remotekey</b> has the following parameters:	
	<ul style="list-style-type: none"> <li>• IP address or hostname</li> <li>• User ID</li> <li>• ITLRecovery.p12</li> </ul>	

**Command Modes** Administrator (admin:)

---

**Usage Guidelines**



---

**Note** You must run this command on the publisher node.

---

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to:

**Example**

```

admin:utils itl reset

Name is None

Generating the reset ITL file.....

The reset ITL file was generated successfully

Locating active Tftp servers in the cluster.....

Following is the list of Active tftp servers in the cluster
=====
se032c-94-42
=====

Number of Active TFTP servers in the cluster : 1

Transferring new reset ITL file to the TFTP server nodes in the cluster.....

Successfully transferred reset ITL to node se032c-94-42

```

## utils ipsec restart

This command is used to restart the ipsec service.

**utils ipsec restart**


---

**Command Modes**

Administrator (admin:)

**Requirments**

Command privilege level:1

Allowed during upgrade: No

Applies to: Unified Communications Manager

**Example**

```

admin:utils ipsec restart
ipsec_setup: Stopping Openswan IPsec...
ipsec_setup: stop ordered, but IPsec appears to be already stopped!
ipsec_setup: doing cleanup anyway...
ipsec_setup: Starting Openswan IPsec U2.6.32/K2.6.32-573.18.1.el6.x86_64...
ipsec_setup: /usr/libexec/ipsec/addconn Non-fips mode set in /proc/sys/crypto/fips_enabled
ipsec_setup: pluto appears to be running already ('/var/run/pluto/pluto.pid' exists), will
not start another
Successfully Restarted IPsec Service
admin:

```

## utils ldap config

This command configures the system LDAP authentication.

**utils ldap config** *{fqdn|ipaddr}*

**Syntax Description**

Parameters	Description
<i>fqdn</i>	Configures the system to use an FQDN for LDAP authentication.
<i>ipaddr</i>	Configures the system to use an IP address for LDAP authentication

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

- **utils ldap config fqdn**—This command is preferred for LDAP authentication, however, you can only use this command if DNS is configured on the system; if the system is not configured to use DNS, use **utils ldap config ipaddr**.
- **utils ldap config ipaddr**—This command is not preferred and should only be used if the system is not, or can not be, configured to use DNS; if the system is configured to use DNS, use **utils ldap config fqdn**.

**Requirements**

Command privilege level: 1

Applies to: Unified Communications Manager and Cisco Unity Connection

## utils ldap config status

This command displays the utils ldap configuration status.

**utils ldap config status**

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils managementAgent alarms minpushLevel

If Push Notifications is enabled, run this command to configure the minimum alarm severity for which Unified Communications Manager sends push notifications alarms to the Cisco cloud.

**utils managementAgent alarms minpushLevel***severity*

Syntax Description	Parameters	Description
	<i>severity</i>	This value represents the minimum alarm severity for which Unified Communications Manager sends Push Notifications alarms to the Cisco cloud. The possible options are: <ul style="list-style-type: none"> <li>• Critical</li> <li>• Error (this is the default)</li> <li>• Warning</li> <li>• Notice</li> <li>• Information</li> </ul>

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service

## utils managementAgent alarms pushfrequency

If Push Notifications is enabled, run this command to configure the interval following which Unified Communications Manager sends push notifications alarms to the Cisco cloud.

**utils managementAgent alarms pushfrequency***minutes*

Syntax Description	Parameters	Description
	<i>minutes</i>	The upload frequency in minutes. This value must be an integer between 5 and 90 with a default of 30 minutes.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service

## utils managementAgent alarms pushnow

If Push Notifications is enabled, run this command to send push notifications alarms to the Cisco cloud immediately, without having to wait for the next scheduled upload.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service

## utils network arp delete

This command deletes an entry in the Address Resolution Protocol table.

**utils network arp delete** *host*

### Syntax Description

Parameters	Description
<i>host</i>	(Optional) Represents the host name or IP address of the host to delete from the table.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Delete Example

```
admin:utils network arp delete myhost
```

## utils network arp set

This command sets an entry in the Address Resolution Protocol table.

**utils network arp set** *{host}* *{addr}*

Syntax Description	Parameters	Description
	<i>host</i>	Represents the host name or IP address of the host to add to the table.
	<i>addr</i>	Represents the hardware address (MAC) of the host to be added in the format: XX:XX:XX:XX:XX:XX

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**Set Example**

```
admin:utils network arp set myhost 11:22:33:44:55:66
```

## utils network arp list

This command lists the contents of the Address Resolution Protocol table.

```
utils network arp list host hostname [options]
```

Syntax Description	Parameters	Description
	<b>host</b>	
	<i>hostname</i>	
	<i>options</i>	(Optional) page, numeric <ul style="list-style-type: none"> <li>• Page: Pauses to display the output one page at a time.</li> <li>• Numeric: Shows hosts as dotted IP addresses.</li> </ul>

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

In the Flags column, C=cached, M=permanent, P=published.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes



Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

**List example**

```
admin:admin: utils network arp listAddress HWtype HWaddress
Flags Mask Iface
sjc21-3f-hsrp.cisco.com ether 00:00:0C:07:AC:71 C
eth0
philly.cisco.com ether 00:D0:B7:85:98:8E C
eth0
Entries: 2 Skipped: 0 Found: 2
```

# utils network capture

This command captures IP packets on the specified Ethernet interface.

```
utils network capture eth0 [page] [numeric] [{filename}] [{countnum}] [{sizebytes}] [{srcaddr}]
[{destaddr}] [{portnum}]
```

**Syntax Description**

Parameters	Description
<b>eth0</b>	Specifies Ethernet interface 0.
<i>page</i>	(Optional) Displays the output one page at a time.  When you use the page or file options, the complete capture of all requested packets must occur before the command completes.
<i>numeric</i>	(Optional) Displays hosts as dotted IP addresses.
<b>file</b> <i>fname</i>	(Optional) Outputs the information to a file.  The file option saves the information to <code>platform/cli/fname.cap</code> . The filename cannot contain the “.” character.
<b>countnum</b>	(Optional) Sets a count of the number of packets to capture.  For screen output, the maximum count equals 1000, and, for file output, the maximum count equals 10,000.
<b>sizebytes</b>	(Optional) Sets the number of bytes of the packet to capture.  For screen output, the maximum number of bytes equals 128, for file output, the maximum of bytes can be either 262144 bytes or ALL.
<b>src addr</b>	(Optional) Specifies the source address of the packet as a host name or IPV4 address.
<b>destaddr</b>	(Optional) Specifies the destination address of the packet as a host name or IPV4 address.
<b>portnum</b>	(Optional) Specifies the port number of the packet, either source or destination.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils network capture-rotate

This command captures IP packets beyond the 100,000 packet limit of **utils network capture**.

**utils network capture-rotate** *{filename}* [*{sizebytes}*] [*{sizePerFilemegabytes}*] *{maxFiles num}* [*{srcaddr}*] [*{destaddr}*] [*{portnum}*][*{host protocoladdr}*]

Syntax Description	Parameters	Description
	<b>file</b> <i>fname</i>	Outputs the information to a file.  <b>Note</b> The file will be saved in platform/cli/fname. fname should not contain the "." character.
	<b>sizebytes</b>	The number of bytes of the packet to capture. Valid values include any number up to 65535 or ALL. The default is ALL.
	<b>sizePerFile</b> <i>megabytes</i>	The sizePerFile sets the value for the size of the log files. (Unit is millions of bytes.) The default value of sizePerFile is 25 MB.
	<b>maxFiles</b> <i>num</i>	the maxFiles indicates the maximum number of log files to be created. The default value of maxFiles is 10.
	<b>src</b> <i>addr</i>	(Optional) Specifies the source address of the packet as a hostname or IPV4 address.
	<b>dest</b> <i>addr</i>	(Optional) Specifies the destination address of the packet as a host name or IPV4 address.
	<b>port</b> <i>num</i>	(Optional) Specifies the port number of the packet, either source or destination.
	<b>host</b> <i>protocol addr</i>	(Optional) Limits capture to traffic to and from a specific host. Options for <i>protocol</i> are IP, arp, rarp, all, and <i>addr</i> must be in IPv4 or hostname format. If <b>host</b> is used, do not provide <b>src</b> or <b>dest</b> .

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

# utils network connectivity

This command verifies the node network connection to the first node in the cluster (this connection is only valid on a subsequent node) and to a remote node.

**utils network connectivity** [{reset}] [hostname/ip address]

utils network connectivity [hostname/ip address] [port-number] [timeout]

Syntax Description	Parameters	Description
	<b>connectivity</b>	This command verifies the node network connection to the first node in the cluster.  It is also used to check connectivity to a remote node, where there are two mandatory parameters, <b>hostname/ip address</b> and <b>port-number</b> .
	<b>reset</b>	(Optional) Clears previous return codes.
	<i>hostname/ip address</i>	<ul style="list-style-type: none"> <li>(Optional) Hostname or IP address of cluster node to check network connectivity with the publisher or the first node.</li> <li>(Mandatory) Hostname or IP address of the host that has to be tested for the TCP connection, to check network connectivity on the remote server.</li> </ul>
	<b>port-number</b>	(Mandatory) Port number of the host that requires connection test.
	<i>timeout</i>	(Optional) Specifies the time in seconds after which port connectivity message is displayed.

**Command Modes** Administrator (admin:)

- Usage Guidelines**
- The **utils network connectivity** [reset] [hostname/ip address] command is used to check the network connectivity to the publisher or the first node.
  - The **utils network connectivity** [hostname/ip address] [port-number] [timeout] command is used to check the network connectivity to a remote server.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils network host

This command resolves a host name to an address or an address to a host name.

**utils network host** *name* [{server*serv*}] [**page**] [**detail**] [**srv**]

**Syntax Description**

Parameters	Description
<i>name</i>	Represents the host name or IP address that you want to resolve.
<i>serv</i>	(Optional) Specifies an alternate domain name server.
[ <b>page</b> ]	(Optional) Displays the output one screen at a time.
[ <b>detail</b> ]	(Optional) Displays a detailed listing.
[ <b>srv</b> ]	(Optional) Displays DNS SRV records.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils network ipv6 host

This command does an IPv6 host lookup (or IPv6 address lookup) for the specified host name or IPv6 address.



**Note** IPv6 is not supported in Cisco Business Edition 5000.

**utils network ipv6 host** {*host\_name**ipv6\_address*}

**Syntax Description**

Parameters	Description
<i>host_name</i>	Specifies the name of the server.

Parameters	Description
<i>ipv6_address</i>	Specifies the IPv6 address of the server.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection.

## utils network ipv6 traceroute

This command traces an IPv6 address or hostname.



**Note** IPv6 is not supported in Cisco Business Edition 5000.

**utils network ipv6 traceroute** [*ipv6-addresshostname*]

**Syntax Description**

Parameters	Description
<i>ipv6-address</i>	Specifies IPv6 address that you want to trace.
<i>hostname</i>	Specifies the host name that you want to trace.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection.

## utils network ipv6 ping

This command allows you to ping an IPv6 address or hostname.



**Note** IPv6 is not supported in Cisco Business Edition 5000.

**utils network ipv6 ping** *destination* [*count*]

Syntax Description	Parameters	Description
	<i>destination</i>	Specifies a valid IPv6 address or host name that you want to ping.
	[ <i>count</i> ]	Specifies the number of times to ping the external server. The default count equals 4.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection.

## utils network ping

This command allows you to ping another server.

**utils network ping** *destination* [*count*] [*size*]

Syntax Description	Parameters	Description
	<i>destination</i>	Represents the ip address or host name of the server that you want to ping.
	[ <i>count</i> ]	Specifies the number of times to ping the external server. The default count is 4.
	[ <i>size</i> ]	Specifies the size of ping packets in bytes. The default value is 56.

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils network traceroute

This command traces IP packets that are sent to a remote destination.

**utils network traceroute** [*destination*]

Syntax Description	Parameters	Description
	<i>destination</i>	Represents the hostname or IP address of the server to which you want to send a trace.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

## utils network name-service {hosts|services} cache invalidate

This command clears the name service cache.

**utils network name-service** *{hosts \ services}* [*cache invalidate*]

Syntax Description	Parameters	Description
	<b>Hosts</b>	Host services cache
	<b>Services</b>	Services service cache

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Consider the following example for flushing/clearing the cache:

```
admin:utils network name-service hosts cache invalidate
admin:
Successful
```

## utils ntp auth symmetric-key

**utils ntp auth symmetric-key** {**enable** | **disable** | **status**}

This command helps you enable or disable authentication of the selected NTP server. The authentication is based on symmetric keyID and key. The symmetric key is stored in the encrypted format in Unified Communications Manager.



**Note** Before you run this command, ensure that you know the NTP server keyID and its corresponding key.

**Syntax Description**

Parameters	Description
<b>enable</b>	Choose one of the NTP servers from the list of available servers and enable it for authentication.
<b>disable</b>	Choose one of the NTP servers from the list of available servers and disable it for authentication.
<b>status</b>	Shows the authentication status of all the listed NTP servers.

**Usage Guidelines**

The system prompts you to enter the KeyID or Symmetric key for authentication of an NTP server.



**Note**

- Unified Communications Manager sends Syslog alert messages when the authentication status of an NTP server changes. You can secure the connections to the syslog server with TLS.
- You can configure the NTP server authentication after you install Unified Communications Manager.

**Requirements**

Command privilege level: Level 1 can execute all commands, Level 0 can execute only status command

Allowed during upgrade: No

Applies to: Unified Communications Manager

**Example: utils ntp auth symmetric-key status - View status when NTP authentication is not enabled**

```
admin:utils ntp auth symmetric-key status
10.77.32.92 : NTP Authentication is disabled.
10.77.46.203 : NTP Authentication is disabled.

ind assid status conf reach auth condition last_event cnt
=====
 1 8468 963a yes yes none sys.peer sys_peer 3
 2 8469 9024 yes yes none reject reachable 2
```

**Example: utils ntp auth symmetric-key enable - Enable NTP authentication**

```
admin:utils ntp auth symmetric-key enable
The List of NTP servers Configured:
1. 10.77.32.92
2. 10.77.46.203
q. press q to exit
Enter the selection for which to configure NTP authentication: 1
Please enter the Key ID [1-65534]:
2
Please enter the Symmetric Key of the NTP Server (SHA1):
Restarting NTP
please run the utils ntp auth symmetric-key status to check the status of NTP Authentication
```

**Example: utils ntp auth symmetric-key status - View status after NTP authentication is enabled**

```
admin:utils ntp auth symmetric-key status
10.77.46.203 : NTP Authentication is disabled.
```



10.77.32.92 : NTP Authentication is enabled.

```
ind assid status conf reach auth condition last_event cnt
=====
 1 57733 9044 yes yes none reject reachable 4
 2 57734 f014 yes yes ok reject reachable 1
```

**Example: utils ntp auth symmetric-key disable - Disable NTP authentication**

```
admin:utils ntp auth symmetric-key disable
The List of NTP servers Configured:
0. All
1. 10.77.46.203
2. 10.77.32.92
q. press q to exit
Enter the selection for which to disable NTP authentication: 2
NTP authentication has been disabled on the particular server.
Restarting NTP
```

**Example: utils ntp auth symmetric-key status - View status after NTP authentication is disabled**

10.77.46.203 : NTP Authentication is disabled.  
 10.77.32.92 : NTP Authentication is disabled.

```
ind assid status conf reach auth condition last_event cnt
=====
 1 42767 9144 yes yes none falsetick reachable 4
 2 42768 912a yes yes none falsetick sys_peer 2
```

**Example: utils ntp auth symmetric-key status - View status of NTP authentication**

```
admin:utils ntp auth symmetric-key status
10.77.32.92 : NTP authentication is failed. Please check the NTP authentication Key ID
and Symmetric Key entered is correct. To update, disable and reenable authentication for
this NTP server.
10.77.32.78 : NTP Authentication is disabled.
```

```
ind assid status conf reach auth condition last_event cnt
=====
 1 31609 c02c yes no bad reject 2
 2 31610 803a yes no none reject sys_peer 3
```

# utils ntp auth auto-key

**utils ntp auth auto-key {enable | disable | status}**

This command helps you enable or disable authentication of the selected NTP server. The authentication is based on the client key. It also allows you to check the authentication status of the ntp servers.



**Note** You can configure the PKI-based authentication with the IFF identity scheme on the NTP server only if you enable common criteria mode on the Unified Communication Manager.

You can enable either symmetric key or PKI-based NTP authentication on Unified Communications Manager.

If you try to enable the symmetric key on the PKI enabled server, the following warning message is displayed:



**Warning** NTP authentication using Autokey is currently enabled and must be disabled before the symmetric key is enabled. Use the command 'utils ntp auth auto-key disable' to disable NTP authentication, then retry this command.

If you try to enable the Autokey on the symmetric key enabled server, the following warning message is displayed:



**Warning** NTP authentication using symmetric key is currently enabled and must be disabled before Autokey is enabled. Use the command 'utils ntp auth symmetric-key disable' to disable NTP authentication, then retry this command.



**Note** NTP servers require ntp version 4 and the rpm version ntp-4.2.6p5-1.el6.x86\_64.rpm and above.

**Syntax Description**

**Parameters Description**

<b>enable</b>	Choose one of the NTP servers from the list of available servers and enable it for authentication.
<b>disable</b>	Choose one of the NTP servers from the list of PKI authentication enabled NTP servers and disable authentication.
<b>status</b>	Shows the authentication status of all the listed NTP servers.

**Usage Guidelines**

While enabling NTP authentication, system prompts you to enter the IFF client key for authentication of an NTP server. When the client key is uploaded successfully, it restarts the NTP service on the Unified Communications Manager publisher node. Post that authentication is enabled between the Unified Communications Manager and NTP server.



- Note**
- You can configure the NTP server authentication after you install or upgrade the Unified Communications Manager.
  - Do not terminate the execution by pressing “Ctrl-C” key during the CLI execution.

**Requirements**

Command privilege level:: Level 1 can execute all commands, Level 0 can execute only status command

Allowed during upgrade: No

Applies to:: Unified Communications Manager

**admin:utils ntp auth auto-key enable-Enable NTP authentication**

```
1: 10.78.83.146
2: 10.77.46.203
3: 10.77.32.92
```

Select the server for which auto-key based NTP authentication is to be enabled (Enter q to exit):2

Enter the IFF client key for the 10.77.46.203:

```
# ntpkey_iffpar_ccm203.3705887848
# Thu Jun 8 10:47:28 2017
```

```
-----BEGIN PRIVATE KEY-----
MIGzAgEAMIGoBgcqhkjOOAQBMIGcAkeEA4r3EkDFdP05QSpzVpGHnZN3JgOkW0Ch9
erxLB7zSxrwNdnDilWg5bUhZZWKZceQd/nyD6FLpZNFrpHnylkBUgQIWAJEjggjZM
r2aaMGSN5x2yUmhT4MqNAkBp2gkQNi8sluLre0YKyc+kdICiRkEK2jKwBETxs7Mh
aEd/c4DQnZkd5U9gco4v9zPpsfPOqftvymVyVmRyKX0NBAMCAQE=
-----END PRIVATE KEY-----
```

The Client key does not match the hostname of the selected NTP server. This could be because a DNS server is not configured or the DNS entry for this host is not present. Please verify the client key uploaded corresponds to the selected NTP server and that the DNS configuration is correct.

Do you want to continue with this operation?<yes/no>:

```
Client key uploaded succesfully
Restarting NTP service.
```

Please run 'utils ntp auth auto-key status' to check the status of NTP authentication.



**Note** The above user warning prompt is not displayed, if the DNS server is able to resolve the hostname of the selected NTP server and if it matches with the hostname in the client key provided.

**admin:utils ntp auth auto-key status - View status when NTP authentication is enabled**

```
1.10.78.83.146 : NTP Authentication is disabled.
2.10.77.46.203 : NTP Authentication is enabled.
3.10.77.32.92 : NTP Authentication is disabled.
```

Select the server for which auto-key based NTP authentication details is to be displayed (Enter q to exit):

2

NTP public certificate:

```
# ntpkey_RSA-SHA1cert_ccm-90.3708840303
# Wed Jul 12 14:55:03 2017
```

```
-----BEGIN CERTIFICATE-----
MIICwTCCAamgAwIBAgIFAN0QaW8wDQYJKoZIhvcNAQEFBQAwETEPMA0GA1UEAxMG
Y2NtLTkwMB4XDTE3MDcxMjA5MjUwM1oXDTE3MDcxMjA5MjUwM1owETEPMA0GA1UE
AxMGMGY2NtLTkwMlIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAvOno6hNu
C88VXYcKMCJ6w6hny7eG6JU8LzEjMIN5aqD0FDjnRzIKK/DL5DMReRy4j/4YQTR7
nT9ThudFwyUu0y86OpPWBgfKeII6kjtkeIlo4mp8RyMLJDp4e0jOh63wCP0cJsdZ1
dXFvx0/OjK6ZdX7OeHtcZn2ycLkSZP6hkos6Un//5zfu1IG47QElIh3bpPWq647
JiHELeuigcNm2plLSorXgmA3LFBFI99pamwF19Lmqb49y0Ie/QchXhudOosG0zuaL
PaEnkPdyNtxvQbCQ24cVBmHup7UBkdZYA+5unpbczMzZe3tQsl/CvizmUbfA+/gi
/DWSBC4Hfc011QIDAQABoyAwHjAPBgNVHRMBAf8EBTADAQH/MASGA1UdDwQEAwIC
```

```

hDANBgkqhkiG9w0BAQUFAAOCAQEAttJbav0+qVPk9abAWlWcmhQUbjW58qrLE9A0
2ZvIvHKq2TyBAIxYcUSQQ3GXSwBDHKZUNSAzrFrTQ+vLFqFvoSH0o5EFruIrwyn
zCD1OqNjXsCPsxyofSDuT/+pxvVxGX1cIpmDa2tieEUcdSvaGxol+ABh008YI6uf
bHNUCdjNSYbF6W0Lms643VSlNEUmBE4Tp+YWpLgbmXDXGalwHlog5fzfnywk161J
n34asWwWmR467WADnPBfMJDWzU1GMceh1lXQ/gbYYX3+rpilAZF6x9Z/goexhNc
L4WyzBrlR7iueJ1wYdFZ5THXOat3bxWMMWU4fDzqTWA7G9hpP6w==
-----END CERTIFICATE-----
      Client Key:
# ntpkey_ifffpar_ccm203.3705887848
# Thu Jun  8 10:47:28 2017

-----BEGIN PRIVATE KEY-----
MIGzAgEAMIGoBgcqhkiG9w0BAQ0BMIGcAkEA4r3EkDFdP05QSpzVpGHnZN3JgOkW0Ch9
erxLB7zSxrwNdnDlLWg5bUhZZWKZceQd/nyD6FLpZNFrpHnylkBUGQIVAJEjgjZM
r2aaMGSN5x2yUmhT4MqNAkBP2gkQNi8sluLre0YKyc+kdiCiRkEK2jKwBETXs7Mh
aEd/c4DQnZkd5U9gco4v9zPpsfPOqftvymVyVmRyKX0NBAMCAQE=
-----END PRIVATE KEY-----
admin:

```

### admin:utils ntp auth auto-key disable-Disable NTP authentication

```

The List of NTP servers Configured:
1. 10.77.46.203
Enter the NTP server in which the authentication needs to be disabled(Enter q to exit): 1
NTP authentication has been disabled on 10.77.46.203
Restarting NTP
admin:

```

## utils ntp server add

The command adds a maximum of five specified NTP servers.

**utils ntp server add** *s1* [*{s1s2s3s4s5}*] [**norestart**]

### Syntax Description

Parameters	Description
<i>s1...</i>	Specifies the NTP servers.
<b>norestart</b>	Causes the NTP service to not restart after you add the servers.

### Command Modes

Administrator (admin:)

### Usage Guidelines

If you use **norestart**, an explicit restart of the NTP service is required for the changes to take effect.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager

**Example: Attempting to Add Servers with Incorrect Command Line Parameters**

```
admin: admin:utils ntp server add s1 s2 s3 s4 s5 s6 s7 s8
Incorrect number of parameters entered for add
usage: utils ntp server add s1 [s2 s3 s4 s5] [norestart]
```

**Example: Attempting to Add a Server Using norestart Without Specifying a Server**

```
admin: utils ntp server add s1 s2 s3 s4 s5 s6 s7 s8
Incorrect number of parameters entered for add
usage: utils ntp server add s1 [s2 s3 s4 s5] [norestart]
```

**Example: Adding servers without norestart**

```
admin: utils ntp server add clock1.cisco.com clock2.cisco.com
clock1.cisco.com : added successfully.
clock2.cisco.com : added successfully.
Restarting NTP on the server.
```

**Example: Adding Servers That Are Already Added, Without norestart**

```
admin: utils ntp server add clock1.cisco.com clock2.cisco.com
clock1.cisco.com : [The host has already been added as an NTP server.]
clock2.cisco.com : [The host has already been added as an NTP server.]
```

**Example: Adding Server to Self Without norestart**

```
admin: utils ntp server add bglr-ccm26
bglr-ccm26 : [This server cannot be added as an NTP server.]
```

**Example: Adding Inaccessible Server Without norestart**

```
admin: utils ntp server add clock3.cisco.com
clock3.cisco.com : [ Inaccessible NTP server. Not added. ]
```

**Example: Adding Servers with norestart**

```
admin: utils ntp server add ntp01-syd.cisco.com ntp02-syd.cisco.com clock.cisco.com norestart
ntp01-syd.cisco.com : added successfully.
ntp02-syd.cisco.com : added successfully.
clock.cisco.com : added successfully.
The NTP service will need to be restarted for the changes to take effect.
```

**Example: Adding Servers When Five Are Already Configured**

```
admin:utils ntp server add clock3.cisco.com
The maximum permissible limit of 5 NTP servers is already configured.
```

## utils ntp server delete

This command deletes NTP servers that are configured.

**utils ntp server delete**

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

This command allows you to delete a configured Network Time Protocol (NTP) server or multiple NTP servers. When you choose the server to delete, you are prompted to indicate if you want to restart the NTP service. If you choose no, the NTP service does not get restarted after the server is deleted.



**Note** It is required to have at least 1 NTP server configured. Therefore, you cannot delete an NTP server if only one is configured. If you select the option to delete all the NTP servers, the NTP servers are deleted in top down order and the last NTP server on the list does not get deleted. The process is similar to the top down order followed during `utils ntp config` or `utils ntp status`

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager

**Example: Deleting Servers with Incorrect Command Line Parameters**

```
admin: utils ntp server delete clock1.cisco.com clock2.cisco.com
Incorrect number of optional parameters entered for delete
usage: utils ntp server delete
```

**Example: Deleting Single Server with NTP Restart**

```
admin: utils ntp server delete
1: clock1.cisco.com
2: clock2.cisco.com
3: ntp01-syd.cisco.com
4: ntp02-syd.cisco.com
5: clock.cisco.com
a: all
q: quit

Choice: 1

Restart NTP (y/n): y

clock1.cisco.com will be deleted from the list of configured NTP servers.
Continue (y/n)?y

clock1.cisco.com : deleted successfully.
Restarting NTP on the server.
```

**Example: Deleting All Servers Without NTP Restart**

```
admin: utils ntp server delete
1: clock1.cisco.com
2: clock2.cisco.com
3: ntp01-syd.cisco.com
4: ntp02-syd.cisco.com
5: clock.cisco.com
a: all
q: quit

Choice: a
```

```
Restart NTP (y/n): n

This will result in all the configured NTP servers being deleted.
Continue (y/n)?y

clock1.cisco.com : deleted successfully.
clock2.cisco.com : deleted successfully.
ntp01-syd.cisco.com : deleted successfully.
ntp02-syd.cisco.com : deleted successfully.
clock.cisco.com : [The NTP server was not deleted. At least one NTP server is required.]
The NTP service will need to be restarted for the changes to take effect.
```

### Example: Deleting All Servers When No Servers Are Configured

```
admin: utils ntp server delete
There are no NTP servers configured to delete.
```

## utils ntp config

This command displays the current configuration of the NTP client and server.



**Note** To avoid potential compatibility, accuracy, and network jitter problems, the external NTP servers that you specify for the primary node should be NTP v4 (version 4). If you are using IPv6 addressing, external NTP servers must be NTP v4.

### utils ntp config

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils ntp restart

This command restarts the NTP service.

### utils ntp restart

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils ntp server list

This command lists all NTP servers.

**utils ntp server list**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils ntp start

This command starts the NTP service if it is not already running.



---

**Note** You can not stop the NTP service from the command line interface. Use this command when the `utils ntp status` command returns stopped.

---

**utils ntp start**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils ntp status

This command displays the current status of NTP.

**utils ntp status**



**Command Modes** Administrator (admin:)

### Requirements

Command privilege level:

Allowed during upgrade:

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager.

## utils os kerneldump

This command configures kerneldump to provide a kernel crash dumping mechanism. The kernel captures the dump to the local disk, in case of a kernel crash.



**Note** The netdump commands have been removed from release 8.6(1) and have been replaced with the kerneldump commands.

**utils os kerneldump** {enable | disable}

**Command Modes** Administrator (admin:)

### Usage Guidelines

If a kernel crash occurs, the capture kernel dumps the core on the local disk of the server. The primary kernel reserves 128MB of physical memory that the capture kernel uses to boot. The kerneldump uses the **kexec** command to boot into a capture kernel whenever the kernel crashes.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

### Example

```
admin: utils os kerneldump enable
*****WARNING*****
Enabling kerneldump requires system reboot
Would you like to boot the machine (y/n):y
kerneldump enable operation succeeded
System going for a reboot
```

## utils os kerneldump ssh

This command enables, disables, or displays the status of an external SSH server.

**utils os kerneldump ssh** {enable | disable | status}

Syntax Description	Parameters	Description
	<b>enable</b>	Configures an external SSH server as a kerneldump server to kernel dumps.
	<b>disable</b>	Removes support of the external SSH server that is configured to collect kernel dumps.
	<b>status</b>	Indicates whether an external SSH server is configured or not, to collect kernel dumps.

**Command Modes** Administrator (admin:)

**Usage Guidelines** If external SSH server has the kerneldump service enabled and a kernel crash occurs, the capture kernel dumps the core on the external server that is configured to collect the dump. Enabling and disabling kerneldump require a system reboot for the changes to come into effect.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

**Example**

```
admin: utils os kerneldump ssh disable 10.77.31.60
Disabling kerneldump requires system reboot
Would you like to continue (y/n): y
kerneldump disable operation succeeded
System going for a reboot
```

## utils os kerneldump status

This command provides the status of the kdump service.

**utils os kerneldump status**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils os secure

This command is used to specify the level of security provided by selinux.

**utils os secure** {**enforce** | **permissive** | **status**}

Syntax Description	Parameters	Description
	<b>enforce</b>	
	<b>permissive</b>	
	<b>status</b>	

**Command Modes** Administrator (admin:)

**Usage Guidelines** Note that selinux does not handle rate limiting. Rate limiting is handled by ipprefs and ip tables.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils os secure dynamic-policies compile

This command generates the selinux policy module and type enforcement that resolves the recorded denials under the dynamic policy.

**utils os secure dynamic-policies compile** *policy name*

Syntax Description	Parameters	Description
	<i>policy name</i>	Type the dynamic policy name under which the compilation of the selinux policy module and type enforcement is done.

**Command Modes** Administrator (admin:)

**Usage Guidelines** **Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils os secure dynamic-policies list

This command lists all the operating system dynamic policies with their statuses.

**utils os secure dynamic-policies list**

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils os secure dynamic-policies load

This command loads the selinux policy module for the dynamic policy into selinux. This command applies new rules into selinux that prevent the denials that are recorded under the dynamic policy from reoccurring.

**utils os secure dynamic-policies load** *policy name*

---

**Syntax Description**

---

Parameters	Description
<i>policy name</i>	Type the dynamic policy name that has a generated selinux policy module, which is not loaded into selinux..

---



---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils os secure dynamic-policies remove

This command deletes all the data for the dynamic policy from the operating system. The data includes unloading the policy module from selinux and deleting the generated policy module, type enforcements, recorded denials, and delta logs.

**utils os secure dynamic-policies remove** *policy name*

---

**Syntax Description**

---

Parameters	Description
<i>policy name</i>	Type the dynamic policy name that is unnecessary or no longer required.

---



---

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils os secure dynamic-policies show

This command displays the rules to be introduced by loading the generated selinux policy module of the dynamic policy. Run this command after the successful compilation to verify that the rules to be loaded are secure.

**utils os secure dynamic-policies show** *policy name*

**Syntax Description**

**Parameters Description**

<i>policy name</i>	Type the dynamic policy name for which you want to view the rules.
--------------------	--

**Command Modes**

Administrator (admin:)

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils os secure dynamic-policies start-recording

This command starts recording the selinux denials and organizes them under the new dynamic policy.



**Note**

- This command sets the system into the permissive mode.
- The dynamic-policies are generated on a per-node basis. As a restriction, these policies cannot be exported or imported. This restriction has the following advantages:
  - Prevent loading external and unsigned policy modules into selinux that may create security vulnerabilities.
  - Prevent the transfer of policy modules between Unified Communications Manager clusters with different configurations.

**utils os secure dynamic-policies start-recording** *policy name*

<b>Syntax Description</b>	<table border="1"> <thead> <tr> <th>Parameters</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><i>policy name</i></td> <td>Type the dynamic policy name where the selinux denials and future policy data is to be organized.</td> </tr> </tbody> </table>	Parameters	Description	<i>policy name</i>	Type the dynamic policy name where the selinux denials and future policy data is to be organized.
Parameters	Description				
<i>policy name</i>	Type the dynamic policy name where the selinux denials and future policy data is to be organized.				
<b>Command Modes</b>	Administrator (admin:)				
<b>Usage Guidelines</b>	<p><b>Requirements</b></p> <p>Command privilege level: 1</p> <p>Allowed during upgrade: Yes</p> <p>Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager</p>				

## utils os secure dynamic-policies stop-recording

This command stops recording the selinux denials for the dynamic policy. This command switches the system back to the original enforcement mode—either permissive mode or enforcing mode. This log generates a delta log for all selinux denials that occurred between the start of the recording till it ends.



**Note** This command fails if the delta log has no new denials. Then, the dynamic policy is purged and you will have to use this command again.

**utils os secure dynamic-policies stop-recording** *policy name*

<b>Syntax Description</b>	<table border="1"> <thead> <tr> <th>Parameters</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><i>policy name</i></td> <td>Type the dynamic policy name the recording of which you want to stop.</td> </tr> </tbody> </table>	Parameters	Description	<i>policy name</i>	Type the dynamic policy name the recording of which you want to stop.
Parameters	Description				
<i>policy name</i>	Type the dynamic policy name the recording of which you want to stop.				
<b>Command Modes</b>	Administrator (admin:)				
<b>Usage Guidelines</b>	<p><b>Requirements</b></p> <p>Command privilege level: 1</p> <p>Allowed during upgrade: Yes</p> <p>Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager</p>				

## utils PlatformWebAccess disable

Use this command to restrict the user sign-in to Cisco OS Administration and Disaster Recovery System applications when SSO is enabled.

**utils PlatformWebAccess disable****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils PlatformWebAccess enable

Use this command to enable the user sign-in to Cisco OS Administration and Disaster Recovery System applications.

**utils PlatformWebAccess enable****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils PlatformWebAccess status

Use this command to display the status of the web access of the system—whether the platform web access is enabled or disabled for Cisco OS Administration and Disaster Recovery System applications.

**utils PlatformWebAccess status****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils processCoreDumps disable

This command disables the process core dumps.

### utils processCoreDumps disable

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils processCoreDumps enable

This command enables the process core dumps.

### utils processCoreDumps enable

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils processCoreDumps status

This command provides the status of the kdump service.

### utils processCoreDumps status

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection



## utils remote\_account create

This command creates a remote account.

**utils remote\_account create**

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** A remote account generates a pass phrase that allows Cisco Systems support personnel to get access to the system for the specified life of the account.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils remote\_account disable

This command allows you to disable a remote account.

**utils remote\_account disable**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils remote\_account enable

This command allows you to enable a remote account.

**utils remote\_account enable**

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** You can have only one remote account that is enabled at a time.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils remote\_account status

This command allows you to check the status of a remote account.

**utils remote\_account status**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils remotesyslog set protocol tcp

This command configures the protocol for communication with remote syslog server as TCP on the system. Restart the node for changes to take effect.

**utils remotesyslog set protocol tcp**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils remotesyslog set protocol udp

This command configures the protocol for communication with remote syslog server as UDP on the system. Restart the node for changes to take effect.

**utils remotesyslog set protocol udp**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils remotesyslog set protocol tls

This command configures the protocol for communication with the remote syslog server as Transport Layer Security (TLS) 1.2 on the system. TLS 1.2 enables Unified Communications Manager and IM and Presence Service to establish a secure connection with syslog servers. This enables Unified Communications Manager and IM and Presence Service to comply with Common Criteria guidelines.



- 
- Note**
- Ensure that the syslog server supports TLS 1.2 protocols as a secure connection will be established only if the syslog server supports TLS 1.2 protocols.
  - In Common Criteria Mode, strict host name verification is implemented. Hence, it is required to configure the server with a fully qualified domain name (FQDN) which matches the certificate.
- 

Restart the node for the changes to take effect.

**utils remotesyslog set protocol tls**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

A security certificate has to be uploaded from the syslog server to the tomcat trust store on Unified Communications Manager and IM and Presence Service.

## utils remotesyslog show protocol

This command shows whether the protocol for communication with remote syslog server is TCP or UDP on the system.

**utils remotesyslog show protocol**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils reset\_application\_ui\_administrator\_name

This command resets the application user interface administrator name.

**utils reset\_application\_ui\_administrator\_name**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils reset\_application\_ui\_administrator\_password

This command resets the application user interface administrator password.




---

**Note** For password changes on IM and Presence nodes, stop the Cisco Presence Engine service in all IM and Presence nodes before resetting the administrator password. After the password reset, restart Cisco Presence Engine service in all the nodes. Make sure that you perform this task during maintenance because you may face presence issues when the PE is stopped. If you change the password from IM and Presence nodes, make sure the new password is same as the current administrator password in Unified Communication Manager.

---

**utils reset\_application\_ui\_administrator\_password**

---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils restore\_application\_ui\_administrator\_account

This command restores the application user interface administrator account.

**utils restore\_application\_ui\_administrator\_account**

---

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils rosters list limited

Run this command on the database publisher node to obtain a count of invalid watchers and invalid contacts. The total counts display in the CLI.

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** We recommend that you run this command only during a maintenance window. This command will list only the count and no details of the invalid records. For details on the invalid records, try **utils rosters list [ watchers | contacts | full**.

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: IM and Presence Service

## utils rosters list full

Run this command on the database publisher node to write the details of all invalid watchers and invalid contacts to a file. The command also displays the total counts in the CLI.

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** We recommend that you run this command only during a maintenance window.

### Requirements

Command privilege level: 4

Allowed during upgrade: No

Applies to: IM and Presence Service

## utils rosters list watchers

Run this command on the database publisher node to write the details of all invalid watchers in the cluster to a file. The total count of invalid contacts also displays in the CLI.

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

We recommend that you run this command only during a maintenance windows. While executing, progress is displayed in the CLI as well as in a log file.

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: IM and Presence Service

## utils rosters list contacts

Run this command on the database publisher node to write the details of all invalid contacts in the cluster to a file. The total count of invalid contacts also displays in CLI.

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

We recommend that you run this command only during a maintenance window.

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: IM and Presence Service

## utils rosters delete

Run this command on the database publisher node to delete all invalid watchers and invalid contacts in the IM and Presence cluster.

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

We recommend that you run this command only during a maintenance windows. While executing, progress is displayed in the CLI as well as in a log file.

**Requirements**

Command privilege level: 4

Allowed during upgrade: No

Applies to: IM and Presence Service

## utils scheduled-task disable

This command disables the scheduled-task.

**utils scheduled-task disable** **scheduled-task**

Syntax Description	Parameters	Description
	<b>scheduled-task</b>	Enter the name of the task that you need to disable.

Command Modes	Administrator (admin:)
	<b>Requirements</b>
	Command privilege level: 1
	Allowed during upgrade: No
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils scheduled-task enable

This command enables the scheduled-task.

**utils scheduled-task enable** **scheduled-task**

Syntax Description	Parameters	Description
	<b>scheduled-task</b>	Enter the name of the task that you need to enable.

Command Modes	Administrator (admin:)
	<b>Requirements</b>
	Command privilege level: 1
	Allowed during upgrade: No
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils scheduled-task list

This command lists all the scheduled tasks.

**utils scheduled-task list**

---

**Command Modes** Administrator (admin:)**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils set urlpattern disable

This command disables the URL pattern and modifies the `zzz20_product_profile.sh` file. After the URL pattern is disabled, this command appends the following line:

```
export TOMCAT_EXCLUDE_URLPATTERNS="/ucmuser"
```

**utils set urlpattern disable**

---

**Command Modes** Administrator (admin:)**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils set urlpattern enable

This command enables the URL pattern and modifies the `zzz20_product_profile.sh` file. After the URL pattern is enabled, this command appends the following line:

```
export TOMCAT_EXCLUDE_URLPATTERNS=""
```

**utils set urlpattern enable**

---

**Command Modes** Administrator (admin:)**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection



## utils service

This command activates, deactivates, starts, stops, or restarts a service.

**utils service** {**activate** | **deactivate** | **start** | **stop** | **restart**} *service\_name*

### Syntax Description

Parameters	Description
<i>service_name</i>	Represents the name of the service you want to affect, for example:
	<ul style="list-style-type: none"> <li>• System NTP</li> <li>• System SSH</li> <li>• Service Manager</li> <li>• A Cisco DB</li> <li>• Cisco Database Layer Monitor</li> <li>• Cisco Unified Serviceability</li> </ul>
	This list is not exhaustive. For a full list of services for the node enter the command: <b>utils service list</b>
<b>Note</b>	If you want to restart the Cisco Tomcat service for standalone Cisco Prime License Manager, execute the following command or reboot the server: <b>utils service restart Cisco Prime LM Server</b> .



### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils service list

This command retrieves a list of all services.

**utils service list** [**page**]

### Syntax Description

Parameters	Description
[ <b>page</b> ]	Displays the output one page at a time.

### Command Modes

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager and IM and Presence Service on Unified Communications Manager

## utils service auto-restart

This command starts or stops a specified service.

**utils service auto-restart** {**enable** | **disable** | **show**}  
*service-name*

Syntax Description	Parameters	Description
	<b>enable</b>	Starts auto-restart.
	<b>disable</b>	Stops auto-restart.
	<b>show</b>	Shows the status of a service.
	<i>service-name</i>	Represents the name of the service that you want to start, stop, or show: <ul style="list-style-type: none"> <li>• System NTP</li> <li>• System SSH</li> <li>• Service Manager</li> <li>• A Cisco DB</li> <li>• Cisco Tomcat</li> <li>• Cisco Database Layer Monitor</li> <li>• Cisco Unified Serviceability</li> </ul>

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils service start

This command starts a service.

**utils service start**

Syntax Description	Parameters	Description
	<i>service</i>	Enter the name of a service, which can consist of multiple words.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils service stop

This command stops a service.

**utils service stop**

Syntax Description	Parameters	Description
	<i>service</i>	Enter the name of a service, which can consist of multiple words.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils snmp config 1/2c community-string

This interactive command adds, deletes, lists or updates a community string.

**utils snmp config 1/2c community-string {add | delete | list | update}**

Syntax Description	Parameters	Description
	<b>add</b>	Adds a new community string.
	<b>delete</b>	Deletes a community string.
	<b>list</b>	Lists all community strings.
	<b>update</b>	Updates a community string.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system prompts you for the parameters.

The SNMP Master Agent service is restarted for configuration changes to take effect. Do not abort command after execution until restart is complete. If the command is aborted during service restart, verify service status of “SNMP Master Agent” by using `utils service list`. If service is down, start it by using `utils service start SNMP Master Agent`

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp config 1/2c inform

This interactive command adds, deletes, lists or updates inform notification destinations.

**utils snmp config 1/2c inform {add | delete | list | update}**

Syntax Description	Parameters	Description
	<b>add</b>	Adds a notification destination.
	<b>delete</b>	Deletes a notification destination.
	<b>list</b>	Lists all notification destinations.
	<b>update</b>	Updates a notification destination.

**Command Modes** Administrator (admin:)

**Requirements**

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp config 1/2c trap

This interactive command affects trap notifications.

**utils snmp config 1/2c trap** {add | delete | list | update}

Syntax Description	Parameters	Description
	<b>add</b>	Adds a new v1/2c trap notification destination associated with a configured v1/2c community string.
	<b>delete</b>	Deletes the configuration information for an existing v1/2c trap notification destination.
	<b>list</b>	Lists the v1/2c trap notifications currently configured.
	<b>update</b>	Updates configuration information for an existing v1/2c trap notification destination.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## utils snmp config 3 inform

This interactive command affects the v3 inform notification.

**utils snmp config 3 inform** {add | delete | list | update}

Syntax Description	Parameters	Description
	<b>add</b>	Adds a new v3 inform notification destination associated with a configured v3 username.
	<b>delete</b>	Deletes the configuration information for an existing v3 inform notification destination.
	<b>list</b>	Lists the v3 inform notifications currently configured.
	<b>update</b>	Updates configuration information for an existing v3 inform notification destination.

### Command Modes

Administrator (admin:)

### Usage Guidelines

The system prompts you for the parameters.

The SNMP Master Agent service is restarted for configuration changes to take effect. Do not abort command after execution until restart is complete. If the command is aborted during service restart, verify service status

of “SNMP Master Agent” by using `utils service list`. If service is down, start it by using `utils service start SNMP Master Agent`

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp config mib2

This interactive command affects the Mib2 configuration information.

`utils snmp config mib2 {add | delete | list | update}`

Syntax Description	Parameters	Description
	<b>add</b>	Adds the Mib2 configuration information.
	<b>delete</b>	Deletes the Mib2 configuration information.
	<b>list</b>	Lists the Mib2 configuration information.
	<b>update</b>	Updates the Mib2 configuration information.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system prompts you for the parameters.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp config 3 trap

This interactive command affects trap notifications.

`utils snmp config 3 trap {add | delete | list | update}`

Syntax Description	Parameters	Description
	<b>add</b>	Adds a new v3 trap notification destination associated with a configured v3 username.

Parameters	Description
<b>delete</b>	Deletes the configuration information for an existing v3 trap notification destination.
<b>list</b>	Lists the v3 trap notifications currently configured.
<b>update</b>	Updates configuration information for an existing v3 trap notification destination.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system prompts you for the parameters.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp config 3 user

This interactive command affects v3 user configuration.

**utils snmp config 3 user** {**add** | **delete** | **list** | **update**}

Syntax Description	Parameters	Description
	<b>add</b>	Adds a new v3 user with the v3 authentication and privacy passwords.
	<b>delete</b>	Deletes the configuration information for an existing v3 user.
	<b>list</b>	Lists the v3 users currently configured.
	<b>update</b>	Updates configuration information for an existing v3 user.

**Command Modes** Administrator (admin:)

**Usage Guidelines** The system prompts you for the parameters.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp get

This interactive command gets the SNMP data using the specified version for the specified MIB OID.

**utils snmp get** *version*

Syntax Description	Parameters	Description
	<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
	<i>community</i>	Specifies the SNMP community string.
	<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
	<i>object</i>	Specifies the SNMP Object ID (OID) to get.
	<i>file</i>	Specifies a file in which to save the command output.

### Command Modes

Administrator (admin:)

### Usage Guidelines

If you run the command on a specific OID (leaf) in the MIB, you get the value of the MIB. For example to get the system uptime: iso.3.6.1.2.1.25.1.1.0 = Timeticks: (19836825) 2 days, 7:06:08.25

If you provide the IPv4/IPv6 address of a remote host, the command gets executed on the remote host.

The IPv4/IPv6 address is required. You cannot use a domain name.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp get 1

This command gets the SNMP data using version 1 for the specified MIB OID.

**utils snmp get 1** *version*



**Syntax Description**

Parameters	Description
<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
<i>community</i>	Specifies the SNMP community string.
<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
<i>object</i>	Specifies the SNMP Object ID (OID) to get.
<i>file</i>	Specifies a file in which to save the command output.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

# utils snmp get 2c

This command gets the SNMP data using version 2c for the specified MIB OID.

**utils snmp get 2c** *version*

**Syntax Description**

Parameters	Description
<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
<i>community</i>	Specifies the SNMP community string.
<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
<i>object</i>	Specifies the SNMP Object ID (OID) to get.
<i>file</i>	Specifies a file in which to save the command output.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp get 3

This command gets the SNMP data for the specified MIB OID.

**utils snmp get 3** *version*

Syntax Description	Parameters	Description
	<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
	<i>community</i>	Specifies the SNMP community string.
	<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
	<i>object</i>	Specifies the SNMP Object ID (OID) to get.
	<i>file</i>	Specifies a file in which to save the command output.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp hardware-agents

This command affects the SNMP agents on the server.

**utils snmp hardware-agents** {*status* | *start* | *stop* | *restart*}

Syntax Description	Parameters	Description
	<b>status</b>	Displays the status of the SNMP agents provided by the vendor of the hardware.  <b>Note</b> Only agents that provide status get displayed by this command. Not all hardware agents provide status.
	<b>stop</b>	Stops all SNMP agents provided by the hardware vendor.
	<b>restart</b>	Restarts all of the SNMP agents provided by the vendor of the hardware.
	<b>start</b>	Starts all of the SNMP agents provided by the vendor of the hardware.

### Command Modes

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp test

This command sends sample alarms to local syslog and remote syslog.

**utils snmp test**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

**Example**

```
admin: admin:utils snmp test
Service Manager is running
Test SNMP Trap starts with Local Host Name, Specify a Remote Sever Name to test Remote Syslog
TestAlarmInformational sent [Returncode=0]
TestAlarmEmergency sent [Returncode=0]
TestAlarmAlert sent [returncode=0]
TestAlarmCritical sent [Returncode=0]
TestAlarmDebug sent [Returncode=0]
TestAlarmNotice sent [Returncode=0]
TestAlarmWarning sent [Returncode=0]
TestAlarmError sent [Returncode=0]
TestAlarmWindows sent [Returncode=0]
Message from syslogd@ipcibu-plat44 at Sat Jul 17 03:56:11 2010 ...
ipcibu-plat44 local7 0 : 1: ipcibu-plat44.blr.eng: Jul 16 2010 22:26:11.53 UTC :
%UC_-0-TestAlarmEmergency: %[AppID=Cisco CallManager][ClusterID=][NodeID=ipcibu-plat44]:
Testing EMERGENCY_ALARM
```

# utils snmp walk

This interactive command walks through the SNMP MIB using the specified version, starting with the specified OID.

**utils snmp walk** *version*

Syntax Description	Parameters	Description
	<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
	<i>community</i>	Specifies the SNMP community string.
	<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
	<i>object</i>	Specifies the SNMP Object ID (OID) to walk
	<i>file</i>	Specifies a file in which to save the command output.

## Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

### Example

For the below example, community string is created using the `utils snmp config 1/2c community-string` command.

```
admin:utils snmp walk 1
```

ctrl-c: To quit the input.

```
Enter the community string:: public
Enter the ip address of the Server, use 127.0.0.1 for localhost.
Note that you need to provide the IP address, not the hostname.: <enter the IP address of
  your server>
The Object ID (OID):: iso.3.6.1.2.1.1.1.0
Enter parameter as "file" to log the output to a file. [nofile]::
This command may temporarily impact CPU performance.
Continue (y/n)?y
SNMPv2-MIB::sysDescr.0 = STRING: Linux release:3.10.0-1062.18.1.el7.x86_64 machine:x86_64
#####
utils snmp walk 2c -> same as utils snmp walk 1
#####
For the below example, user is created using
utils snmp config 3 user add
```

```

utils snmp walk 3
admin:utils snmp walk 3

ctrl-c: To quit the input.

Enter the user name:: test
Enter the authentication protocol [SHA]:: SHA
Enter the authentication protocol pass phrase:: *****
Enter the privacy protocol [AES128]:: AES128
Enter the privacy protocol pass phrase:: *****
Enter the ip address of the Server, use 127.0.0.1 for localhost.
Note that you need to provide the IP address, not the hostname.: <enter the IP address of
your server>
The Object ID (OID):: iso.3.6.1.2.1.1.1.0
Enter parameter as "file" to log the output to a file. [nofile]::
This command may temporarily impact CPU performance.
Continue (y/n)?y
SNMPv2-MIB::sysDescr.0 = STRING: Linux release:3.10.0-1062.18.1.el7.x86_64 machine:x86_64
    
```

## utils snmp walk 1

This interactive command walks through the SNMP MIB using SNMP version 1 starting with the specified OID

**utils snmp walk 1** *version*

### Syntax Description

Parameters	Description
<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
<i>community</i>	Specifies the SNMP community string.
<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
<i>object</i>	Specifies the SNMP Object ID (OID) to walk
<i>file</i>	Specifies a file in which to save the command output.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp walk 2c

This interactive command walks through the SNMP MIB using SNMP version 2c starting with the specified OID.

**utils snmp walk 2c** *version*

### Syntax Description

Parameters	Description
<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
<i>community</i>	Specifies the SNMP community string.
<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
<i>object</i>	Specifies the SNMP Object ID (OID) to walk
<i>file</i>	Specifies a file in which to save the command output.

### Command Modes

Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils snmp walk 3

This interactive command walks through the SNMP MIB starting with the specified OID.

**utils snmp walk 3** *version*

### Syntax Description

Parameters	Description
<i>version</i>	Specifies the SNMP version. Possible values include 1, 2c or 3.
<i>community</i>	Specifies the SNMP community string.
<i>object</i>	Specifies the SNMP Object ID (OID) to walk
<i>ip-address</i>	Specifies the IPv4/IPv6 address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IPv4/IPv6 address of another node in the cluster to run the command on that node.
<i>file</i>	Specifies a file in which to save the command output.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils soap realservice test

This command executes a number of test cases on the remote server.

**utils soap realservice test** [*remote-ip*]*remote-https**remote https-password*

Syntax Description	Parameters	Description
	<i>remote-ip</i>	Specifies the IP address of the server under test.
	<i>remote-https-user</i>	Specifies a username with access to the SOAP API.
	<i>remote-https-password</i>	Specifies the password for the account with SOAP API access.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils sso

This command provides information about SAML SSO authentication.

**utils sso** {*enable* | *disable* | *status*}

Syntax Description	Parameters	Description
	<b>enable</b>	Provides the location in Cisco Unified CM Administration where you can enable SAML SSO.
	<b>disable</b>	Disables SAML SSO based authentication.
	<b>status</b>	Provides the status of SAML SSO.

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

**Example**

```
Admin: utils sso enable
*** W A R N I N G ***
SSO cannot be enabled using CLI command
=====
To enable Cluster wide SAML SSO please access
Cisco Unified CM Administration Page->System->SAML Single Sign On
=====
```

## utils sso recovery-url

This command enables or disables recovery URL for SAML SSO based authentication.

**utils sso recovery-url** {enable | disable}

**Syntax Description**

Parameters	Description
<b>enable</b>	Enables recovery URL for SAML SSO based authentication.
<b>disable</b>	Disables recovery URL for SAML SSO based authentication.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils system restart

This command allows you to restart the system on the same partition.

**utils system restart**

**Command Modes**

Administrator (admin:)



**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils system shutdown

This command allows you to shut down the system.

**utils system shutdown**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines**

This command has a five-minute timeout. If the system does not shut down within five minutes, the command gives you the option of doing a forced shutdown.



---

**Caution** If the server is forced to shutdown and restart from your virtual machine, the file system may become corrupted.

---

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils system switch-version

This command allows you to restart the system on the inactive partition.

**utils system switch-version**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils system boot

This command redirects where the system boot output gets sent.

**utils system boot** {console | serial}

### Syntax Description

Parameters	Description
<i>console</i>	Redirects the system boot output to the console.
<i>serial</i>	Redirects the system boot output to the COM1 (serial port 1).

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager and Cisco Unity Connection

## utils system upgrade

This command allows you to install upgrades and Cisco Option (COP) files from both local and remote directories.

**utils system upgrade** {initiate | cancel | status}

### Syntax Description

Parameters	Description
<b>cancel</b>	Cancels the active upgrade.
<b>initiate</b>	Starts a new upgrade wizard or assumes control of an existing upgrade wizard. The wizard prompts you for the location of the upgrade file from the source.
<b>status</b>	Displays the status of an upgrade.

### Command Modes

Administrator (admin:)

### Usage Guidelines

The wizard prompts you to enter information about your upgrade:

- **Credentials Information**—Make sure that you have the credentials of the server on which the upgrade image is saved. If you are not upgrading the Unified Communications Manager publisher node, and you have previously upgrade this node, you can use download credentials from the publisher node. The default value of the Use download credentials from Publisher is yes.




---

**Note** You can use download credentials from the publisher node only when you upgrade individual cluster node. This option is not applicable for cluster-wide upgrade.

---

- Upgrade file source—Enter the location for the server where your upgrade file is saved. You can upgrade from a local source(CD or DVD), or you can use FTP or SFTP to download a remote upgrade file, or if you want to resume an upgrade after a cancel operation, you can use the previously downloaded upgrade file through the local image source option.
- Continue with upgrade after download—You must indicate whether you want the upgrade to proceed automatically once the upgrade file is downloaded (the default value is yes). If you choose to upgrade automatically, no checksum or SHA details get displayed. If you set the value of to yes or no, the setting remains in the system.
- Version switching—You must indicate whether you want to switch to the new version automatically once the upgrade completes (the default value is no). If you enter yes, the system switches to the new version and reboots automatically after the upgrade completes. If you set the value to yes or no, the setting remains in the system.

### Requirements

Command privilege level: 0

Applies to: Unified Communications Manager, IM and Presence service on Unified Communications Manager, Cisco Unity Connection.




---

**Note** If a cluster upgrade is in progress, and another upgrade is initiated using CLI, then the following message is displayed:

A cluster upgrade is in progress. You can check the status of the cluster upgrade using the CLI or GUI of the CUCM Publisher.

---

### Example:

```
admin:utils system upgrade initiate
```

```
Warning: Do not close this window without first canceling the upgrade.
```

```
Warning: A cluster upgrade is in progress. You can check the status of the cluster upgrade using the CLI or GUI of the CUCM Publisher.
```

```
Use download credentials from Publisher(yes/no) [yes]:no
```

```
Source:
```

```
1) Remote Filesystem via SFTP
2) Remote Filesystem via FTP
3) Local DVD/CD
4) Local Image<UCSInstall_UCOS_12.5.0.98000-889.iso>
q) quit
Please select an option (1 - 4 or "q" ): 4
```

```
Please enter SMTP Host Server (optional):
Checking for valid upgrades.
```

```

Please wait...
Available options and upgrades in "upgrade" directory:
1) UCSInstall_UCOS_12.5.0.98000-338.iso
q) quit
Please select an option (1 - 1 or "q" ): 1
Accessing the file.
Please wait...
Validating the file...
A system reboot is required when the upgrade process completes or is canceled.
This will ensure services affected by the upgrade process are functioning properly.
Downloaded: UCSInstall_UCOS_12.5.0.98000-338.iso
File version: 12.5.0.98000-338
File checksum : (MD5): 8f:ce:0b:12:6b:d5:6f:d5:fd:25:d9:aa:12:d0:d5:30
(SHA512):
84ac0fd21723173ae89f1c01926a0852f46941c1785ae8e55cb8ab426db9fb42fd1ce07e0c9e3ac7db01a4f7812f239fc38390dc2bc44d5161ebf13617c3050
Automatically switch versions if the upgrade is successful (yes/no): yes
Start installation (yes/no): yes

```

**Example:**

```

admin:utils system upgrade initiate

Warning: Do not close this window without first canceling the upgrade.

Use download credentials from Publisher (yes/no) [yes]:yes
Using publisher setting
Checking for valid upgrades. Please wait...
Available options and upgrades in "10.65.104.39:/var/sftp/uploads":
1.dp-ffr.3-1-7.NL.k3.cop q) quit
Please select an option (1 - 1 or "q" ):

```

**Example:**

```

admin:utils system upgrade initiate

Warning: Do not close this window without first canceling the upgrade.
Use download credentials from Publisher(yes/no)[yes]:no

Source:

1) Remote Filesystem via SFTP
2) Remote Filesystem via FTP
3) Local DVD/CD
4) Local Image<UCSInstall_UCOS_12.5.0.98000-889.iso>
q) quit
Please select an option (1 - 4 or "q" ): 4

Please enter SMTP Host Server (optional):
Continue with upgrade after download (yes/no) [yes]:
switch-version server after upgrade (yes/no) [no]
Checking for valid upgrades.
Please wait...
Available options and upgrades in "upgrade" directory:
1) UCSInstall_UCOS_12.5.0.98000-338.iso
q) quit
Please select an option (1 - 1 or "q" ): 1
Accessing the file.
Please wait...

```

```
Validating the file...
A system reboot is required when the upgrade process completes or is canceled.
This will ensure services affected by the upgrade process are functioning properly.
Downloaded: UCSInstall_UCOS_12.5.0.98000-338.iso
File version: 12.5.0.98000-338
Automatically switch versions if the upgrade is successful (yes/no): yes
Start installation (yes/no): yes
```

## utils system upgrade cluster

This command allows you to install upgrades for cluster nodes (Unified Communications Manager and IM and Presence) and Cisco Option Package (COP) files from both local and remote directories.

**utils system upgrade cluster** {**initiate** | **cancel** | **status**}

Syntax Description	Parameters	Description
	<b>cancel</b>	Cancels the active upgrade.
	<b>initiate</b>	<p>Starts a new upgrade wizard or assumes control of an existing cluster upgrade wizard.</p> <p>This option allows you to perform a cluster-wide upgrade from the Unified Communications Manager publisher.</p> <p>This option is available only for the Unified Communications Manager publisher and not for the Unified Communications Manager subscriber or IM and Presence nodes.</p>
	<b>status</b>	<p>Displays the status of an upgrade for each node in the cluster with the following fields:</p> <ul style="list-style-type: none"> <li>• Node—The hostname of the node.</li> <li>• Role—The role of the node.</li> <li>• Step—The current Step number or the Total number of steps to be executed for upgrade completion.</li> <li>• Description—The current component which is currently upgrading for the particular node.</li> <li>• Historical Time—The amount of time taken to complete the current component/step for the respective node based on previous clusterwide upgrade runs.</li> <li>• Elapsed Time—The amount of time that passes from the start of the current component/step to its finish for the respective node.</li> </ul>

**Command Modes** Administrator (admin:)

**Usage Guidelines** The wizard prompts you to enter information about your upgrade:

- **Credentials Information**—Make sure that you have the credentials of the server on which the upgrade image is saved.
- **Upgrade file source**—Enter the location for the server where your upgrade file is saved. You can upgrade from a local source (CD or DVD), or you can use FTP or SFTP to download a remote upgrade file, or if you want to resume an upgrade after a cancel operation, you can use the previously downloaded upgrade file through the local image source option.
- **Continue with upgrade after download**—You must indicate whether you want the upgrade to proceed automatically once the upgrade file is downloaded (the default value is yes). If you choose to upgrade automatically, no checksum or SHA details get displayed. If you set the value of to yes or no, the setting remains in the system.
- **Version switching**—You must indicate whether you want to switch to the new version automatically once the upgrade completes (the default value is no). If you enter yes, the system switches to the new version and reboots automatically after the upgrade completes. If you set the value to yes or no, the setting remains in the system.

### Requirements

Command privilege level: 0

Applies to: Unified Communications Manager on Unified Communications Manager.



**Note** If a single-node upgrade is in progress, and a cluster upgrade is initiated, then, the following message is displayed:

```
failed (Local upgrade is in progress.)
```

If a single-node upgrade is in progress in Unified Communication Manager publisher, either using CLI or User Interface, if you initiate a cluster upgrade using CLI, then the following message is displayed:

```
A Single-node upgrade is in progress. You can cancel the upgrade to initiate Cluster upgrade.
```

If a cluster upgrade session is in progress in Unified Communication Manager publisher either using User Interface or CLI, if you initiate another cluster session using CLI, then the following message is displayed:

```
Another user session is currently configuring a cluster upgrade. Assume control (yes/no):  
yes
```

### Example:

```
admin:utils system upgrade cluster initiate
```

```
Warning: Do not close this window without first canceling the upgrade.
```

```
Source:
```

```
1) Remote Filesystem via SFTP
2) Remote Filesystem via FTP
3) Local DVD/CD
4) Local Image<None>
q) quit
Please select an option (1 - 4 or "q" ): 1Directory [/home/image/BOTH]:
Server [10.65.104.19]:
```

```

User Name [image]:
Password [*****]:
Please enter SMTP Host Server (optional):
Continue with upgrade after download (yes/no) [no]:
Switch-version cluster after upgrade [valid only for ISO] (yes/no) [no]:

Checking for valid upgrades. Please wait...

Available CUCM options and upgrades in "10.65.104.19:/home/image/BOTH":

  1) UCSInstall_UCOS_12.5.0.98000-541.iso
  2) UCSInstall_UCOS_UNRST_12.5.0.98000-541.iso
  3) ciscocm.free_common_space_v1.1.cop
  4) ciscocm.migrate-export-v1.20.cop.sgn
  q) quit
Please select an option (1 - 4 or "q" ): 1

Available IMP options and upgrades in "10.65.104.19:/home/image/BOTH":

  1) UCSInstall_CUP_12.5.0.98000-661.iso
  2) UCSInstall_CUP_UNRST_12.5.0.98000-661.iso
  3) ciscocm.free_common_space_v1.1.cop
  4) ciscocm.migrate-export-v1.20.cop.sgn
  q) quit

Please select an option (1 - 4 or "q" ): 1
Processing the cluster wide download ...
UCM1-PUB.ciscoctg.com           Downloading..287mb
UCM1-SUB-1B.ciscoctg.com        Downloading..115mb
UCM1-SUB-1A.ciscoctg.com        Downloading..347mb
IMP1-SUB-1B.ciscoctg.com        failed (Local upgrade is in progress.)
UCM1-SUB-2B.ciscoctg.com        Downloading..490mb
IMP1-PUB.ciscoctg.com           Downloading..55mb
UCM1-SUB-2A.ciscoctg.com        failed
Exiting upgrade command. Please wait...

```

**Example:**

```

admin:utils system upgrade cluster initiate

Warning: Do not close this window without first canceling the upgrade.
Cluster upgrade is in progress. You may not take over the installation.
Source:
  1) Remote Filesystem via SFTP
  2) Remote Filesystem via FTP
  3) Local DVD/CD
  4) Local Image <UCSInstall_UCOS_12.5.0.98000-569.iso>
  q) quit

Please select an option (1 - 4 or "q" ): 4
Please enter SMTP Host Server (optional):
Continue with upgrade after download (yes/no) [no]: no
Switch-version cluster after upgrade [valid only for ISO] (yes/no) [no]: no
Checking for valid upgrades. Please wait...
Available CUCM options and upgrades in "upgrade" directory:
  1) UCSInstall_UCOS_12.5.0.98000-569.iso
  q) quit
Please select an option (1 - 1 or "q" ): 1
Available IMP options and upgrades in "upgrade" directory:
  1) UCSInstall_CUP_12.5.0.98000-695.iso
  q) quit

```

```

Please select an option (1 - 1 or "q" ): 1
Processing the cluster wide download ...
UCM1-SUB-1B.ciscoctg.com           Download complete
UCM1-SUB-2A.ciscoctg.com           Download complete
IMP1-SUB-1B.ciscoctg.com           Download complete
UCM1-SUB-1A.ciscoctg.com           Download complete
UCM1-PUB.ciscoctg.com              Download complete
UCM1-SUB-2B.ciscoctg.com           Download complete
IMP1-PUB.ciscoctg.com              Download complete
Cluster wide Download complete
A system reboot is required when the upgrade process is complete or cancelled.
This will ensure the services affected by the upgrade process are functioning properly
Downloaded UCM Image: UCSInstall_UCOS_12.5.0.98000-569.iso
File version: 12.5.0.98000-569
File checksum : (MD5): 66:93:bc:4d:c5:ae:19:34:72:77:96:5a:be:1a:28:3d
                  (SHA512): fdaab4a67072528927a2a6c9600b761e086af4894ac0b
                              85221e731fea864567674f6ac2c806fb2a8a05d
                              fe31485ef92ca63f8f4d37448d30715c79bf2738dfd2
Downloaded IMP Image: UCSInstall_CUP_12.5.0.98000-695.iso
File version: 12.5.0.98000-695
File checksum : (MD5): 9e:f3:4e:e0:49:e3:c5:44:16:a5:f9:0e:8d:d5:a7:36
                  (SHA512): 57393dd5e70d43137d5ffb906fd815097f66a5a33e1fc
                              24bf4b6ed86894a6e0794f5f2165bc8395d2217
                              e24ae0b05b4d168b52ae480e5c9f7a29b7170f2ed92a
The IMP servers in the cluster must be rebooted after Unified CM publisher is switched
to the new version,even IF IMP servers are not being being upgraded
Automatically switch versions if the upgrade is successful (yes/no): no
Start installation (yes/no): yes
Cluster-wide upgrade has been initiated...

```

Node	Role	Step	Description	Historical time to complete	Elapsed Time
Ucm_Pub1	CUCM Publisher	1/15	Installing	1:37:13	00:07:14
IM&P_Pub1	IM&P Publisher	0/15	Waiting on Pub	1:20:13	
Ucm_Sub1	CUCM Subscriber	0/15	Waiting on Pub	1:37:13	
Cluster	None	overall	Overall upgrade	4:34:26	00:07:14

## utils system enableAdministration

Configuration changes are not permitted during an upgrade; however, you can use this command to enable emergency provisioning during an upgrade.





- Caution** Once you begin the upgrade process, configuration changes are not permitted until the upgrade is complete and you have performed all of the post-upgrade tasks. Configuration changes include:
- changes made through any of the Unified Communications Manager or IM and Presence Service graphical user interfaces (GUI), the command line interface (CLI), or the AXL API
  - LDAP synchronizations, including incremental synchronizations that are pushed to Unified Communications Manager from an Oracle LDAP
  - automated jobs
  - devices attempting to autoregister

Any configuration changes that you make during an upgrade may be lost, and some configuration changes can cause the upgrade to fail.

---

#### **utils system enableAdministration**

---

**Command Modes** Administrator (admin:)

#### **Requirements**

Command privilege level: 1 and 4

## utils update dst

This command updates the daylight saving time (DST) rules for the current year.

#### **utils update dst**

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines** This command takes a backup of the existing DST rules file and creates a new DST rules file for the current year.



- Caution** Restart the phones after you execute the command. Not restarting the phones results in wrong DST start and stop dates.

---

#### **Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to Unified Communications Manager and IM and Presence Service.

## utils users validate

This command checks user records across all nodes and clusters in the deployment to identify duplicate or invalid userid or directory URI values.

```
utils users validate {all | userid | uri}
```

Syntax Description	Parameters	Description
	<b>all</b>	Validate the userid and directory URI values for all users in the nodes and clusters.
	<b>userid</b>	Validate the userid value for all users in the nodes and clusters.
	<b>uri</b>	Validate the directory URI value for all users in the nodes and clusters.

**Command Modes** Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: IM and Presence Service on Unified Communications Manager

## utils vmtools refresh

This command refreshes the currently installed VMware Tools to the latest version that is prescribed by the ESXi host for that VM.



**Note** After the initial reboot, VMware Tools are in the **running** state. When you upgrade to a newer version of VMware Tools, selinux may initially block the installation. In this case, the system still allows VMware Tools to install, but a new dynamic policy is generated to suppress any additional selinux blockage. You can view the new dynamic policy with the **utils os secure dynamic-policies list** command. For more information, see the **utils os secure dynamic-policies CLI** command.



**Note** This is applicable for native vmtools.

### utils vmtools refresh

**Command Modes** Administrator (admin:)

**Usage Guidelines** To update the current version of the VMware Tools, select **Guest > Install/Upgrade VMWare Tools > Interactive Tools Upgrade**.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection.

### Example

```
admin:utils vmtools refresh
VMware Tools match host. Upgrade allowed, though not required.

***  W A R N I N G  ***
Running this command will update your current version of VMware Tools
to the latest version prescribed by the ESXi host on which this VM is
running. The tools install will cause your system to reboot twice.
```

## utils vmtools status

This command displays the type and the version of currently installed VMware Tools.

### utils vmtools status

---

#### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils vmtools switch open

This command uninstalls the currently installed native VMware Tools and installs the open VMware Tools.

### utils vmtools switch open

---

#### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils vmtools switch native

This command uninstalls the currently installed open VMware Tools and installs the native VMware Tools.

**utils vmtools switch native**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils system boot status

This command shows the location where the system boot messages are to be sent. The location is either console or serial port one.

**utils system boot status**

---

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, Cisco Unity Connection

## utils system upgrade dataexport initiate

This command exports the nodes configuration and user data to a remote SFTP server, for use in a later fresh install with data import.

**utils system upgrade dataexport initiate**

---

### Syntax Description

Parameters	Description
<b>Export Data Directory</b>	Remote directory
<b>Remote Server Name or IP</b>	Remote SFTP
<b>Remote Server Login ID</b>	Username of remote server

Parameters	Description
<b>Remote Server Password</b>	Password for remote server
<b>New Hostname</b>	Destination hostname
<b>New IP Address</b>	Destination IP

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection



**Note** This command should be executed on Publisher first followed by all subscriber nodes in the cluster. Same SFTP Remote server details should be configured for all nodes in the cluster.

## utils system upgrade dataexport status

This command displays the status of the dataexport operation for this cluster node.

**utils system upgrade dataexport status**

**Command Modes** Administrator (admin:)

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils system upgrade dataexport cancel

This command cancels the ongoing dataexport operation.

**utils system upgrade dataexport cancel**

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

## utils ucmgmt agent disable

This command will disable the agent, stop it from running, and prevent it from restarting.

**utils ucmgmt agent disable**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt agent disable
Stopping cloud_agent (via systemctl): [ OK ]
```

## utils ucmgmt agent enable

This command will start the agent and enable the watchdog process to ensure that it is running.

**utils ucmgmt agent enable**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Cisco Unity Connection

**Example**

```
admin:utils ucmgmt agent enable
Agent watchdog activated.
Agent will start up shortly(~ 5 minutes).
```

## utils ucmgmt agent remove

This command will remove the agent and all of its configurations. This is equivalent to running the uninstall cop file.

**utils ucmgmt agent remove**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt agent remove
Removing agent..
Starting removal of UC Management Agent
Agent removal complete.
```

## utils ucmgmt agent restart

This command will restart a running agent immediately, and force the agent to register with the cloud service.

**utils ucmgmt agent restart**

---

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt agent restart
Stopping agent..
Agent is restarting. Check agent status with 'utils ucmgmt agent status'.
```

## utils ucmgmt agent status

This command display status information about the agent.

**utils ucmgmt agent status****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt agent status
Agent Config Information:
  Verification Code: ZUSXXXP9
  Installed UCMGMT Agent version: 20210831-VOS
  Agent's organization id: XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXXX

Agent Runtime Information:
  Agent process is not running.
  To start up the agent, run 'utils ucmgmt agent restart'.
  Agent process is enabled.
  Agent watchdog is enabled.
  Agent is not verified in Webex Control Hub.
```

## utils ucmgmt agent verification

This command displays the verification code of the successfully installed agent.

**utils ucmgmt agent verification****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt agent verification

Verification Code: XXXXXXXX
```

## utils ucmgmt config export

This command creates an agent configuration string for import into an unconfigured agent node.



**utils ucmgmt config export****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt config export
```

```
Organization and proxy configuration processing complete.
```

```
This config can be imported into an unconfigured destination node by running (if available):
'utils ucmgmt config import [[2SedFCjFJiXYUuzwYrxf9mly9FdH_...==]]'
```

**utils ucmgmt config import**

This command imports a configured agent and enables this agent. The agent still needs to be verified in Control Hub.

**utils ucmgmt config import****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt config import
[[2SedFCjFJiXYUuzwYrxf9mly9FdH_U2FsdGVkX18Qt1FwVd4dYKIQqnlLLuvilAGRhTapcaKxWdEFPmhsWIzApSmrymrkYHJq4.....
HE0AUZBfkjBvDpnq5incYdS8SOPtFvilxcKk7x/BIzuSYAIpcRku+uP6XNQ318z/KigrDC1CN03Z+bjrCrXg6ySzzrPzA=]]
Found compatible org in config (XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX).
```

```
Configuration import is complete.
```

```
Agent service will auto-start in the next 5 minutes.
```

```
To start the UCMGMT agent immediately run 'utils ucmgmt agent restart'
```

**utils ucmgmt organization**

This command sets the Control Hub organization ID for the agent if it is not already set.

**utils ucmgmt organization**

Syntax Description	Parameters	Description
	<b>organization_id</b>	Organization ID can be found on the Control Hub. This is a mandatory field.
<b>Command Modes</b>	Administrator (admin:)	
	<b>Requirements</b>	
	Command privilege level: 1	
	Allowed during upgrade: No	
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection	
	<b>Example</b>	
	<pre>min:utils ucmgmt organization XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX</pre>	

## utils ucmgmt proxy add

This command will validate the cloud controller access by using the supplied proxy information. If successful, the proxy is added to the ucmgmt proxy list.

**utils ucmgmt proxy add**

<b>Command Modes</b>	Administrator (admin:)
	<b>Requirements</b>
	Command privilege level: 1
	Allowed during upgrade: No
	Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection
	<b>Example</b>
	<pre>admin:utils ucmgmt proxy add http://proxy.proxy-example.com:8080 test (Optional) Validating Proxy Password (won't display): Re-enter Proxy Password (won't display):  Attempting to contact UCMGMT Cloud Controller... please wait (upto 30 seconds). Successfully contacted controller. {"serviceName": "Lookup Service", "serviceType": "REQUIRED", "serviceState": "online", "message": "Healthy", "lastUpdated": "2022-10-04T22:49:53", "upstreamServices": []}  Adding proxy.proxy-example.com:8080 to proxy list.</pre>

**Example**

```
admin:utils ucmgmt proxy add http://proxy.proxy-example.com:80
```

```
Attempting to contact UCMGMT Cloud Controller... please wait (upto 30 seconds).  
Successfully contacted controller.
```

```
{"serviceName": "Lookup Service", "serviceType": "REQUIRED",  
"serviceState": "online", "message": "Healthy",  
"lastUpdated": "2022-10-06T17:10:30", "upstreamServices": []}
```

```
Adding http://proxy.proxy-example.com:80 to proxy list.
```

## utils ucmgmt proxy clear

This command will clear all the proxies stored for this node.

**utils ucmgmt proxy clear****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt proxy clear
```

## utils ucmgmt proxy force add

This command will add an unvalidated proxy to the agent configured. Proxy will be added to the ucmgmt proxy list without access validation.

**utils ucmgmt proxy force add****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt proxy force add http://staged.proxy.example.com:8080 user1
(Optional) Validating Proxy Password (won't display):
Re-enter Proxy Password (won't display):
```

Adding http://staged.proxy.example.com:8080 to proxy list.

**Example**

```
admin:utils ucmgmt proxy force add http://proxy.proxy-example.com:80
```

Adding http://proxy.proxy-example.com:80 to proxy list.

## utils ucmgmt proxy list

This command lists all the proxies stored for this node. Authenticating proxy credentials listings will redact passwords.

**utils ucmgmt proxy list****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence Service on Unified Communications Manager, and Unity Connection

**Example**

```
admin:utils ucmgmt proxy list
"http://proxy.example.com:80"
"http://user1:<REDACTED>@staged.proxy.example.com:8080"
```