







Uobičajene radnje sa telefonom

Pozivanje	Pozovite broj, a zatim pritisnite  .
Odgovaranje na poziv	Pritisnite  , Odgovori ili  .
Prekidanje	Pritisnite  ili PrekPoz.
Stavljanje poziva na čekanje/preuzimanje poziva	Pritisnite na dugme Čekanje ili Nastavi .
Prenos poziva na novi broj	Izaberite Opcije > Prenesi , unesite određeni broj, a zatim ponovo pritisnite Opcije > Prenesi .
Ponovno biranje broja	Pritisnite  dva puta ili Opcije > PonBir.
Prosleđivanje lokala	Izaberite Opcije > PrSve . Unesite broj telefona na koji želite da prosledite sve pozive. Za otkazivanje izaberite Opcije > PrSve .
Korišćenje evidencije poziva	Izaberite Katalog (Imenik) > Propušteni pozivi, Primljeni pozivi ili Pozvani brojevi . Da biste birali broj, dođite do stavke na listi i pritisnite Biraj ili  .
Pristupanje adresaru telefona	Pritisnite Tel. im. ili Katalog > Telefonski imenik .



Cisco, Cisco Systems, the Cisco logo, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

© 2008 Cisco Systems, Inc. All rights reserved.

OL-18307-01



KRATKE INFORMACIJE



Cisco Unified Wireless IP telefon 7925G za Cisco Unified Communications Manager 7.0

Korišćenje telefona

Tasterske prečice i dugmad






Definicije softverskih tastera

Unošenje teksta






Ikone ekrana telefona



Uobičajene radnje sa telefonom

Korišćenje telefona

Uključivanje/isključivanje telefona	Pritisnite i držite taster  dok se telefon ne uključi ili isključi.
Pristup funkcijama telefona	Pritisnite Opcije da biste dobili listu funkcija: <ul style="list-style-type: none"> • Pritisnite numerički taster funkcije <i>ili</i> • Dodite do funkcije i pritisnite .
Pristup opcijama glavnog menija	Pritisnite strelicu za navigaciju da biste otvorili: <ul style="list-style-type: none"> • Meni kataloga (Imenik) • Prikaz linije (Telefon) • Meni „Postavke“ (Alatke) • Meni „Usluge“ (Svet) Pritisnite numerički taster da biste izabrali opciju menija.
Podešavanje osvetljaja ekrana	Izaberite Postavke > Postavke telefona > Postavke ekrana , a zatim izaberite Osvetljaj ekrana . Pritisnite  ili  , a zatim pritisnite Sačuvaj .
Prelazak na glavni ekran iz prikaza linije	Pritisnite  (strelica nalevo).

Tasterske prečice i dugmad

Naizmenično uključivanje i isključivanje vibracije i tona zvona	Pritisnite i držite  .
Prilagodavanje jačine zvuka zvona, slušalice ili zvučnika	Pritisnite  nagore ili  nadole.
Prigušivanje/uključivanje tona na telefonu	Pritisnite  da biste uključili ili isključili.
Aktivacija zvučnika ili slušalice	Pritisnite i držite  . Da biste koristili slušalicu, još jednom pritisnite i držite dugme.

Pristup govornim porukama	Pritisnite i držite 
Zaključavanje/ otključavanje tastature	Da biste je zaključali, pritisnite i držite  Da biste je otključali, pritisnite Otključaj , a zatim U redu .


Definicije softverskih tastera

DodSebe	Dodavanje sebe u poziv na deljenoj liniji
GJaviSe	Odgovor na poziv koji zvoni u drugoj grupi ili na drugoj liniji
HLlog	Prijavljivanje u hunt grupu ili odjavljivanje iz nje
IDZP	Prijavljivanje sumnjivih poziva
JaviSe	Odgovor na poziv u svojoj grupi
Konfer	Kreiranje konferencijskog poziva
MeetMe	Uspostavljanje „Meet-Me“ konferencije
NeUzn	Uključivanje/isključivanje funkcije „Ne uznemiravaj“ (NeUzn)
Park	Skladištenje aktivnog poziva pomoću opcije parkiranja poziva
Poruka	Pristupanje govornoj pošti
Prenesi	Prenos poziva
PrimObav	Primanje obaveštenja kad lokal koji je zauzet postane dostupan
PrSve	Podešavanje/otkazivanje prosleđivanja poziva
QRT	Prosleđivanje problema vezanih za pozive administratoru sistema
SkrBir	Pozivanje korišćenjem broja indeksa brzog biranja
Spoji	Spajanje više poziva na jednoj liniji da bi se uspostavila konferencija
Tel. im.	Otvaranje telefonskog imenika
tSkreni	Slanje poziva u sistem za razmenu glasovnih poruka
Učesnici	Pregled učesnika konferencije

Ukloni	Uklanjanje učesnika konferencije
UredBr	Uređivanje broja u evidenciji poziva


Unošenje teksta


Znak – pritisnite taster jednom ili više puta.


Razmak – pritisnite taster 


Broj – pritisnite numerički taster.

Simbol – pritisnite sledeće tastere:


 da biste uneli * + - / = \ : ;

 da biste uneli **razmak** , . ‘ “ | _ ~ ’

 da biste uneli # ? () [] { }

 da biste uneli ! @ < > \$ % ^ &

Ikone ekrana telefona

	Poziv stavljen na čekanje
	Deljena linija se koristi
	Prosleđivanje poziva omogućeno
	Dolazni poziv ili BLF nadgledana linija zvoni (samo za BLF JaviSe)
	BLF nadgledana linija se koristi
	BLF nadgledana linija je neaktivna
	BLF nadgledana linija je podešena na stanje „Ne uznemiravaj“
	Brzo biranje, evidencija poziva ili lista kataloga (BLF status nepoznat)
	Interfonska linija je neaktivna

	Zvuk interfonske linije je jednosmeran
	Zvuk interfonske linije je dvosmeran
Funkcije linije	
	Telefonska linija
	URL adresa usluge
	Glasovna poruka
Ostale funkcije	
	Ton je prigušen
	Slušalice su aktivne
	Bluetooth je omogućen
	Bluetooth uređaj je povezan
	Režim zvučnika je aktivan
	Zvono je isključeno (nečujni režim)
	Zvono i vibracija su uključeni
	Uključena je samo vibracija
	Aplikacija je aktivna
	Status radio signala
	Nema radio signala
	Stanje napunjenosti baterije
	Tastatura je zaključana
	Poslovni broj telefona za kontakt
	Kućni broj telefona za kontakt
	Broj mobilnog telefona za kontakt
	Drugi broj telefona za kontakt