802.1x WLAN + VLAN override with Mobility Express (ME) 8.2 and ISE 2.1

Contents

Introduction **Prerequisites Requirements Components Used** Configure **Network Diagram Configurations Configuration on ME Declare ME on ISE** Create a new user on ISE Create the Authentication rule Create the Authorization rule Configuration of end device Verify Authentication process on ME Authentication process on ISE

Introduction

This documents describes how to set up a WLAN (Wireless Local Area Network) with Wi-Fi Protected Access 2 (WPA2) Enterprise security with a Mobility Express controller and an external Remote Authentication Dial-In User Service (RADIUS) server. Identity Service Engine (ISE) is used as example of external RADIUS servers.

The Extensible Authentication Protocol (EAP) used in this guide is Protected Extensible Authentication Protocol (PEAP). Besides that the client is assigned to an specific VLAN (other than the one assigned to the WLAN ny default).

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- 802.1x
- PEAP
- Certification Authority (CA)
- Certificates

Components Used

The information in this document is based on these software and hardware versions:

ME v8.2

ISE v2.1

Windows 10 Laptop

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Configure

Network Diagram



Configurations

The general steps are:

- 1. Create the Service Set Identifier (SSID) in the ME and declare RADIUS server (ISE in this example) on ME
- 2. Declare ME on RADIUS server (ISE)
- 3. Create the authentication rule on ISE
- 4. Create the authorization rule on ISE
- 5. Configure the endpoint

Configuration on ME

In order to allow communication between RADIUS server and ME it is needed to register RADIUS server on ME and vice versa. This step shows how to register RADIUS server on ME.

Step 1. Open the GUI of the ME and navigate to Wireless Settings > WLANs > Add new WLAN.



Step 2. Select a name for the WLAN.

Add Ne	ew WLAN		×
General	WLAN Security	VLAN & Firewall	QoS
	WLAN Id	3	•
	Profile Name *	me-ise	
	SSID *	me-ise	
	Admin State	Enabled	•
	Radio Policy	ALL	•
			oply 🛞 Cancel

Step 3. Specify Security configuration under WLAN Security tab.

Choose **WPA2 Enterprise**, for Authentication server choose **External RADIUS**. Click the edit option to add the RADIUS's ip address and pick a **Shared Secret** key.



Add N	ew WLAN	×
General	WLAN Security	VLAN & Firewall QoS
Authe	Security ntication Server	WPA2 Enterprise • External Radius •
 ⊘ <	Radius IP 🛦	Radius Port Shared Secret 1812 ••••••• e enter valid IPv4 address •••••••
External F all WLANs	Radius configuration a	applies to 🛛 📿 Apply 🛞 Cancel

<a.b.c.d> corresponds to the RADIUS server.

Step 4. Assign a VLAN to the SSID.

If the SSID needs to be assigned to the AP's VLAN this step can be skipped.

In order to assign the users for this SSID to a specific VLAN (other than AP's VLAN), enable **Use VLAN Tagging** and assign the desired **VLAN ID**.

Add New WLAN	×
General WLAN Security	VLAN & Firewall QoS
Use VLAN Tagging	Yes 🔻
VLAN ID *	2400 🔹
Enable Firewall	No
VLAN and Firewall configuration all WLANs	n apply to 🛛 🕢 Apply 🛞 Cancel

Note: If VLAN Tagging is used, be sure that the switchport where the Access Point is connected to, is configured as trunk port and the AP VLAN is configured as native.

Step 5. Click **Apply** to finish the configuration.

Add New WLAN	×				
General WLAN Security	VLAN & Firewall QoS				
Use VLAN Tagging	Yes				
VLAN ID *	2400 🔹				
Enable Firewall	No				
VLAN and Firewall configuration apply to all WLANs Cancel					

Step 6. Optional, configure the WLAN to accept the VLAN override.

Enable AAA override on the WLAN and add the needed VLANs. To do so you will nee to open a CLI session to the ME management interface and issue these commands:

```
>config wlan disable <wlan-id>
>config wlan aaa-override enable <wlan-id>
>config wlan enable <wlan-id>
>config flexconnect group default-flexgroup vlan add <vlan-id>
Declare ME on ISE
```

Step 1. Open ISE console and navigate to **Administration > Network Resources > Network Devices > Add.**

elisio Identity Serv	rices Engine Home	e 🔹 🕨 Context Visibil	lity	ns • Policy	 Administration 	→ Worl
♦ System ♦ Ident	iity Management 🛛 🕶 Netw	ork Resources 🔹 Þ D	evice Portal Manag	ement pxGrid	Services 🔹 🕨 Feed Se	ervice I
✓ Network Devices	Network Device Groups	Network Device Pro	ofiles External RA	ADIUS Servers	RADIUS Server Sequ	ences
	Ø					
Network devices	Ne	twork Devices				
Default Device	/	Edit 🕂 Add 🕞 Dupl	icate 😭 Import (🏷 Export 👻 🙆	Senerate PAC XDele	te 🔻

Step 2. Enter the information.

Optionally it can be specified a Model name, software version, description and assign Network

Device groups based on device types, location or WLCs.

a.b.c.d correspond to the ME's IP address.

Network Devices List > New Network Device Network Devices
* Name WLC-name
Description optional description
IP Address: a.b.c.d / 32
* Device Profile 😅 Cisco 💌 🕀
Model Name wic-model
Software Version wlc-software 🍷
* Network Device Group
Device Type WLCs-2504 📀 Set To Default
Location All Locations 📀 Set To Default
WLCs 😡 Set To Default
✓ RADIUS Authentication Settings
Enable Authentication Settings
Protocol RADIUS
* Shared Secret Show
Enable KeyWrap 🗌 🕡
* Key Encryption Key Show
* Message Authenticator Code Key Show
Key Input Format 💿 ASCII 🔵 HEXADECIMAL
CoA Port 1700 Set To Default

For more information about Network Device Groups review this link:

Create a new user on ISE

Step 1. Navigate to Administration > Identity Management > Identities > Users > Add.

diado Identity Services Engine	Home	▶ Context Visibility	 Operations 	▶ Policy	 Administration
► System	nt 🕨 Network	Resources 🔹 🕨 Devid	e Portal Managemer	nt pxGrid 8	System
◄Identities Groups External	Identity Sources	Identity Source Se	quences 🔹 🕨 Setting	s	Licensing
Users	O Netwo	rk Access Users			Certificates Logging Maintenance
Latest Manual Network Scan Res	🥖 Edit	🕂 Add 🔢 Change S	Status 👻 🎲 Import	🕞 Export 👻	Upgrade Backup & Restor
	Sta	atus Name		Description	Admin Access
	jų Lo	ading		_	Settings
					Identity Managem
					Identities

Step 2. Enter the information.

In this example this user belongs to a group called ALL_ACCOUNTS but it can be adjusted as needed.

Network Access Users List > New Network Access User						
Network Access User						
*Name user1						
Status 🔽 Enabled 👻						
Email						
Passwords						
Password Type: Internal Users 🔹						
Password	Re-Enter Passw					
* Login Password	•••••					
Enable Password						
User Information						
First Name						
Last Name						
 Account Options 						
Description						
Change password on next login						
 Account Disable Policy 						
Disable account if date exceeds 2017-01-21						
▼ User Grouns						
Submit Cancel						

Create the Authentication rule

Authentication rules are used to verify if the credentials of the users are right (Verify if the user really is who it says it is) and limit the authentication methods that are allowed to be used by it.

Step 1. Navigate to **Policy > Authentication**.



Step 2. Insert a new authentication rule.

To do so navigate to **Policy > Authentication > Insert new row above/below.**

diate Identity Services Engine	Home	▶ Operations	► Administration	▶ Work Centers	Li
Authentication Authorization F	Profiling Posture Client Provisio	oning			
ting the protocols that ISE should use to	communicate with the network device	es and the identity sources that	it should use for auther	ntication	
ed	ort Page				
: If Wired_MAB OR _Protocols and				Ir	isert new row above
use Internal Endpoints : If Wired_802.1X OR					uplicate above uplicate below

Step 3. Enter the needed information

This authentication rule example allows all the protocols listed under the **Default Network Access** list, this applies to the authentication request for Wireless 802.1x clients and with Called-Station-ID and ends with *ise-ssid*.

dialo Identity S	ervices Engine	Home	Context Visibility	 Operations 	▼Policy	Administration	Work Centers	
Authentication	Authorization	Profiling Postu	ire Client Provisio	ning 🔹 🕨 Policy Ele	ements			
Authentication	n Policy tication Policy by s to Administration	electing the protoc n > System > Back -Based	cols that ISE should u cup & Restore > Polic	ise to communicate y Export Page	e with the netv	vork devices, and the i	identity sources that it sh	iould use for authentica
	Rule name		If Wireless_802.1	X AND Select Attrib	ute 🔍 A	low Protocols : Defau	ult Network Access	📀 and 👝 .
	Default	:	Us Condition	nditions Below to L Name D2.1X O A c	ibrary Description ondition to m Radius:Cal	atch 802.1X based au ed-Sta 📀 🛛 End:	uthentication request	AND - AND

Also, choose the Identity source for the clients that matches this authentication rule, in this example it is used *Internal users*

Rule name : If	Allow Protocols : Defau	It Network Access 📀 and .
✓ Default : Use	Internal Users Identity Source Internal Users Options If authentication failed Reject If user not found Reject If process failed Drop Note: For authentications using PEAP, LEAP, EAP-FAST, EAP-TLS or it is not possible to continue processing when authentication fails o If continue option is selected in these cases, requests will be reject	Identity Source List
		Tureulai Ozeiz

Once It is finished click Done and Save

Rule name	: If Wireless_802.1X AND Radius: Cal 🔶 Allow Protocols : Default Network Access 📀 and	Done
🔽 🕶 Default	: Use Internal Users 🗇	Actions 👻
Save		

For more information about Allow Protocols Policies consult this link:

Allowed Protocols Service

For more information about Identity sources consult this link:

Create a User Identity Group

Create the Authorization rule

The authorization rule is the one in charge to determine if the client is allowed to join the network or not

Step 1. Navigate to **Policy > Authorization.**

es Engine	e Home) ¢	ontext Visibility	Operations	→Policy	Administration	Work Centers
norization	Profiling Po:	sture	Client Provisionin	g 🔹 🕨 Policy Ele	Authentic	ation	Authorization
					Profiling		Posture
V Policy by co dministratio	onfiguring rules k on > System > Ba	oased (ackup &	on identity groups ar k Restore ≻ Policy E	nd/or other condi xport Page	Client Pro	wisioning	Policy Elements Dictionaries Conditions Results

Step 2. Insert a new rule. Navigate to **Policy > Authorization > Insert New Rule Above/Below.**

cisco	Identity	Services Engine	Home	Context Visibility	Operations	→ Policy	Administration	Work Centers	License \
Authe	entication	Authorization Prot	filing Postur	e Client Provisioning	 Policy Eleme 	nts			
dia sina s	ulaa haaad	on identity wayne and	lar athar and	tions Dress and dress vid	aa ta ahanwa tha	ordor			
> System	> Backup	& Restore > Policy Expo	ort Page	uons. Drag and drop ru	es to change the t	or der.			
-									
		Conditions (ider	ntity groups an	d other conditions)		1	Permissions		
									Insert New Rule Above
									Insert New Rule Below
									Duplicate Above
									Duplicate Below

Step 3. Enter the information.

First choose a name for the rule and the Identity groups where the user is stored. In this example the user is stored in group *ALL_ACCOUNTS*.

Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule Image: NameAuthZrule	
Image: Second Action Characteristic Second Action Characteristi	¢
Image: Second Coscond	
User Identity Groups USer Identity Groups S S Frank SPth Cheo IP District If Non	s de ost
🛛 🔽 Frank S Mar (1999) Phanas if Non	
	872
Charpiant_Devices_Account if Met	
I Constant Sector (default)	1 4004755
Etipioves Ophoenting if (Mireless_800.4M AND EAP-MSCHARV2.) ALL_ACCOUNTS (default) CP_Optic & DDD	39212

After that choose other conditions that make the authorization process to fall into this rule. In this example the authorization process hits this rule if it uses 802.1x Wireless and it is called station ID ends with *ise-ssid*.

	Status	Rule Name	Conditions (id	dentity groups :	and other conditions)	Permissions	
Ø	-	NameAuthZrule	if AL	🛟 and	Wireless_802.1X AND Radius:Call	😑 then 🛛 AuthZ Pr 💠	
1	2			15	💾 Add All Conditions Below to Librar	у	
				٩	Condition Name De	scription	AND -
1					Wireless 802.1X 💟 Normali:	adius:Called-Stat 🚫 Ends With 👻 ise-ssic	
12	~			e			

Finally choose the Authorization profile that allows the clients to join the network, click **Done** and **Save.**

	Status	Rule Name	Conditions (ide	tity groups and other conditions))	Permi	issions		
	-	NameAuthZrule	if AL		ND Radius:Call	💠 then	PermitAc		Done
1	<u>~</u>								Edit 🕶
1						1	PermitAccess		Edit 🕶
1								Standard	Edit 🕶
1	<u>~</u>								Edit -
1	0							€ E	Edit 🕶
1	0								Edit 🕶
1	0								Edit 🕶
1	0								Edit 🕶
1	0							PermitAccess	Edit -
1									Edit 🕶
	~	Default	if no matches, the	DenyAccess					Edit 🕶
	_								
Sa	ve Res	et							

Optionally, create a new authorization profile that will assign the wireless client to a different VLAN:

•		
(> -+	
	Standard	
	↓ ■ .	<u>िं</u> द्र
	😪 Blackhole_Wireless_Access	🎡 Add New Standard Profile

Enter the information:

Add New Standard Pro	file		Þ
Authorization Profile		í	1
* Name	I name-of-profile		
Description			
* Access Type	ACCESS_ACCEPT T		
Network Device Profile	the Cisco v 🕀	_	
Service Template			
Track Movement			
Passive Identity Tracking			
- Common Trades			
 Common Tasks 		^	
DACL Name			
ACL (Filter-ID)		- 11	
		- 11	
🗹 VLAN	Tag ID 1 Edit Tag IDIName van-Id	- 11	
Voice Domain Perm	lission	~	
 Advanced Attribut 	tes Settings	_	
Select an item			
		_	
 Attributes Details 			
Access Type = ACCESS Tunnel-Private-Group-ID Tunnel-Type = 1:13 Tunnel-Medium-Type =	ACCEPT > = 1:vlan-id 1:6		
٢		>	
		Save	ancel

Configuration of end device

Configure a Windows 10 laptop to connect to an SSID with 802.1x Authentication using PEAP/MS-CHAPv2 (Microsoft version of the Challenge-Handshake Authentication Protocol version 2).

In this configuration example ISE uses its self-signed certificate to perform the authentication.

To create the WLAN profile on the windows machine there are two options:

- 1. Install the self-signed certificate on the machine to validate and trust ISE server to complete the authentication
- 2. Bypass the validation of the RADIUS server and trust any RADIUS server used to perform the authentication (not recommended, as it can become a security issue)

The configuration for these options are explained on <u>End device configuration - Create the WLAN</u> <u>Profile - Step 7</u>.

End device configuration - Install ISE self-signed certificate

Step 1. Export self-signed certificate from ISE.

Log in to ISE and navigate to Administration > System > Certificates > System Certificates.

Then select the certificate used for EAP Authentication and click Export.



Save the certificate in the needed location. This certificate is installed on the Windows machine.

Export Certificate 'EAP-SelfSignedCertificate#EAP-SelfSignedCertificate#00001'	×
 Export Certificate Only 	
Export Certificate and Private Key	
*Private Key Password	
*Confirm Password	
Warning: Exporting a private key is not a secure operation. It could lead to possible exposure of the private l	œy.
Export	ncel

Step 2. Install the certificate in the Windows machine.

Copy the certificate exported before into the Windows machine, change the extension of the file from .pem to .crt, after that double click on it and select **Install Certificate...**.

80	Certificate	×
Ger	neral Details Certification Path	
ſ	Certificate Information	1
	This CA Root certificate is not trusted. To enable trust, install this certificate in the Trusted Root Certification Authorities store.	
	Issued to: EAP-SelfSignedCertificate	
	Issued by: EAP-SelfSignedCertificate	
	Valid from 23/11/2016 to 23/11/2018	
	Install Certificate Issuer Statement	
	OK	

Choose to install it in Local Machine, then click Next.

🔶 😸 Certificate Import Wizard	^
Welcome to the Certificate Import Wizard	
This wizard helps you copy certificates, certificate trust lists, and certificate revocation lists from your disk to a certificate store.	
A certificate, which is issued by a certification authority, is a confirmation of your identity and contains information used to protect data or to establish secure network connections. A certificate store is the system area where certificates are kept.	
Store Location Current User Local Machine	
To continue, click Next.	
	:I

Select Place all certificates in the following store, then browse and choose Trusted Root Certification Authorities. After that click Next.

÷	Servificate Import Wizard	×
	Certificate Store Certificate stores are system areas where certificates are kept.	
	Windows can automatically select a certificate store, or you can specify a location for the certificate.	
	O Automatically select the certificate store based on the type of certificate	
	Place all certificates in the following store	
	Certificate store:	
	Trusted Root Certification Authorities Browse	
	Next Canc	el

Then click Finish.

I

÷	🚰 Certificate Import Wizard	×
	Completing the Certificate Import Wizard	
	The certificate will be imported after you click Finish.	
	You have specified the following settings:	
	Certificate Store Selected by User Trusted Root Certification Authorities Content Certificate	
	Finish Cancel	

At the end click **Yes** to confirm the installation of the certificate.

Security Warning

You are about to install a certificate from a certification authority (CA) claiming to represent:

EAP-SelfSignedCertificate

Windows cannot validate that the certificate is actually from "EAP-SelfSignedCertificate". You should confirm its origin by contacting "EAP-SelfSignedCertificate". The following number will assist you in this process:

Warning:

If you install this root certificate, Windows will automatically trust any certificate issued by this CA. Installing a certificate with an unconfirmed thumbprint is a security risk. If you click "Yes" you acknowledge this risk.

Do you want to install this certificate?



Finally click OK.



End device configuration - Create the WLAN Profile

Step 1. Right click on Start icon and select Control panel.

Programs and Features							
Mobility Center							
Power Options							
Event Viewer							
System							
Device Manager							
Network Connections							
Disk Management							
Computer Management							
Command Prompt							
Command Prompt (Admin)							
Task Manager							
Control Panel							
File Explorer							
Search							
Run							
Shut down or sign out	>						
Desktop							
ען גען אין אין אין אין אין אין אין אין אין אי	u i						

Step 2. Navigate to **Network and Internet** and then to **Network and Sharing Center** and click on **Set up a new connection or network.**

💐 Network and Sharing Center										
← → ✓ ↑ 💐 > Control Panel > Network and Internet > Network and Sharing Center										
Control Panel Home View your basic network information and set up connections										
Change adapter settings	View your active networks									
Change advanced sharing settings	cisco.com Domain network	Access type: Internet Connections: <i>«</i> Ethernet								
	Change your networking settings Set up a new connection or ne Set up a broadband, dial-up, o Troubleshoot problems Diagnose and repair network p	etwork or VPN connection; or set up a router or access point. problems, or get troubleshooting information.								

Step 3. Select Manually connect to a wireless network and click Next.

	_		×
🗧 👙 Set Up a Connection or Network			
Choose a connection option			
choose a connection option			
Connect to the Internet			
Set up a broadband or dial-up connection to the Internet.			
Set up a new network			
bet up a new router of access point.			
Connect to a hidden network or create a new wireless profile.			
Connect to a workplace			
Set up a dial-up or VPN connection to your workplace.			
	Next	Can	cel

Step 4. Enter the information with the name of the SSID and security type WPA2-Enterprise and click **Next**.

					-		×
4	💐 Manually connect to a v	vireless network					
	Enter information for	r the wireless network y	ou want to ad	d			
	Network name:	ise-ssid					
	Security type:	WPA2-Enterprise	~				
	Encryption type:	AES	\checkmark				
	Security Key:		Hide chara	cters			
	Start this connection	automatically					
	Connect even if the r	network is not broadcasting					
	Warning: If you seled	ct this option, your computer's	privacy might be at	risk.			
				Next		Cano	cel

Step 5. Select **Change connection settings** to customize the configuration of the WLAN profile.

		_		×
←	💐 Manually connect to a wireless network			
	Successfully added ise-ssid			
	Change connection settings Open the connection properties so that I can change the settings.			
			Clo	se

Step 6. Navigate to Security tab and click Settings.

ise-ssid Wireless Ne	twork Properties		×
Connection Security			
Security type:	WPA2-Enterprise	~	
Encryption type:	AES	~	
Choose a network au	thentication method:		
Microsoft: Protected	EAP (PEAP) 🗸 🗸	Settings	
Remember my cro	edentials for this connec	tion each	
une in logged o			
	_		
Advanced settings	•		
		ОК	Cancel

Step 7. Choose if RADIUS server is validated or not.

If yes, enable Verify the server's identity by validating the certificate and from Trusted Root Certification Authorities: list select the self-signed certificate of ISE.

After that select **Configure** and disable **Automatically use my Windows logon name and password...**, then click **OK**

Protected EAP Properties	×
When connecting:	
Verify the server's identity by validating the certificate	
Connect to these servers (examples:srv1;srv2;.*\.srv3\.com):	
Trusted Root Certification Authorities:	
Eggille & Clobel Line and	^
EAP-SelfSignedCertificate	
 Fortunet Road Contribution for the fortune Low Science Contribution (1977) Sup (1977) E., Contribution (1972) State Science Lag Contribution (1972) 	~
< >	
Notifications before connecting:	
Tell user if the server name or root certificate isn't specified	~
Select Authentication Method:	_
Secured password (EAP-MSCHAP v2) Configu	re
C Enable Fast Reconnect	
Disconnect if server does not present cryptobinding TLV	
Enable Identity Privacy	
OK Cano	el

EAP MSCHAPv2 Properties						
When connecting:						
Automatically use my Windows logon name and password (and domain if any).						
OK Cancel						

Once back to **Security** tab, select **Advanced settings**, specify authentication mode as **User authentication** and save the credentials that were configured on ISE to authenticate the user.

ise-ssid Wireless Network Properties 🛛 🕹 🗙								
Connection Security								
Security type:	WPA2-Enterprise		~					
Encryption type:	AES		~					
Choose a network aut	thentication method:							
Microsoft: Protected	EAP (PEAP) 🛛 🗸	Settin	gs					
Remember my cre time I'm logged o	edentials for this connect n	tion each						
	_							
Advanced settings								
		ОК	Cancel					

Advanced sett	ings		×				
802.1X settings	802.11 settings						
Specify a	uthentication mode:						
User aut	hentication $$	Save credent	tials				
Delete credentials for all users							
Enable si	ngle sign on for this network						
Perfo	rm immediately before user log	ion					
O Perfo	rm immediately after user logo	n					
Maximun	n delay (seconds):	10	*				
Allow sign o	additional dialogs to be display on	ed during single					
This r and u	network uses separate virtual L ser authentication	ANs for machine					
		ОК	Cancel				

Windows Secur	ity	×
Save creder Saving your cre when you're no	itials dentials allows your computer to connect to the network t logged on (for example, to download updates).	
altalta cisco	user1	
	OK Cancel	

Verify

The authentication flow can be verified from WLC or from ISE perspective.

Authentication process on ME

Run this command to monitor the authentication process for a specific user:

> debug client <mac-add-client>
Example of a successful authentication (some output has been omitted):

```
*apfMsConnTask_0: Nov 25 16:36:24.333: 08:74:02:77:13:45 Processing assoc-req
station:08:74:02:77:13:45 AP:38:ed:18:c6:7b:40-01 thread:669ba80
*apfMsConnTask_0: Nov 25 16:36:24.333: 08:74:02:77:13:45 Association received from mobile on
BSSID 38:ed:18:c6:7b:4d AP 1852-4
*apfMsConnTask_0: Nov 25 16:36:24.334: 08:74:02:77:13:45 Applying site-specific Local Bridging
override for station 08:74:02:77:13:45 - vapId 3, site 'FlexGroup', interface 'management'
*apfMsConnTask_0: Nov 25 16:36:24.334: 08:74:02:77:13:45 Applying Local Bridging Interface
Policy for station 08:74:02:77:13:45 - vlan 0, interface id 0, interface 'management'
*apfMsConnTask_0: Nov 25 16:36:24.334: 08:74:02:77:13:45 Set Clinet Non AP specific
apfMsAccessVlan = 2400
*apfMsConnTask_0: Nov 25 16:36:24.334: 08:74:02:77:13:45 This apfMsAccessVlan may be changed
later from AAA after L2 Auth
*apfMsConnTask_0: Nov 25 16:36:24.334: 08:74:02:77:13:45 Received 802.11i 802.1X key management
suite, enabling dot1x Authentication
*apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 0.0.0.0 START (0) Change state to
AUTHCHECK (2) last state START (0)
*apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 0.0.0.0 AUTHCHECK (2) Change state to
8021X_REQD (3) last state AUTHCHECK (2)
*apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 0.0.0.0 8021X_REQD (3) DHCP required on
```

AP 38:ed:18:c6:7b:40 vapId 3 apVapId 3for this client *apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 apfPemAddUser2:session timeout forstation 08:74:02:77:13:45 - Session Tout 0, apfMsTimeOut '0' and sessionTimerRunning flag is *apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 Stopping deletion of Mobile Station: (callerId: 48) *apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 Func: apfPemAddUser2, Ms Timeout = 0, Session Timeout = 0*apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 Sending assoc-resp with status 0 station:08:74:02:77:13:45 AP:38:ed:18:c6:7b:40-01 on apVapId 3 *apfMsConnTask_0: Nov 25 16:36:24.335: 08:74:02:77:13:45 Sending Assoc Response to station on BSSID 38:ed:18:c6:7b:4d (status 0) ApVapId 3 Slot 1 *spamApTask0: Nov 25 16:36:24.341: 08:74:02:77:13:45 Sent dot1x auth initiate message for mobile 08:74:02:77:13:45 *Dotlx_NW_MsgTask_0: Nov 25 16:36:24.342: 08:74:02:77:13:45 reauth_sm state transition 0 ---> 1 for mobile 08:74:02:77:13:45 at 1x_reauth_sm.c:47 *Dot1x_NW_MsgTask_0: Nov 25 16:36:24.342: 08:74:02:77:13:45 EAP-PARAM Debug - eap-params for Wlan-Id :3 is disabled - applying Global eap timers and retries *Dot1x NW_MsqTask_0: Nov 25 16:36:24.342: 08:74:02:77:13:45 Disable re-auth, use PMK lifetime. *Dot1x_NW_MsgTask_0: Nov 25 16:36:24.342: 08:74:02:77:13:45 Station 08:74:02:77:13:45 setting dot1x reauth timeout = 1800 *Dotlx_NW_MsgTask_0: Nov 25 16:36:24.342: 08:74:02:77:13:45 dotlx - moving mobile 08:74:02:77:13:45 into Connecting state *Dot1x_NW_MsgTask_0: Nov 25 16:36:24.342: 08:74:02:77:13:45 Sending EAP-Request/Identity to mobile 08:74:02:77:13:45 (EAP Id 1) *Dot1x_NW_MsgTask_0: Nov 25 16:36:24.401: 08:74:02:77:13:45 Received EAPOL EAPPKT from mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:24.401: 08:74:02:77:13:45 Received Identity Response (count=1) from mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.978: 08:74:02:77:13:45 Processing Access-Accept for mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.978: 08:74:02:77:13:45 Username entry (user1) created in mscb for mobile, length = 253 *Dot1x NW MsgTask_0: Nov 25 16:36:25.978: 08:74:02:77:13:45 Station 08:74:02:77:13:45 setting dot1x reauth timeout = 1800 *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.978: 08:74:02:77:13:45 Creating a PKC PMKID Cache entry for station 08:74:02:77:13:45 (RSN 2) *Dot1x NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Adding BSSID 38:ed:18:c6:7b:4d to PMKID cache at index 0 for station 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: New PMKID: (16) *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.979: [0000] 80 3a 20 8c 8f c2 4c 18 7d 4c 28 e7 7f 10 11 03 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Adding Audit session ID payload in Mobility handoff *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 0 PMK-update groupcast messages sent *Dot1x NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 PMK sent to mobility group *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Disabling re-auth since PMK lifetime can take care of same. *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Sending EAP-Success to mobile 08:74:02:77:13:45 (EAP Id 70) *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Freeing AAACB from Dot1xCB as AAA auth is done for mobile 08:74:02:77:13:45 *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Found an cache entry for BSSID 38:ed:18:c6:7b:4d in PMKID cache at index 0 of station 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Found an cache entry for BSSID 38:ed:18:c6:7b:4d in PMKID cache at index 0 of station 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: Including PMKID in M1 (16) *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.979: [0000] 80 3a 20 8c 8f c2 4c 18 7d 4c 28 e7 7f 10 11 03 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: M1 - Key Data: (22) *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.979: [0000] dd 14 00 0f ac 04 80 3a 20 8c 8f c2 4c 18 7d 4c *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: [0016] 28 e7 7f 10 11 03 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.979: 08:74:02:77:13:45 Starting key exchange to mobile

*Dot1x_NW_MsgTask_0: Nov 25 16:36:25.980: 08:74:02:77:13:45 Sending EAPOL-Key Message to mobile 08:74:02:77:13:45 state INITPMK (message 1), replay counter 00.00.00.00.00.00.00 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.980: 08:74:02:77:13:45 Reusing allocated memory for EAP Pkt for retransmission to mobile 08:74:02:77:13:45 *Dot1x NW_MsgTask_0: Nov 25 16:36:25.980: 08:74:02:77:13:45 Entering Backend Auth Success state (id=70) for mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.980: 08:74:02:77:13:45 Received Auth Success while in Authenticating state for mobile 08:74:02:77:13:45 *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.980: 08:74:02:77:13:45 dotlx - moving mobile 08:74:02:77:13:45 into Authenticated state *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.983: 08:74:02:77:13:45 Received EAPOL-Key from mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.983: 08:74:02:77:13:45 Received EAPOL-key in PTK_START state (message 2) from mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.983: 08:74:02:77:13:45 Successfully computed PTK from PMK!!! *Dot1x NW_MsgTask_0: Nov 25 16:36:25.983: 08:74:02:77:13:45 Received valid MIC in EAPOL Key Message M2!!!!! *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.984: 00000000: 30 14 01 00 00 0f ac 04 01 00 00 0f ac 04 01 00 0..... *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.984: 00000010: 00 0f ac 01 0c 00 *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.984: 00000000: 01 00 00 of ac 04 01 00 00 of ac 04 01 00 00 Of *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.984: 00000010: ac 01 0c 00 *Dot1x NW_MsgTask_0: Nov 25 16:36:25.984: 08:74:02:77:13:45 PMK: Sending cache add *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.984: 08:74:02:77:13:45 Stopping retransmission timer for mobile 08:74:02:77:13:45 *Dot1x NW MsqTask_0: Nov 25 16:36:25.984: 08:74:02:77:13:45 Sending EAPOL-Key Message to mobile 08:74:02:77:13:45 state PTKINITNEGOTIATING (message 3), replay counter 00.00.00.00.00.00.00.01 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.984: 08:74:02:77:13:45 Reusing allocated memory for EAP Pkt for retransmission to mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Received EAPOL-key in PTKINITNEGOTIATING state (message 4) from mobile 08:74:02:77:13:45 *Dotlx NW MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Stopping retransmission timer for mobile 08:74:02:77:13:45 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 0.0.0.0 8021X_REQD (3) Change state to L2AUTHCOMPLETE (4) last state 8021X_REQD (3) *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Mobility query, PEM State: L2AUTHCOMPLETE *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Building Mobile Announce : *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Building Client Payload: *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Client Ip: 0.0.0.0 *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Client Vlan Ip: 172.16.0.136, Vlan mask : 255.255.255.224 *Dot1x NW_MsqTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Client Vap Security: 16384 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Virtual Ip: 192.0.2.1 *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 ssid: ise-ssid *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Building VlanIpPayload. *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 0.0.0.0 L2AUTHCOMPLETE (4) DHCP required on AP 38:ed:18:c6:7b:40 vapId 3 apVapId 3for this client *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 Not Using WMM Compliance code qosCap 00 *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 0.0.0.0 L2AUTHCOMPLETE (4) Plumbed mobile LWAPP rule on AP 38:ed:18:c6:7b:40 vapId 3 apVapId 3 flex-acl-name: *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 0.0.0.0 L2AUTHCOMPLETE (4) Change state to DHCP_REQD (7) last state L2AUTHCOMPLETE (4) *Dotlx_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) pemAdvanceState2 6623, Adding TMP rule *Dot1x_NW_MsgTask_0: Nov 25 16:36:25.988: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) Adding Fast Path rule type = Airespace AP - Learn IP address

08:74:02:77:13:45, data packets will be dropped

on AP 38:ed:18:c6:7b:40, slot 1, interface = 1, QOS = 0 IPv4 ACL ID = 255, IPv *apfReceiveTask: Nov 25 16:36:25.989: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) mobility role update request from Unassociated to Local Peer = 0.0.0.0, Old Anchor = 0.0.0.0, New Anchor = 172.16.0.136 *apfReceiveTask: Nov 25 16:36:25.989: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) State Update from Mobility-Incomplete to Mobility-Complete, mobility role=Local, client state=APF_MS_STATE_ASSOCIATED *apfReceiveTask: Nov 25 16:36:25.989: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) pemAdvanceState2 6261, Adding TMP rule *apfReceiveTask: Nov 25 16:36:25.989: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) Replacing Fast Path rule type = Airespace AP - Learn IP address on AP 38:ed:18:c6:7b:40, slot 1, interface = 1, QOS = 0 IPv4 ACL ID = 255, *apfReceiveTask: Nov 25 16:36:25.989: 08:74:02:77:13:45 0.0.0.0 DHCP_REQD (7) Successfully plumbed mobile rule (IPv4 ACL ID 255, IPv6 ACL ID 255, L2 ACL ID 255) *pemReceiveTask: Nov 25 16:36:25.990: 08:74:02:77:13:45 0.0.0.0 Added NPU entry of type 9, dtlFlags 0x0 *pemReceiveTask: Nov 25 16:36:25.990: 08:74:02:77:13:45 0.0.0.0 Added NPU entry of type 9, dtlFlags 0x0 *apfReceiveTask: Nov 25 16:36:27.835: 08:74:02:77:13:45 WcdbClientUpdate: IP Binding from WCDB ip_learn_type 1, add_or_delete 1 *apfReceiveTask: Nov 25 16:36:27.835: 08:74:02:77:13:45 IPv4 Addr: 0:0:0:0 *apfReceiveTask: Nov 25 16:36:27.835: 08:74:02:77:13:45 In apfRegisterIpAddrOnMscb_debug: regType=1 Invalid src IP address, 0.0.0.0 is part of reserved ip address range (caller apf_ms.c:3593) *apfReceiveTask: Nov 25 16:36:27.835: 08:74:02:77:13:45 IPv4 Addr: 0:0:0:0 *apfReceiveTask: Nov 25 16:36:27.840: 08:74:02:77:13:45 WcdbClientUpdate: IP Binding from WCDB ip_learn_type 1, add_or_delete 1 *apfReceiveTask: Nov 25 16:36:27.841: 08:74:02:77:13:45 172.16.0.16 DHCP_REQD (7) Change state to RUN (20) last state DHCP_REQD (7)

For an easy way to read debug client outputs, use the Wireless debug analyzer tool:

Wireless Debug Analyzer

Authentication process on ISE

Navigate to **Operations > RADIUS > Live Logs** in order to see which authentication policy, authorization policy and authorization profile assigned to the user.

altalta cisco	Identi	ty Service	s Engine	Home	Context Vis	sibility 🔽	perations	In Policy	• Administrati	ion → \	Work Centers		License
▼RA	ADIUS	TC-NAC Liv	ve Logs	+ TACACS	Reports + Tro	oubleshoot	 Adaptive N 	Network Control					
Live	Logs	Live Sessio	ons										
	Misconfigured Supplicants		ants Mis	sconfigured Devices	nfigured Network RADIUS Drops C Devices C		Client Stopped Respondi		nding Repe				
										Refresh	Never	_ Sł	Latest 20 record
OR	Refresh	C Reset	t Repeat Co	ounts 🛛 💆 E	Export To 🕶								
	Time	Time Sta Details Ide Endpoint ID Endpoint		int Au	uthentication	Policy	Autho	rization Polic:	y Auth	norization Profiles			
	No	0	ò	user1	08:74:02:77:13:	:45 Apple-D	evice De	fault >> Rule na	me >> Default	Default	>> NameAuthZr	rule Permi	itAccess

For more information click on **Details** to see a more detailed authentication process.